## Steckverbinder

# Systembus

A	Pin	В
GND	01	GND
+12V	02	+12V
/WR	03	/IORQ
/BUSAK	04	/RD
/M1	05	RFSH
/MREQ	06	/HALT
/BAO	07	/BAI
/MEMI	08	
A3	09	A4
A2	10	A5
Al	11	A6
A0	12	A7
-	13	-
-	14	/BUSRQ
/NMI	15	/INT
A8	16	A15
A9	17	A14
A10	18	A13
A11	19	A12
/SEL	20	/Clear
/WAIT	21	/RESET
D0	22	D4
D1	23	D5
D2	24	D6
D3	25	D7
TAKT	26	Takt-IN
/IEO	27	/IEI
-5V	28	-5V
+5V	29	+5V

#### DSY5

A	Pin	В
VID	01	SYN
MV	02	MS
GND	03	GND

GND	04	GND
BAS	05	BAS

# SBC3

### XB1-PIO

A	Pin	В
BRDY	01	ARDY
BSTB	02	ASTB
В0	03	A0
B1	04	A1
B2	05	A2
В3	06	A3
B4	07	A4
В5	08	A5
В6	09	A6
В7	10	A7
GND	11	GND
-5V	12	+12V
+5V	13	+5V

## XB2-CTC

A	Pin	В
GND	01	GND
+5V	02	C/TRG3
ZC/T2	03	C/TRG2
ZC/T1	04	C/TRG1
ZC/T0	05	C/TRG0

## <u>FDC</u>

PIN	A	В	C
1	1	GND	/DIR
2	1	GND	/LC
3	-	GND	/ST
4	/MO0	GND	/FR
5	/MO1	GND	/HDSel
6	/MO2	GND	/HDL
7	/MO3	GND	/WE
8	/WD	GND	-
9	/IX	GND	/RDY

10	/DS0	GND	/T0
11	/DS1	GND	/FLT
12	/DS2	GND	/2S
13	/DS3	GND	/WP

#### res

A	Pin	В
01		
02		
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		
13		

Zuletzt geändert: 2011/09/07 15:24 von joerg