Hardware-Software-Codesign

Felix Leitl

9. September 2025

Inhaltsverzeichnis

Architectures
General-Purpose Processors
Reasons for High Performance
General-Purpose Processors and Real-Time
Multimedia - Extensions and Sub-words
Microcontrollers
Digital Signal Processors
DSP - Arithmetics
DSP - Program Development
DSP - Trends
Application-specific instruction set processors (ASIP)
Integrated Circuit
Phases of IC Design
Design Styles for ICs
Comparison of Design Styles
FPGA (field programmable gate arrays)
FPGA Design Steps
FPGA - Application Areas
System models
Dataflow Graph (DFG)
Control flow graph (CFG)
Sequencing Graphs




Abbildung 1: Implementation Styles

Architectures

See fig. 1

General-Purpose Processors

- Properties
 - high performance for a broad range of applications, not optimized for any particular application
 - high power consumption
- Design
 - highly optimized circuits
 - design times ¿ 100 person years
 - cost/device only cheap when fabricated in huge numbers
- Application areas
 - PCs
 - Smartphones

Reasons for High Performance

- Exploitation of parallelism
 - multiple scalar units (superscalar)
 - * Functional units: integer units, floating-point unit, load/store-unit
 - * Dynamic scheduling
 - * instruction compatibility

- * complex control unit
- deep instruction pipeline
 - * fetch | decode | read | execute | write back
 - * each scalar unit my have individual pipeline depth
 - * branch prediction
- Multi-level memory hierarchy
 - $-\uparrow \text{Speed} \Rightarrow \downarrow \text{Size} \Leftrightarrow \uparrow \text{Size} \Rightarrow \downarrow \text{Speed}$
 - Register < Cache < Main Memory

General-Purpose Processors and Real-Time

- Execution time of programs is not well predictable
 - Dynamic scheduling
 - Caching
 - Branch prediction
- Complex I/O and memory interface

Multimedia - Extensions and Sub-words

- Multimedia Applications
 - 8 / 16 Bit data types
 - many arithmetic operations
 - huge data sets \Rightarrow Huge I/O-bandwidth
 - high data parallelism
- Sub-word execution
 - split 32/64-bit registers and ALUs into smaller sub-units
 - instructions execute in parallel on these sub-units
 - compromise between usage of parallelism and available data paths
 - currently most often based on hand-written assembly routines
 - Depends on language with defined bit width per data type and diverse overflow semantics
 - Compiler needs to automatically detect sub-word parallelism

Microcontrollers

- \bullet For control-dominant applications
 - control flow dominant programs (many branches and jumps)
 - few arithmetic operations
 - low throughput requirements
 - multitasking
- Microcontrollers are optimized for
 - Bit- and logic-level operations
 - Registers often realized in RAM: context switch through pointer operation, therefore shortest interrupt latencies
 - integrated peripheral units (e.g. A/D, D/A, CAN, Timer)
- Systems with 4/8 bit processors
- Microcontrollers with high performance
 - 16 64 bit processors
 - Application areas
 - * Systems with high control-dominant parts and additional demand
 - * High throughput (telecommunication, automotive)
 - * Computational power (industrial control, signal processing)
 - * As a part of an SOC

Digital Signal Processors

- Signal processing applications
 - data-flow dominant
 - many arithmetic operations, less branches and jumps
 - high degree of parallelism
 - high throughput requirements
- DSPs are optimized for
 - parallel instruction processing (MAC fig. 2)
 - Harvard Architecture, simultaneous access of multiple operands
 - zero-overhead loops
 - special addressing modes (circular, bit-revers)




Abbildung 2: Multiply & accumulate

DSP - Arithmetics

- Number formats
 - Mantissa determines precision
 - Exponent determines dynamic range
- Fixed point
 - in case of equal mantissa length smaller (cheaper) and faster as floating-point
 - application design requires consideration of rounding and scaling problems
 - sufficient for many DSP applications
- Floating point
 - high dynamic range of numbers
 - easier application program development

DSP - Program Development

- Assembler, Complier
 - Many DSP features still only usable if code is written in assembly
 - Programming in $C \to \text{profiling} \to \text{time-critical parts}$ in assembly code
- Libraries
 - Programming in C, call of hand-written optimized functions
- Code generation
 - Usage of design environments for modeling, simulation and code generation
 - e.g. Synopsis

DSP - Trends

- Multi-DSP Systems
 - for applications requiring highest performance
 - interfaces available to connect multiple processors
 - Multi-Processor SoC (MPSoC)
- VLIW (Very long instruction word)
 - multiple functional units
 - Compiler detects parallelism and creates a program that schedules multiple instructions jointly
 - Only useful for applications with high degree of instruction parallelism
 - suffers often from low code density
 - compilation difficult

Application-specific instruction set processors (ASIP)

- Specialization
 - instruction set (Operant chaining)
 - functional units (pixel operations, $1/\operatorname{sqrt}(x)$)
 - memory architecture (parallel access onto multiple memory banks)
- Advantages
 - higher performance
 - lower cost
 - smaller code images
 - lower power consumption

Integrated Circuit


Phases of IC Design

- 1. Design
 - (a) Modeling
 - (b) Synthesis & Optimization
 - (c) Verification
- 2. Fabrication
 - (a) Masks
 - (b) Wafer
- 3. Testing

4. Packaging

- (a) Slicing
- (b) Packaging

Design Styles for ICs



- MPGA: mask-programmable gate array (beim Hersteller "programmiert")
 FPGA: field-programmable gate array (beim Anwender "programmiert")

Abbildung 3: Design Styles for ICs

Comparison of Design Styles

	Custom	Cell-based	MPGA	FPGA
Density	very high	high	high	medium-low
Performance	very high	high	high	medium-low
Design time	very long	short	short	very short
Manufacturing time	medium	medium	short	very short
Cost- low volume	very high	high	high	low
Cost- high volume	low	low	low	high

Abbildung 4: Comparison of Design Styles

FPGA (field programmable gate arrays)

- Logic blocks
- I/O-blocks
- \bullet Interconnect

FPGA Design Steps




Abbildung 5: FPGA design steps

FPGA - Application Areas

- Glue Logic
- Rapid Prototyping, Emulation
- Embedded Systems
 - $-\,$ when when processors are too slow or too power-inefficient and
 - * flexibility is a must
 - * the sale volumes are too low to afford ASIC
- Custom Computing
 - Goal: Combine flexibility of processors with efficient advantages of ASICs
 - e.g. Outsourcing a complex task from SW to HW

System models

Dataflow Graph (DFG)




Abbildung 6: Data Flow Graph

Control flow graph (CFG)

```
what_is_this {
    read (a,b);
    done = FALSE;
    repeat {
        if (a>b);
            a = a-b;
        elseif (b>a);
            b = b-a;
        else done = TRUE;
        } until done;
        write (a);
    }
}
```

Abbildung 7: Control Flow Graph

Sequencing Graphs

- Hierarchy of entities
 - entities modeling the data flow
 - hierarchy modeling the control flow
- ullet Special nodes

Start/End nodes: NOP
Branch nodes: BRANCH
Iteration nodes: LOOP
Module call nodes: CALL

• Attributes

- Nodes: computation times, costs

- Edges: conditions for branches, iterations




Abbildung 8: Sequencing Graph - Entity




Abbildung 9: Sequencing Graph - Branch




Abbildung 10: Sequencing Graph - Loop




Abbildung 11: Sequencing Graph - Call