SCHLENKER 36/10 - CABINET MOUNTING LAYOUT

BACKPLATE 1100 W x 1700 H mm
PRELIMINARY PROFILE / DUCT SET-OUT

PROFILE AND DUCT COORDINATES (mm)

ID	TYPE	X	Y	W/L	H	PURPOSE
VD-L	DUCT	40	40	60	1620	Left vertical wiring duct
VD-R	DUCT	1000	40	60	1620	Right vertical wiring duct
R1	DIN TS35	120	140	860	-	AC terminals / protection
HD-1	DUCT	100	260	900	60	Horizontal segregation
R2	DIN TS35	120	440	860	-	Power / Pilz / PLC / network
HD-2	DUCT	100	580	900	60	Horizontal segregation
R3	DIN TS35	120	730	860	-	ELV field terminals
HD-3	DUCT	100	840	900	60	Horizontal segregation
R4	DIN TS35	120	970	860	-	Safety / field terminals
HD-4	DUCT	100	1080	900	60	Horizontal segregation
VFD	ZONE	120	1200	500	360	4 x G120C; direct mount
R5	DIN TS35	650	1370	330	-	Protection / safety starters
HD-5	DUCT	100	1580	900	60	Bottom wiring duct

INSTALLATION NOTES

1. Coordinates use the top-left plate corner as X0/Y0.
2. Plate size supplied by operator: 1100 W x 1700 H mm.
3. DIN rails are proposed TS35; confirm rail depth before purchasing.
4. G120C units mount directly to the plate, not to DIN rail.
5. Maintain at least 80 mm above and below the reserved G120C zone.
6. Keep motor/400 VAC wiring segregated from ELV, safety and PROFINET.
7. Do not drill component mounting holes until exact order numbers and manufacturer drilling templates have been checked.
8. Confirm enclosure earth studs, gland plate and door hardware before cutting the two full-height vertical ducts.

CONSTRUCTION HOLD POINT

This drawing releases only the proposed DIN-rail and wiring-duct set-out. Component envelopes are planning zones. Verify each device order number, manufacturer clearance, terminal access and heat-loss calculation before drilling device holes or energising the cabinet.

Drawing basis: operator dimensions and supplied reference layout | Units: mm | Scale: graphical