



SCOPE OF WORKS

Exterior Wall Preparation & Painting

A · Surface preparation

1. High-pressure wash all plastered wall surfaces to remove dirt, dust, chalk and any loose or failing paint.
2. Chip out all badly damaged or hollow-sounding ("drummy") plaster.
3. Open up all cracks wider than 3 mm and rake them out, ready for re-plastering.
4. Re-plaster the prepared areas with a cement mixture containing:
 - Plaster sand
 - Cement
 - Plaster-key bonding agent (for adhesion to the existing surface)
 - Waterproofing cement additive
5. Float all newly plastered areas to match the existing plaster finish.
6. Seal all open gaps between the plaster and the window and door frames with a flexible acrylic sealant.

B · Priming

7. Apply one coat of solvent-based plaster primer to all newly plastered areas.
8. Apply one coat of solvent-based plaster primer to all flaky, powdery or chalky surfaces, to bind them for good topcoat adhesion.

C · Damp-related repairs (where present)

9. Find and repair the underlying cause of the damp first. This is essential — sealing over active damp will not solve the problem.
10. Remove all blistered or peeling paint where adhesion has failed due to damp.
11. Allow the affected wall to dry out naturally for as long as possible (ideally to a moisture level below 10%).
12. Re-plaster and float the affected areas to match the existing finish (plaster mixture as above).
13. Apply a damp-proofing sealer (e.g. Dampseal) to the newly plastered / affected areas.

D · Finishing coats

14. Apply two coats of the selected water-based topcoat (product of your choice).
15. Observe the drying and overcoating times stated on each product's Technical Data Sheet (TDS).

This scope of works is a general guide for a typical home; the exact steps for your walls depend on their condition. Plaster and crack repair materials are not included and are priced separately.