



SCOPE OF WORKS

Roof Preparation & Painting

Galvanised & metal (Chromadek) roofs

1. Clean and de-grease the complete roof surface with sugar soap or a suitable de-greaser.
2. Rinse all surfaces thoroughly with a high-pressure washer and clean water, and allow to dry.
3. Patch-prime all rust-affected areas with one coat of anti-rust metal primer (spot-treat the affected areas only).
4. **Important — new or bare Chromadek / metal:** the surface must first be overcoated with the correct primer, even where there is no rust or corrosion. Confirm the right primer with a paint supplier before you start.
5. Apply two coats of roof paint (product of your choice), following the drying and overcoating times on the product's Technical Data Sheet (TDS).

Tiled roofs

1. Clean and de-grease the complete roof surface with sugar soap or a suitable de-greaser.
2. Rinse all surfaces thoroughly with a high-pressure washer and clean water, and allow to dry.
3. Repair or replace the roof ridging and any cracked or broken tiles.
4. **Important — porous tiles:** very porous roof tiles need a primer coat first. Confirm with a paint supplier whether your tiles require priming.
5. Apply the roof paint at a spreading rate of about **2–3 m² per litre** (tiles are porous and drink a lot of paint), following the drying and overcoating times on the product's TDS.

This scope of works is a general guide for a typical home; the exact steps depend on your roof. Rust treatment, ridging and tile repairs are not included in these prices and are quoted separately.