



SCOPE OF WORKS

Interior Walls & Ceilings

Interior walls

- Make sure the walls are clean and dust-free.
- Repair and prepare the interior plaster work.
- Apply Dampseal to any damp-affected areas.
- Apply acrylic silicone around all window and door frames, and wherever else applicable.
- Open up wall cracks and fill them with a crack-filler of your choice.
- Sand the crack-filler with 80-grit sandpaper to create a finish that matches the plastered wall.
- Apply two coats of interior paint of your choice — see the Technical Data Sheet for drying times.

Interior ceilings

- Make sure the ceilings are clean and dust-free.
- Apply paintable acrylic to all cornice gaps.
- **Important:** if there are brown water stains from leaks, apply a universal undercoat to those areas first.
- Fill any nail-head gaps with a crack-filler of your choice.
- Sand the crack-filler with 80-grit sandpaper to match the current ceiling finish.
- Apply one coat of interior ceiling paint of your choice.

This scope of works is a general guide for a typical home; the exact steps depend on the condition of your walls and ceilings. Plaster and crack repair materials are not included and are priced separately.