



SCOPE OF WORKS

Exterior Wall Preparation & Painting

A · Surface preparation

- High-pressure wash all plastered wall surfaces to remove dirt, dust, chalk and any loose or failing paint.
- Chip out all badly damaged or hollow-sounding ("drummy") plaster.
- Open up all cracks wider than 3 mm and rake them out, ready for re-plastering.
- Re-plaster the prepared areas with a cement mixture containing:
 - Plaster sand
 - Cement
 - Plaster-key bonding agent (for adhesion to the existing surface)
 - Waterproofing cement additive
- Float all newly plastered areas to match the existing plaster finish.
- Seal all open gaps between the plaster and the window and door frames with a flexible acrylic sealant.

B · Priming

- Apply one coat of solvent-based plaster primer to all newly plastered areas.
- Apply one coat of solvent-based plaster primer to all flaky, powdery or chalky surfaces, to bind them for good topcoat adhesion.

C · Damp-related repairs (where present)

- Find and repair the underlying cause of the damp first. This is essential — sealing over active damp will not solve the problem.
- Remove all blistered or peeling paint where adhesion has failed due to damp.
- Allow the affected wall to dry out naturally for as long as possible (ideally to a moisture level below 10%).
- Re-plaster and float the affected areas to match the existing finish (plaster mixture as above).
- Apply a damp-proofing sealer (e.g. Dampseal) to the newly plastered / affected areas.

D · Final coatings

- Apply two full coats of your chosen topcoat — product and colour of your choice.
- Allow a minimum of 4 hours drying time between coats.
- See the product's Technical Data Sheet for more information.

This scope of works is a general guide for a typical home; the exact steps for your walls depend on their condition. Plaster and crack repair materials are not included and are priced separately.