



SCOPE OF WORKS

Roof Preparation & Painting

Galvanised & metal (Chromadek) roofs

- Clean and de-grease the complete roof surface with sugar soap or a suitable de-greaser.
- Rinse all surfaces thoroughly with a high-pressure washer and clean water, and allow to dry.
- Patch-prime all rust-affected areas with one coat of anti-rust metal primer (spot-treat the affected areas only).
- **Important — new or bare Chromadek / metal:** the surface must first be overcoated with the correct primer, even where there is no rust or corrosion. Confirm the right primer with a paint supplier before you start.
- Apply two coats of roof paint (product of your choice), following the drying and overcoating times on the product's Technical Data Sheet (TDS).

Tiled roofs

- Clean and de-grease the complete roof surface with sugar soap or a suitable de-greaser.
- Rinse all surfaces thoroughly with a high-pressure washer and clean water, and allow to dry.
- Repair or replace the roof ridging and any cracked or broken tiles.
- **Important — porous tiles:** very porous roof tiles need a primer coat first. Confirm with a paint supplier whether your tiles require priming.
- Apply the roof paint at a spreading rate of about **2–3 m² per litre** (tiles are porous and drink a lot of paint), following the drying and overcoating times on the product's TDS.

This scope of works is a general guide for a typical home; the exact steps depend on your roof. Rust treatment, ridging and tile repairs are not included in these prices and are quoted separately.