

Linux3.0.8平台搭建移植文档——change logo

如果要让系统启动过程中,除了能看到bootlogo小企鹅,还希望能看到自己的bootlogo,只需图片转换工具和部分源码的修改即可实现

1. 图片转换

安装windows 版本(gimp-2.6.9-i686-setup.exe), gimp号称linux下的 photoshop, 软件位于"\\172.20.220.24\软件共享\\00_嵌入式课程所需软件\\6_平台\\\11nux_resource\\2.6.35.7_tools"目录下

打开任何格式的一张将要转换的图片(图片分辨率小于等于800x480)

选择:图像--->模式--->索引颜色转换--->

最大颜色数量设置为(224)--->转换

或:图像--->缩放图像--->设置想要的图像大小

最后:文件--->另存为--->选择ppm格式--->保存格式为 ASCII

最后将转换好的图片文件拷贝到 drivers\video\logo目录下,比如: logo_sunplusedu_big_clut224.ppm

2. 修改Kconfig文件

#vi drivers/video/logo/Kconfig

.

config LOGO_LINUX_CLUT224 bool "Standard 224-color Linux logo" default y



```
凌阳教育——全国唯一原厂嵌入式培训
      config LOGO SUNPLUSEDU BIG CLUT224
              bool "Standard 224-color sunplusedu big logo"
              default v
       . . . . . .
3. 修改Makefile文件
#vi drivers/video/logo/Makefile
obj-$(CONFIG_LOGO_LINUX_CLUT224) += logo_linux_clut224.o
obj-$(CONFIG_LOGO_SUNPLUSEDU_BIG_CLUT224) += logo_sunplusedu_big_clut224.o
```

4. 修改开机logo图片数据管理文件logo.c

#vi drivers/video/logo/logo.c

```
#ifdef CONFIG LOGO LINUX CLUT224
                  /* Generic Linux logo */
                  logo = &logo_linux_clut224;
#endif
#ifdef CONFIG LOGO SUNPLUSEDU BIG CLUT224
                 /* Generic Linux logo */
                 logo = &logo_sunplusedu_big_clut224;
#endif
. . . . . .
```

5. 添加头文件申明

```
#vi include/linux/linux_logo.h
extern const struct linux logo logo linux clut224;
extern const struct linux_logo logo_sunplusedu_big_clut224;
```

6. 修改内核配置选项

```
Device Drivers --->
  Graphics support --->
      [*] Bootup logo --->
        --- Bootup logo
                 Standard black and white Linux logo
```



凌阳教育——全国唯一原厂嵌入式培训

www. sunplusedu. com

- [] Standard 16-color Linux logo
- [] Standard 224-color Linux logo
- [*] Standard 224-color sunplusedu big logo (NEW)

注意:

主要是前后名字一定要保持一致,不要写错,否则编译不通过