

MSM8960 Thermal Mitigation Algorithm

80-N8633-1 C

November 21, 2012

Submit technical questions at: https://support.cdmatech.com/

Confidential and Proprietary – Qualcomm Technologies, Inc.

Restricted Distribution: Not to be distributed to anyone who is not an employee of either Qualcomm or its subsidiaries without the express approval of Qualcomm's Configuration Management.

Not to be used, copied, reproduced, or modified in whole or in part, nor its contents revealed in any manner to others without the express written permission of Qualcomm Technologies, Inc.

Qualcomm reserves the right to make changes to the product(s) or information contained herein without notice. No liability is assumed for any damages arising directly or indirectly by their use or application. The information provided in this document is provided on an "as is" basis.

This document contains confidential and proprietary information and must be shredded when discarded.

Qualcomm is a trademark of QUALCOMM Incorporated, registered in the United States and other countries. All QUALCOMM Incorporated trademarks are used with permission. Other product and brand names may be trademarks or registered trademarks of their respective owners.

This technical data may be subject to U.S. and international export, re-export, or transfer ("export") laws. Diversion contrary to U.S. and international law is strictly prohibited.

Qualcomm Technologies, Inc. 5775 Morehouse Drive San Diego, CA 92121 U.S.A.

© 2011-2012 Qualcomm Technologies, Inc. All rights reserved.

Contents

1 Ir	ntroduction	6
	1.1 Purpose	6
	1.2 Scope	
	1.3 Conventions	
	1.4 References	7
	1.5 Technical assistance.	
	1.6 Acronyms	
	urpose of Thermal Mitigation	•
2 P	urpose of Thermal Mitigation	8
	2.1 Overview of thermal issues	
	2.2 Thermal management physical design and layout techniques	
	2.3 Thermal management algorithm goals	
	2.4 Thermal management algorithm prerequisites	10
а Т	hermal Characterization	4.4
3 I		
	3.1 Calibration of a specific form factor (phone or dongle)	
	3.1.1 Purpose of thermal calibration	
	3.1.2 Variations requiring change in calibration	
	3.1.3 Calibration methods	12
4 T	hermal Software Architecture for Android	15
	4.1 Boot thermal mitigation	17
	4.2 KTM	
	4.3 ThermalD	
	4.4 Overall AP Thermal Management	
	4.5 Thermal sensors	
	4.5.1 TSENS	
	4.5.2 TSENS calibration	
	4.5.3 HKADC	
	4.6 TMD	21
	4.7 AP-side thermal mitigation configuration	
	4.7.1 Thermal zone definition	
	4.7.2 Configuration file requirements	
	4.7.3 Configuration file example	25
	4.7.3 Configuration file example	
		26
	4.7.4 Editing configuration file	26 26
	4.7.4 Editing configuration file	26 26
	4.7.4 Editing configuration file	26 26 26

28
28
31
31
32
32
32
37
37
37
38
3

Figures

Figure 3-1	Measuring the temperature profile	13	
Figure 4-1	LA thermal software architecture		
Figure 4-2	TSENS sensor locations	16	
Figure 4-3	Boot and kernel thermal mitigation	17	
Figure 4-4	Overall AP TM mechanism	19	
Figure 5-1	Uplink flow control	33	
	UL flow control		
Figure 5-3	UE states – Mitigation 1	35	
Figure 5-4	UE states – Mitigation 2	36	
Tables	e 5-4 UE states – Mitigation 2		
Table 1-1	Reference documents and standards		
Table 4-1	Thermal zone	21	
	Sensor names		
Table 4-3	Sensor actions and action information	23	
Table 4-4	Thermal mitigation feature set	27	

Revision history

Revision	Date	Description		
А	Dec 2011	Initial release		
В	Jan 2012	Updates for thermal daemon and configuration file		
С	Nov 2012	Numerous changes were made to this document; it should be read in its entirety.		



1 Introduction

NOTE: Numerous changes were made to this document. It should be read in its entirety.

1.1 Purpose

As Qualcomm Technologies, Inc. (QTI) chipsets continue to advance, with heightened capabilities, performance, and concurrency, there is a need to have a thermal management framework in place to deal with high-power dissipation use cases. The thermal issue manifests in cases where temperatures of devices approach or exceed Underwriters Laboratories (and other worldwide regulatory bodies), carrier, and customer requirements. The primary ways of dealing with the increased power requirements and associated heat is, first, efficient power management as described in [Q4] and [Q5], and second, mechanical designs that efficiently dissipate the heat created as described in [Q2] and [Q3]. In addition, QTI provides thermal mitigation algorithms to deal with those instances where the temperature exceeds the desired operating levels. The software-based thermal management algorithm reduces the thermal load on the system by throttling performance of various features.

This document describes the mechanisms necessary for customizing the thermal management algorithm on devices using supported QTI ICs. This document also includes a brief introduction to threshold selection using thermal characterization, and describes proper configuration of the algorithm.

1.2 Scope

10

12

13

14

15

16

17

18

19

20

21

22

23

24

This document is intended for all engineers who use MSM8960 chipsets.

1.3 Conventions

Function declarations, function names, type declarations, and code samples appear in a different font, e.g., #include.

Shading indicates content that has been added or changed in this revision of the document.

1.4 References

Reference documents are listed in Table 1-1. Reference documents that are no longer applicable are deleted from this table; therefore, reference numbers may not be sequential.

Table 1-1 Reference documents and standards

Ref.	Document					
Qualc	Qualcomm Technologies					
Q1	Application Note: Software Glossary for Customers	CL93-V3077-1				
Q2	Application Note: Thermal Design Considerations	80-VU794-5				
Q3	Application Note: Thermal Design Checklist	80-VU794-21				
Q4	Presentation: Resource Power Manager (RPM) Overview and Debug	80-VP169-1				
Q5	Presentation: MSM8x60/APQ8x60 Linux Power Management Debugging Guide	80-VR629-2				
Standards						
S1	Information Technology Equipment – Safety	IEC 60950-1:2005				
S2	Safety Specification	UL1905				

1.5 Technical assistance

For assistance or clarification on information in this document, submit a case to QTI at https://support.cdmatech.com/.

If you do not have access to the CDMATech Support Service website, register for access or send email to support.cdmatech@qti.qualcomm.com.

1.6 Acronyms

11

For definitions of terms and abbreviations, see [Q1].

2 Purpose of Thermal Mitigation

The thermal management algorithm provides a safety net, preventing the user device from causing damage to components or injury/discomfort to users. To accomplish this, one must lower power dissipation to keep the temperature at acceptable levels. The algorithm carefully monitors key temperatures within the device and can be configured for the implementation of appropriate responses at the modem and Apps Processor (AP) level for MSMTM products, achieved via multiple management steps.

Finding the appropriate thermal performance tradeoff requires thermal calibration of the device. This is achieved by executing different combinations of scenarios on the device.

With more capabilities (such as higher DL and UL data rates), more powerful APs, and thermally hostile environments, the use of a thermal management algorithm becomes increasingly important to avoid any damage to components/impact to users while achieving carrier thermal performance standards.

2.1 Overview of thermal issues

Present thermal analysis shows several potential causes driving the need to manage thermal:

- Market demand for feature-rich devices increases thermal susceptibility.
- Multimedia-centric features, e.g., SVLTE, SVDO, Mi-Fi, multicore GHz CPUs, graphics processors, and HD video increase thermal dissipation.
- Smaller/thinner designs lead to smaller PCBs, leading to concentrating power density.
- The Power Amplifier (PA) reaches maximum junction temperature in small form factor devices; this is dependent on component selection and maximum Tx power.
- Enabling higher UL data rates tends to cause higher Tx power, leading to more PA thermal dissipation.
- Touch temperature of the device's external casing may cause customer concerns; industry norms can limit smartphone external temperatures to 45°C (typically, ambient + 20°C) and external USB dongle temperatures to 75°C per [Q4] and [S1].
- Silicon-level temperature must stay below the specified limit (typically, for logic 125°C, and memory 85 to 105°C).
- Devices embedded in a Printed Circuit Board (PCB) (inside the computer housing) are exposed to higher ambient temperatures and restricted convective cooling forces, creating an even more severe thermal environment.

10

11

12

14

15

16

17

18

20

22

23

25

26

27

28

29

3.0

2.2 Thermal management physical design and layout techniques

To limit the impact of the thermal environment on the device, several techniques are suggested and recommended:

- Perform thermal analysis techniques during product design and development stages.
- Investigate device power and thermal budget from the analysis to locate projected hotspots.
- Implement efficient thermal management methods in the device mechanical structure.
- Ensure PAs reside in a location where heat is easily dissipated.
- Extensive use of thermal vias is necessary along with thermal paths within the PCB, allowing for lower thermal resistance of the device.
- Ensure no other large power dissipating components reside near or on the other side of the board from the PA and the MSM.
- Use of thermal dissipating techniques in the industrial design is highly recommended.

NOTE: See [Q2] and [Q3] for more information on thermal design.

2.3 Thermal management algorithm goals

Thermal management is targeted to:

- Protect components from exceeding thermal design limits; if the limits are exceeded, the Quality of Service (QoS) can be degraded and components can be damaged
- Ensure compliance with external case and touch temperature requirements from customers, carriers, and standard organizations (Underwriters Laboratories, PCI Express, and user expectations)
- Minimize the risk of power-limit constraints
- Manage the thermal risk and tradeoffs during concurrent operations
- Allow limited customer tailoring of temperature thresholds and methods for power reduction

10

11

12

13

14

15

17

20

21

2.2

2.3

2.4

2.4 Thermal management algorithm prerequisites

To properly manage the thermal scenarios of a device, the temperature must be measured from different thermally active points. It is done by sensors already present on the chipset and by placing thermistors at thermally active points, e.g., PA, PMIC, battery, etc. Currently, the thermal algorithm only works on PA thermistors reading.

The following lists preferred sensor locations. Each of these sensors can usually be read by the housekeeping ADC (HKADC) contained in QTI chipsets.

- Thermistor in close proximity to the PAs The PA is the primary component contributing to thermal increase in a device, easily dissipating well over 1 Watt in poor RF conditions.
- Thermistor or internal sensor in MSMs/MDMs The use of larger processors (AP or modem processor) tends to increase the heat generation of this component.
- Separate third-party component If an external heat-generating component, e.g., some designs where third-party AP is used, a thermistor should be thermally coupled or in close proximity.
- TCXO thermistor In extreme thermal environments, the TCXO tends to be most susceptible to heating, which can lead to dropped calls and poor performance. Sensing this condition helps determine when to invoke the thermal algorithm.
- Other locations, e.g., battery, PMIC, etc.

QTI recommends placing thermistors near thermally active devices.

10

11

12

13

14

15

17

18

3 Thermal Characterization

To properly evaluate thermal management against user-perceived QoS, the device needs to be calibrated thermally to utilize the management algorithm. Understanding the relationship between the internal temperature sensors and the actual temperatures of the components and external surfaces greatly assists in proper configuration of the device.

3.1 Calibration of a specific form factor (phone or dongle)

Every form factor and hardware design iteration must have thermal testing performed for understanding of heating profiles, e.g., layout, size, and PCB characteristics, all of which impact thermal loading.

3.1.1 Purpose of thermal calibration

Characterizing the thermal behavior of the device:

- Calibrates the external thermistors with the components monitored; this helps establish the
 correlation of the thermistor temperature with the actual component of concern. This is done
 by characterizing the ADC reading and making changes in software as needed.
- Calibrates how measurable internal temperatures of a device map to external temperatures exposed to the customer; external temperatures are not measurable in the real customer device, therefore, understanding the equilibrium and transient thermal loads and how they impact the internal sensors and external temperature is important if external temperatures are a concern.
- Provides use cases and their thermal impact on components and customers; various concurrent scenarios may thermally load the device differently, and understanding the hotspots for each may be important in configuring the algorithm.
- Provides information on the transient nature of the device (thermal time constant); measuring the thermal time constant provides the required time to engage the thermal management algorithm. Once engaged, it determines how long the algorithm takes to stabilize and/or cool the device.

3.1.2 Variations requiring change in calibration

Thermal testing and modeling suggests a new board or new form factor requires recalibrating the thermal characteristics and tuning the algorithm. Changes in the placement of components, changes in the location of temperature sensors, and especially changes in form factor dimensions all change the thermal characteristics.

10

11

12

13

14

15

16

17

19

20

21

2.2

23

24

2.7

28

29

30

3.1.3 Calibration methods

3.1.3.1 Full commercial software performance execution

The use of final software to perform peak performance on both the modem and AP is the preferred method for thermally calibrating the device. Running benchmarks or using Factory Test mode can provide some utility, but the concurrencies experienced and the power dissipation levels experienced in the components are very different between real-world use cases and test modes.

3.1.3.2 Identifying high power dissipation thermal use case scenarios

Use cases producing the maximum thermal effects, which are needed to activate the thermal management algorithm, involve multiple sensor points in various components. This implies several of the following scenarios.

Modem side

10

11

12

13

14 15

16

17

18

19

20

21

2.2

- RF conditions Poor RF link in a stationary situation, which causes high Tx power
- A scenario with significant UL data throughput drives Tx power higher, with larger data
 - High DL data rates in conjunction with applications such as video

AP side

- GHz CPUs with multiple cores
- Graphics processors
- HD video
- Concurrency
- Camera operations
- WLAN use 23

These scenarios and concurrent operation of the scenarios tend to produce thermal effects requiring thermal management. Measurement of the temperature profile over several thermal time constants for each scenario, as shown in Figure 3-1, determines if:

- Steady state temperature will exceed acceptable limits of any component, or the external surface
- Components influencing the thermal response
- Steady state temperature requires a thermal response of:
 - □ Normal Normal operating region where power reduction is not needed
 - □ Mitigation 1 Operating region where first set of mitigation steps are performed; this can be reducing the power by using flow control if desired on the modem side, and reducing the CPU clock on the apps side
 - □ Mitigation 2 Operating region where second step of mitigation steps are performed; this can be reducing the power further by using Tx backoff as desired on the modem side or reducing the CPU clock further on the apps side.
 - □ Emergency Operating region where damage to components/users is imminent and hence drastic steps such as tearing down the call are taken




Figure 3-1 Measuring the temperature profile

10

11

12

13

14

15

17

3.1.3.3 External heater use

10

11

12

13

14

15

16

17

If final commercial software is not available, thermal characterization of the form factor is possible by placing small patch heaters inside the device. Thermal loads of each patch heater should be representative of each component's power dissipation for each thermal scenario identified.

NOTE: Lab scenarios present several factors tending to over-represent the thermal response:

- Long durations of maximum Tx power are unlikely due to a variety of fading and coverage conditions on real networks.
- 100% UL data duty-cycle is unlikely due to nuances of the network, scheduling, and data packet readiness.
- Long durations of full DL bandwidth to a single user are unlikely due to the needs of the network to share bandwidth among many users.

The thermal realities experienced in the field tend to be much less severe than laboratory thermal conditions. While not limiting the potential thermal liability, real network conditions temper the plausible customer impact as witnessed during internal testing. Internal device temperatures in small form factors reach 85°C in the laboratory environment and seldom exceed 60°C in the field across many scenarios.

4 Thermal Software Architecture for Android

Thermal management software, as shown in Figure 4-1, consists of three key components, the thermal daemon, sensor inputs, and thermal management devices. In addition, there are algorithms for boot and kernel initialization to manage thermal performance.




Figure 4-1 LA thermal software architecture

WLAN

Kernel PMIC

CoreBSP HW Engines
CoreBSP Thermal

MM Video/Camera
Modem W/C2K/LTE/RF

The thermal daemon, a super user process running in Linux AndroidTM user space, is the central control for thermal software. Sensor inputs for temperature readings come from two sources. Temperature sensors (TSENS) are embedded in five locations in the MSM, as shown in Figure 4-2. The second source is the HKADC in the PM8921 connected to the MSM8960, which has one PA thermistor connected on analog inputs. Thermal management devices are software components listening to the thermal daemon. The thermal daemon sends events to management devices to restrict performance to a predetermined level during times of high thermal load on the system.




Figure 4-2 TSENS sensor locations

4.1 Boot thermal mitigation

10

11

13

14

15 16 Boot thermal mitigation ensures the device does not exceed temperature limits by adding a short delay if temperature is high prior to powering on high-power CPUs and initializing DDR. The Sensor 9 temperature is checked against a threshold set in the boot loader. If the temperature is above the threshold, a short delay occurs. After the delay the temperature is checked again. This repeats until either the maximum number of checks occurs or the temperature reduces below the threshold, as can be seen in Figure 4-3. The threshold, max number of check, and delay time are all configured in boot header files. Defaults for the threshold are set at 150°C, effectively disabling this algorithm. However, some thermal designs may require this aggressive management technique to operate in some extreme environmental conditions. To change the defaults, just add these defines to the boot builds file with the desired values:

```
#define MAX_TEMP_CHK_ITER 40
#define MAX_WAIT_TIME_MICROSEC 250000
#define BOOT_TEMP_CHECK_UPPER_THRESHOLD_DEGC 150
```




Figure 4-3 Boot and kernel thermal mitigation

17

4.2 KTM

The Kernel Thermal Monitor (KTM) provides thermal management during kernel initialization, prior to initialization of the main thermal management algorithm which requires services such as the file system to be operational. The KTM compares Sensor 0 to a preconfigured threshold every second. If the temperature exceeds the threshold, the performance level of the CPU cluster is reduced to a preconfigured operating point until the temperature reduces below the threshold. Once the thermal daemon process starts, a signal is sent to the KTM to stop checking the temperature.

4.3 ThermalD

10

11

12

13

14

15

16

17

18

19

2.0

21

22

23

The Thermal Daemon (ThermalD) user space process performs two main functions, monitoring temperature profile and controlling management devices.

Monitoring of the temperature profile is done by actions triggered at configurable temperature thresholds. On initialization, the ThermalD reads a configuration file containing all of the sensor and threshold data. If a temperature threshold is crossed, the ThermalD acts by sending events to management devices.

The interface to management devices, in general terms, is a management level. Typically, four levels are configured for any one of the devices. Level 0 is normal operation, Level 1 is the first level of management, etc.

In addition to the thermal management setup through the configuration file, the core control algorithm is hardcoded to ensure thermal protection. The core control algorithm monitors the temperature of each CPU core. If the temperature exceeds 115°C, the core is taken offline through the hotplug mechanism in Linux. Once the core temperature reduces below 95°C, the core control algorithm allows the core to come back online if required.

4.4 Overall AP Thermal Management

Three distinct AP thermal management schemes described in Section 4.1 through 4.3 are currently provided. After passing Boot Thermal Mitigation (BTM), boot loaders run with a single core at a speed of 918 MHz. This operating point is thermally safe in a typical mechanical design. When the Linux kernel initializes, both cores are started at maximum frequency. However, KTM does not start until a few services are initialized in the kernel. Consequently, there are a few seconds in which no thermal protection is operating while running the system at maximum CPU load.

In general this does not result in a thermal problem, but at extreme ambient temperatures in challenging mechanical designs this may not be sustainable over multiple back-to-back reboot cycles. In these rare cases, reduced initial CPU frequency or number of initial CPU cores used may be required to ensure thermal stability.

The KTM will operate until the user space thermal daemon is initialized. Overall timeline is depicted in Figure 4-4.




Figure 4-4 Overall AP TM mechanism

10

12

13

14

15

4.5 Thermal sensors

There are two sources for temperature data on the MSM8960 configuration, TSENS and HKADC reading from external thermistors. TSENS is a hardware block inside the MSM8960 with 10 temperature sensors connected. HKADC is a hardware block inside the PM8921 providing access to read analog inputs.

4.5.1 TSENS

2

10

11

12

13

14

15

18

19

20

21

2.2

23

24

28

TSENS hardware in the MSM8960 is controlled by a software driver running in Linux Android kernel space. No other processors access the TSENS hardware. There are 5 sensors, one main and 4 remote, which are monitored (see Figure 4-1). Each of the sensors inside the MSM8960 die is calibrated during chip fabrication. Upon initialization, the driver configures the TSENS hardware based on inputs from ThermalD and other self-contained data (such as calibration data). If calibration data is not available, the TSENS driver returns an error. The hardware is configured to continuously poll any sensors enabled at a programmable rate.

4.5.2 TSENS calibration

The calibration procedure writes an offset value into the QFPROM (fuse blow) for each sensor corresponding to the raw ADC reading at the ambient temperature at the time of calibration (typically 30°C). Additionally, the driver contains slopes for each of the sensors based on test data across many parts. The parameters are used by the driver to enable reporting of temperatures from each sensor in °C within the following accuracy limit of TSENS reading:

- 99.5% devices at 60°C [-3.7°C, +4°C]
- 99.5% devices at 90°C [-4.47°C, +4.9°C]

4.5.3 HKADC

The HKADC is a block in the PM8921 used to read the PMIC analog inputs. Some of the analog inputs are connected to thermistors providing temperature readings at hotspot areas outside of the MSM8960. On the MSM8960 reference design:

- One 99.5% device at $60^{\circ}\text{C} [-3.7^{\circ}\text{C}, +4^{\circ}\text{C}]$
- 99.5% devices at 90°C [-4.47°C, +4.9°C]

PA-based thermistors are connected to the PM8921. The readings from these thermistors are sent to the thermal algorithm through the QMI interface.

4.6 TMD

10

11

12

13

14

15

Thermal Management Devices (TMD) are software entities used to reduce the overall power consumption of a hardware block within the system, thereby reducing the thermal load. TMDs supported in the MSM8960 design are listed as part of the actions in Table 4-3.

4.7 AP-side thermal mitigation configuration

The thermal configuration file sets the operational parameters of the thermal management software. Each section, referred to as a thermal zone definition, is associated with one temperature sensor. Prior to the first thermal zone definition, the configuration file contains one line for the default sampling rate. The default is applied to any of the sensors without explicit sampling rates set in their thermal zone definition. Additionally, before the default sampling rate, inserting the word debug will enable verbose debug output from ThermalD.

4.7.1 Thermal zone definition

The thermal zone definition lists the configuration for one thermal zone consisting of six lines as shown in Table 4-1.

Table 4-1 Thermal zone

Field name	Values	Units	Notes
temp sensor name	See Table 4-2	0.0	U.
sampling	1000 to 65535	ms	
thresholds	-273 to 273	°C	Threshold to activate
thresholds_clr	-273 to 273	°C	Threshold to clear
actions	See Table 4-3		Action to act upon at thresholds; multiple entries allowed are separated by + with no spaces; this should be same for all threshold levels
action_info	See Table 4-3		Information used by action; multiple entries allowed are separated by + with no spaces

Temp sensor name listed in Table 4-2 corresponds to sensors located on the die shown in Figure 4-2.

Sampling is the rate at which the ThermalD will check the temperature against configured thresholds.

The final four fields, thresholds, thresholds_clr, actions, and actions_info, create a threshold group. There may be multiple threshold groups listed in each zone. Each threshold group defines a threshold to activate, a threshold_clr to deactivate, actions, and action_info associated with each action. Also, in each threshold group, multiple actions can be taken at the defined threshold. The entries must be separated by '+' with no spaces between the entries. Each action listed must also have a corresponding action_info separated by '+' with no spaces between the entries. Actions correspond to the available mitigation devices supported by thermal management as listed in Table 4-3. action_info is the level to be sent to the mitigation device listed in the associated action. The file is read during the ThermalD initialization to configure the thermal management system.

Table 4-2 Sensor names

11

12

13

14

Name	Notes		
tsens_tz_sensor0	Must always have at least one mitigation step enabled		
tsens_tz_sensor1	A.M.		
tsens_tz_sensor2	20 11		
tsens_tz_sensor3	700		
tsens_tz_sensor4	27 110		
pa_therm0	GSM/UMTS/LTE PA		
pa_therm1	LTE PA – Applicable to only specific RF platforms		

Table 4-3 Sensor actions and action information

Action	Action info	Notes
none	Set to 0; not used but needed for parser to work properly	This mitigation step is disabled. If a threshold is crossed, no action is taken.
report	Set to 0; not used but needed for parser to work properly	The threshold crossing information is sent across an abstract local socket THERMALD_UI in a new line-separated string format. Parameters are sent in the following order: sensorname – Name of sensor reporting temperature – Current temperature current_threshold_level – Current threshold level triggered or cleared is_trigger – TRUE on level trigger, FALSE on level clearing
сри	Sets the max allowable frequency for Krait CPUs	0 to 2000000 kHz
gpu	Sets the max allowable frequency for GPU	This information will be provided in a future revision of this document.
wlan	Sends a mitigation request to WLAN to reduce allowable maximum Tx power	Levels 0 to 4 0 - No mitigation 1 - Disable aggregation 2 - Tx power backoff level 1 3 - Tx power backoff level 2 4 - IMPS
lcd	Sets the backlight intensity; will not adjust the max value over the currently configured brightness set by the user	0 to 255 0 – Backlight off 255 – Maximum brightness
modem	Sends mitigation request to the modem on standalone design	Levels 0 to 3 O – No mitigation 1 – Data throttling 2 – Tx power backoff 3 – Call drop/Maximum mitigation/Only E911 calls allowed
battery	Sends mitigation request to battery charging	Levels 0 to 3 0 – No mitigation 3 – Maximum mitigation
shutdown	Sends a shutdown request to the kernel with a delay to power down the phone	Delay in milliseconds

4.7.2 Configuration file requirements

The configuration file must contain a thermal zone definition for tsens_tz_sensor0 as the first entry with the lowest of all temperature thresholds. The first threshold group in the tsens_tz_sensor0 thermal zone definition is used to set the TSENS threshold. Any other threshold groups in the tsens_tz_sensor0 thermal zone definition or threshold groups in any other thermal zone definition are only active after tsens_tz_sensor0 kicks in. For correct operation, the first threshold group in the tsens_tz_sensor0 thermal zone definition must have an activation threshold set lower than any other polling threshold in any other threshold group. This allows ThermalD to remain asleep until the first threshold is crossed, at which point ThermalD begins polling at a rate defined by the configuration file. Polling continues until all thresholds have cleared.

Also note that there should be a return character in the end of the thermald.conf file, i.e., entered at the last line of the thermald.conf file.

4.7.2.1 Action field requirements

10

11

12

13

14

15

16

17

18

- The actions field lists the mitigation devices acted upon at each threshold. The parser for the configuration file is not complex, therefore, these fields are not completely free form. The rules for actions and actions_info within a threshold group must be separated by only the '+' character and no spaces.
- Actions must be explicitly stated for each threshold. Device settings are not implicitly reset to that of previous thresholds except upon clearing the lowest threshold.
- Each action must have a corresponding action_info.
- Action_info must also be separated by only the '+' character and no spaces.

4.7.3 Configuration file example

The example configuration file below turns on verbose debug output (line 1) and default polling rate to 5 sec (line 2).

Next, the first thermal zone definition is named tsens_tz_sensor0. The thermal zone definition sets a sampling rate for this sensor at 1 sec, which overrides the default 5 sec rate. The first threshold group in the tsens_tz_sensor0 thermal zone definition configures an activation threshold at 65°C, an action for the CPU to mitigate to a maximum frequency of 756 MHz, a second action for the LCD to mitigate to brightness level 200 out of 255; the threshold will clear at 60°C. The second threshold group configures an activation threshold at 75°C, an action for the CPU to mitigate to a max frequency of 540 MHz, a second action for the LCD to mitigate to brightness level 100 out of 255; the threshold will clear at 70°C. CPU and LCD management devices are reset to their default setting upon clearing the lowest threshold at 60°C.

The second thermal zone definition is named pa_therm0. The thermal zone definition sets a sampling rate for this sensor at 1 sec, which overrides the default 5 sec rate. The first threshold group in the pa_therm0 thermal zone definition configures an activation threshold at 70°C, an action for the modem to mitigate to level 1; the threshold will clear at 65°C. The second threshold group configures an activation threshold at 80°C, an action for the modem to mitigate to level 2; the threshold will clear at 75°C. Modem management is reset to normal setting upon clearing the lowest threshold at 65°C.

19 20 21

2.2

2.3

24

25

26

27

28

30

31

32

33

34

35

10

11

12

14

15

16

```
debug
sampling
                  5000
[tsens_tz_sensor0]
   sampling
                      1000
   thresholds
                      65
   thresholds_clr
                      60
   actions
                     cpu+lcd
                                  cpu+lcd
   action info
                      756000+200 540000+100
[pa_therm0]
   sampling
                      1000
   thresholds
                      70
                                  80
                                  75
   thresholds_clr
                      65
   actions
                      modem
                               modem
   action info
                                   2
```

4.7.4 Editing configuration file

To edit the configuration file, execute the following commands while connected to the device through a USB.

```
adb pull /etc/thermald.conf
adb remount
<edit>
adb push thermald.conf /etc/
```

4.7.5 ThermalD logging

10

11

12 13

18 19

21

22

2.4

25

26

28

31

ThermalD has minimal logging unless it is started in Debug mode or a debug flag is in the first line of the configuration file. Since ThermalD runs at startup, to turn on full logging, the daemon needs to be stopped and restarted.

```
adb shell stop thermald
adb shell
thermald --debug &
```

The following command will output the ThermalD log information in the command window.

```
adb logcat -s ThermalDaemon
```

Timestamps can also be output by adding the –v time option.

adb logcat -v time -s ThermalDaemon

4.8 Modem thermal mitigation

Modem thermal management consists of three distinct mitigation levels:

- Uplink data throughput while keeping the original power class reduces the requirement of higher Tx power to close the reverse link.
- Downlink data throughput eases the power/MIPS requirements of the modem processor.
- Maximum Tx power limiting reduces the PA Tx power similar to SAR reduction.

Limited service mode restricts all data calls.

4.9 Modem thermal mitigation feature set

Table 4-4 lists the thermal mitigation feature set.

Table 4-4 Thermal mitigation feature set

Feature	LTE	WCDMA/ HSPA	DO	1X	Notes
Thermal Emergency state; call teardown supervision and E911 allowance	Supported	Supported	Supported	Supported	
UL data throttling	Supported	Supported	Supported	Supported	
DL data throttling	NA	Supported	Supported	Supported	
Interference cancellation disabling	NA	NA	NA	NA	
Rx diversity disabling	NA	NA	NA	NA	
Tx power scaling – Duty-cycle backoff	Supported	Supported	Supported	Supported	Primarily used when data throttling is not effective or possible at edge of cell

4.10 Modem-side thermal mitigation configuration

For thermal mitigation to work on the modem, the following prerequisites must be present:

- A test SIM, i.e., SIM with MCC in range of 1 to 12, should *not* be used. A test SIM will enable a GCF test flag, resulting in disabling thermal mitigation.
- Data throttling requires the network/testbox to support dynamic scheduling.

4.10.1 Common NV settings

10

11

12

13

15

16

18

19

20

25

2.7

The following sections describe NV items required to be set that are applicable to all radio technologies.

4.10.1.1 NV 947 - GPRS-enabled Anite GCF

This NV is required to enable/disable the GCF Testing mode in the device. The NV is set as NV 947: <GCF_flag>.

If GCF Testing mode is enabled, i.e., the GCF flag is set, the thermal mitigation algorithm is disabled. Therefore, it is required to disable the GCF flag by setting NV 947: 0.

Also, note that a test SIM, i.e., SIM with MCC in range of 1 to 12, should *not* be used. This kind of a SIM will enable a GCF test flag automatically, and hence thermal mitigation will be disabled.

4.10.1.2 NV 6241 – Thermal monitor timers

NV 6241: <Basic Loop>, <Mitigation Loop>, <t_down>,<misc timer>, <pa change backoff> It is recommended to set NV 6241: 5000, 5000, 5000, 5000, 1.

4.10.2 LTE technology-specific NVs/EFS

4.10.2.1 NV 65675 – CFM monitor enable masks

- By default (if the NV item is not written), all monitors including the thermal monitor are enabled (one still needs to configure the DEM thermal threshold, as described in Section 4.1).
- To disable the thermal mitigation for LTE, set the 2 LSBs of the mask to 0, i.e., 0xFFFFFFC.
- To revert to the default mask, remove the EFS file /nv/item_files/modem/utils/cfm/cfm_monitor_enabled_masks using QPSTTM/EFS Explorer.
- The only supported values are 0xFFFFFFC (disable LTE) and 0xFFFFFFFF (enable all monitors in all modes). All other values are not supported and may cause unknown behavior.

4.10.2.2 NV 65611 – LTE FC MAC BSR target data rates

By default (if the NV item is not written), the default target MAC-level data rate configuration for UL data throttling is as follows:

```
Uint8 num_state = 10;
                   Uint8 default_state = 5;
                   Uint16 reserved = 0; /* keep this set to 0 */
                   /* number of bytes per TTI (ms) */
                   Uint32 target_rate[0] = 6250 (50 \text{ Mbps})
                   Uint32 target_rate[1] = 5000 (40 \text{ Mbps})
                   Uint32 target_rate[2] = 3125 (25 Mbps)
10
                   Uint32 target rate[3] = 1250 (10 \text{ Mbps})
11
                   Uint32 target_rate[4] = 625 (5 Mbps)
12
                   Uint32 target_rate[5] = 125 (1 \text{ Mbps})
13
                   Uint32 target_rate[6] = 63 (500 \text{ kbps})
14
                   Uint32 target_rate[7] = 13 (100 \text{ kbps})
15
                   Uint32 target rate[8] = 6 (50 \text{ kbps})
16
                   Uint32 target rate[9] = 1 (10 kbps)
```

To change the data rate configuration, write to num state, default state, target rate[0]... target_rate[num_state-1]. The data rate is expressed in number of bytes per millisecond.

To revert to the default configuration, remove the file /nv/item_files/modem/lte/common/ lte_fc_macul_target_rates using QPST/EFS Explorer.

For flow control target data rates (NV 65611), the default value is 10 states, as described above. The default rate is currently set to 1 Mbps. The minimum rate can be set to a lower value, but the recommendation is to set it to a value that would meet the requirement for control channels and delay-sensitive applications. Setting this to 0 is not recommended, as it would shut down the uplink and could cause the call to eventually drop. The default state should be chosen carefully to guarantee a timely response that reduces the temperature. By setting the default state to 5 in the default configuration, the data rate is initially reduced to 1 Mbps after uplink flow control has been triggered.

17

18

19

2.0

21

22

23

25

26

2.7

28

4.10.2.3 NV 65676 – CFM state remaining time

- By default (if the NV item is not written), the thermal step timer is set to 15 sec.
- The thermal step timer can be changed from 0 to 255 sec by writing to the NV item.
- To revert to the default step timer, remove the EFS file /nv/item_files/modem/utils/cfm/cfm_thermal_step_timer_in_sec using QPST/EFS Explorer.

This timer controls how fast the uplink data rate is increased or decreased (depending on the state). It is currently set to 15 sec based on the observations from test results. This setting should correspond to the time it takes for the temperature sensors to converge to a new temperature value.

4.10.2.4 EFS file for Tx backoff

10

11

12

15

16

17

18

19

20

21

22

2.3

2.4

25

For LTE, when the threshold for Tx backoff is crossed (NV 6242), the PA power is adjusted per the parameters configured in the EFS file (tx_power_backoff located in /nv/item_files/modem/lte/ML1/).

- P_backoff Initial value for Tx power backoff in dB
 - □ Recommended initial value 5 dB
 - \Box At each step n, the value of power backoff is $n \times P_backoff$
 - □ n is increased by one upon each expiry of step_timer
- T_on The length of time when the UE removes the limit on MTPL
 - □ Recommended initial value 50 ms
- T off The length of time when the UE reduces MTPL
 - □ Recommended initial value 50 ms
 - Step timer Time spent in each step (see P backoff)
 - □ Recommended initial value 15 sec
- P min The minimum value for MTPL
- □ Recommended initial value 10 dBm

```
Here is the structure of the EFS file in order:
             /* Initial backoff */
            uint16 p_backoff;
             /* Maximum value of the backoff */
            uint16  p_backoff_max;
             /* Time for non-backed-off value of power */
            uint16 t_on;
             /* Time for backed off Value of power */
            uint16 t_off;
10
             /* Timer for each step of the backoff */
11
            uint32 step_timer;
12
13
            As an example, the following hex content of the file is:
14
15
            05000C00 32003200 983A0000
17
             ■ P_backoff – 5 dB (0500 for 5 dB)
18
               Max_backoff – 12 dBm (0C00 for 13 dB)
19
               T_on - 50 \text{ ms} (3200 \text{ for } 50 \text{ ms})
20
             - T_off – 50 ms (3200 for 50 ms)
21
             ■ Step_timer – 15 sec (983A for 15 sec)
22
```

4.10.3 WCDMA/HSPA technology-specific NVs/EFS

None

4.10.4 1X/DO technology-specific NVs/EFS

None

23

24

25

5 Modem Thermal Mitigation Details

NOTE: Test results are appended as an example of how the mitigation algorithm can be used, and references for results are given. However, the behavior of the algorithm and settings should be based on the form factor of the device under test.

5.1 LTE thermal mitigation functioning

5.1.1 Uplink flow control and Tx backoff behavior

Uplink flow control consists of:

- Temperature monitor (currently only PA temperature is used to trigger uplink data throttling)
- Centralized flow control manager
- LTE MAC BSR control
- Tx power backoff

Temperature monitor

Normal/mitigation

CFM

UP/Down

Update target data rate(NV65611) as per step timer (NV65676)

Maintain fake buffer size

Buffer Status Report

Figure 5-1 shows the uplink flow control.

Figure 5-1 Uplink flow control

In this section, the uplink throughput in each flow control state is reviewed. The flow control state is derived from the input of one or more thermal sensor subsystems and potentially other resources. Since the focus is on the thermal sensor, only the transitions related to the PA temperature monitor are described.

UL flow control can be in any of four states, Normal, MAC_BRS, Tx Backoff, or Shutdown, as shown in Figure 5-2.




Figure 5-2 UL flow control

The UE's flow control can be categorized in four different states depending on its thermal state, as shown in Figure 5-3 and Figure 5-4.

■ Normal state (FC_OFF) – This is the default state of the UE. In this state, the UE is below the configured temperature threshold (PA mitigation threshold), and the UE operates in complete accordance with 3GPP specifications. Once the configured threshold is crossed, the UE moves to the Flow Control (FC_ON) state.

- MAC BSR state Mitigation 1
 - □ Upon entering this state from the FC_OFF state, if LTE is up and the MAC_BSR client is registered with the CFM, a DOWN command is sent to the MAC_BSR client.
 - □ Upon entering this state from the Tx Backoff state, if LTE is up and the Tx_backoff client is registered with the CFM, an UP command is sent to the Tx_backoff client.
 - □ While in the MAC_BSR state:
 - If a "normal" indication is received from the temperature monitor, and
 - If the MAC_BSR client is registered with the CFM, an UP command is sent to the MAC_BSR client.
 - If the MAC_BSR client is not registered with the CFM, then transition to the FC OFF state.
 - If a "mitigation" indication is received from the temperature monitor, and if the MAC_BSR client is registered, a DOWN command is sent to the client.
 - ☐ If the MAC_BSR client registers with CFM while CFM is in this state, the MAC_BSR client receives a DOWN command immediately after registration.
 - □ Upon receiving the "Tx backoff" indication from the temperature monitor, transition to the Tx_backoff state.
 - □ Upon receiving an "emergency" indication from the temperature monitor, transition to the Shutdown state.




Figure 5-3 UE states - Mitigation 1

12

13

14

15

16

17

18

19

2.0

- Tx Backoff state Mitigation 2
 - Upon entering this state from the Shutdown state, it is assumed that LTE is not active in the Shutdown state, therefore no action is necessary when transitioning to this state from the Shutdown state.
 - □ Upon entering this state from the MAC_BSR state, if LTE is up and the Tx_backoff client is registered with CFM, a DOWN command is sent to the Tx_backoff client.
 - □ While in the Tx_backoff state:
 - If a "mitigation" indication is received from the temperature monitor, and if the Tx_backoff client is registered with CFM, an UP command is sent to the Tx_backoff client; CFM transitions to the MAC_BSR state.
 - If a "normal" indication is received from the temperature monitor, and
 - If the MAC_BSR client is registered, CFM transitions to the MAC_BSR state.
 - If the MAC_BSR client is not registered, CFM transitions to the FC_OFF state.
 - If the MAC_BSR client registers with CFM while CFM is in this state, the MAC_BSR client receives a DOWN command immediately after registration.
 - If the Tx backoff client registers with CFM while CFM is in this state, the Tx_backoff client shall receive a DOWN command immediately after registration.
 - Upon receiving an "emergency" indication from the temperature monitor, transition to the Shutdown state.




Figure 5-4 UE states - Mitigation 2

- Shutdown Emergency state
 - ☐ The behavior in the Emergency state is to drop the RRC connection. The PA is not shut down in this state.

10

11

12

13

14

15

16

17

18

19

2.0

21

22

23

5.2 WCDMA/HSPA thermal mitigation

5.2.1 RLC data throttling and Tx backoff behavior

The objective of RLC flow control is to reduce power consumption associated with HSPA, as one of the major contributors of power consumption is processing higher data rates.

In the downlink direction, based on the commands from the DEM module, the RLC flow control function will flow control the peer-side RLC (UTRAN) by means of Windows commands when entered into the Mitigation state. A sufficient decrease in the RLC window size, i.e., closing the window, will decrease the amount of data sent to the UE and thereby the processing required. The window size is decreased gradually in steps whenever the periodic timer expires in the Mitigation state. If the device enters the Emergency state, the RLC window size with value 1 is sent to the peer entity in order to go to the lowest possible data throttling. Conversely, if the basic state is entered, the data flow can be increased by increasing the window size (opening the window).

A similar process of window size adjustment is used in the uplink direction. In this case, since the transmitting entity is located on the UE itself, the window size can be directly controlled without the need for sending any commands over the air to the peer-side RLC.

Tx power backoff happens upon entering the Mitigation 2 state:

- Initialize step counter and MPTL backoff value
- Call RF API to reduce the MTPL by an initial backoff value
- Trigger duty-cycle and step timers

Upon exiting the Mitigation 2 state, call the RF API to restore MTPL to a normal value before backoff.

5.3 1X/DO thermal mitigation functioning

The thermal sensor for the power amplifier subsystem is integrated with the Congestion Control Manager (CCM). CCM impacts reverse link flow control only in DO/1X mode of operation. The CCM reduces the reverse link data rate so that the heat generated from the PA can be reduced to an acceptable level, so as to maintain the maximum possible data rate in the system.

If PA sensor mitigation is triggered, the reverse link limits the maximum allowed payload size (or packet size) on certain carriers at the reverse link MAC layer (RMAC) in the DO protocol stack. RMAC performs QoS-based packet prioritization. By allowing a certain packet size, QoS may be maintained. If PA sensor critical is triggered on DO, RMAC on DO sets the maximum payload size of all active carriers to 0 except SLP. The SLP carrier is kept at the default maximum payload size.

If PA sensor mitigation/critical is triggered on 1X, the device shall stop requesting for R-SCH (Reverse Supplemental Channel), which will stop the reverse link traffic on 1X. When the PA sensor Normal state is triggered, the device shall resume R-SCH processing.

10

14

15

16

17

18

19

20

21

22

23

2.4

25

29

30

31

32

6 Thermal Management Test Results

Updates will be included in subsequent revisions.