ACKNOWLEDGEMENT

By utilizing this website and/or documentation, I hereby acknowledge as follows:

Effective October 1, 2012, QUALCOMM Incorporated completed a corporate reorganization in which the assets of certain of its businesses and groups, as well as the stock of certain of its direct and indirect subsidiaries, were contributed to Qualcomm Technologies, Inc. (QTI), a whollyowned subsidiary of QUALCOMM Incorporated that was created for purposes of the reorganization.

Qualcomm Technology Licensing (QTL), the Company's patent licensing business, continues to be operated by QUALCOMM Incorporated, which continues to own the vast majority of the Company's patent portfolio. Substantially all of the Company's products and services businesses, including QCT, as well as substantially all of the Company's engineering, research and development functions, are now operated by QTI and its direct and indirect subsidiaries ¹. Neither QTI nor any of its subsidiaries has any right, power or authority to grant any licenses or other rights under or to any patents owned by QUALCOMM Incorporated.

No use of this website and/or documentation, including but not limited to the downloading of any software, programs, manuals or other materials of any kind or nature whatsoever, and no purchase or use of any products or services, grants any licenses or other rights, of any kind or nature whatsoever, under or to any patents owned by QUALCOMM Incorporated or any of its subsidiaries. A separate patent license or other similar patent-related agreement from QUALCOMM Incorporated is needed to make, have made, use, sell, import and dispose of any products or services that would infringe any patent owned by QUALCOMM Incorporated in the absence of the grant by QUALCOMM Incorporated of a patent license or other applicable rights under such patent.

Any copyright notice referencing QUALCOMM Incorporated, Qualcomm Incorporated, QUALCOMM Inc., Qualcomm Inc., Qualcomm or similar designation, and which is associated with any of the products or services businesses or the engineering, research or development groups which are now operated by QTI and its direct and indirect subsidiaries, should properly reference, and shall be read to reference, QTI.

¹ The products and services businesses, and the engineering, research and development groups, which are now operated by QTI and its subsidiaries include, but are not limited to, QCT, Qualcomm Mobile & Computing (QMC), Qualcomm Atheros (QCA), Qualcomm Internet Services (QIS), Qualcomm Government Technologies (QGOV), Corporate Research & Development, Qualcomm Corporate Engineering Services (QCES), Office of the Chief Technology Officer (OCTO), Office of the Chief Scientist (OCS), Corporate Technical Advisory Group, Global Market Development (GMD), Global Business Operations (GBO), Qualcomm Ventures, Qualcomm Life (QLife), Quest, Qualcomm Labs (QLabs), Snaptracs/QCS, Firethorn, Qualcomm MEMS Technologies (QMT), Pixtronix, Qualcomm Innovation Center (QuIC), Qualcomm iskoot, Qualcomm Poole and Xiam.



Standalone MP-Decision Tuning Guide

80-N9277-1 A

Qualcomm Confidential and Proprietary

Qualcomm Confidential and Proprietary

Restricted Distribution. Not to be distributed to anyone who is not an employee of either Qualcomm or a subsidiary of Qualcomm without the express approval of Qualcomm's Configuration Management.

Not to be used, copied, reproduced in whole or in part, nor its contents revealed in any manner to others without the express written permission of Qualcomm.

Qualcomm reserves the right to make changes to the product(s) or information contained herein without notice. No liability is assumed for any damages arising directly or indirectly by their use or application. The information provided in this document is provided on an "as is" basis.

This document contains Qualcomm confidential and proprietary information and must be shredded when discarded.

QUALCOMM is a registered trademark of QUALCOMM Incorporated in the United States and may be registered in other countries. Other product and brand names may be trademarks or registered trademarks of their respective owners. CDMA2000 is a registered certification mark of the Telecommunications Industry Association, used under license. ARM is a registered trademark of ARM Limited. QDSP is a registered trademark of QUALCOMM Incorporated in the United States and other countries.

This technical data may be subject to U.S. and international export, re-export, or transfer ("export") laws. Diversion contrary to U.S. and international law is strictly prohibited.

Qualcomm Confidential and Proprietary

QUALCOMM Incorporated 5775 Morehouse Drive San Diego, CA 92121-1714 U.S.A. Copyright © 2012 QUALCOMM Incorporated. All rights reserved.

Revision History

Version	Date	Description	
А	Jan 2012	Initial release	



Contents

- MP-Decision Parameters Overview
- MP-Decision Parameters Nw, Tw
- MP-Decision Parameters Ns, Ts
- MP-Decision Parameters mp_decision
- MP-Decision Parameters no_sleep
- MP-Decision Parameters --debug
- MP-Decision Parameters Plotting RQ Depth
- MP-Decision Parameters Plotting RQ Depth (Example Plot)
- References
- Questions?

MP-Decision Parameters – Overview

- MP-decision takes as input the average runQ depth (the average of the sum of all the tasks in the CPU runQs) in a fixed time interval.
- Let N be the value that represents the average runQ depth. Then:
 - Nw is the upper threshold for N.
 - Tw is the time duration (in ms) for which the Nw threshold has been exceeded before the second core is woken up.
 - Ns is the lower threshold for N.
 - Ts is the time duration (in ms) for which the Ns threshold must be exceeded before the second core is put to sleep.
 - decision_ms is the time interval (in ms) for which N is computed.
 - --no_sleep is the option to disable idle power collapse while the second core is online (Dual Core mode).
 - --debug enables verbose debug logging.

MP-Decision Parameters – Nw, Tw

- Nw and Tw control the decision to bring the second core online. When the system is in Single Core mode (CPU1 offline) the runQ average samples read from kernel are compared to the threshold Nw.
- The second core is brought online only if the *Nw* threshold is exceeded for *Tw* time. In other terms, the second core is brought online if a set of consecutive samples with value greater than *Nw* are read from kernel and the total duration of those samples is greater than *Tw*.
- The lower the value of *Nw*, the more sensitive *mpdecision* is to runQ changes.
- The shorter the *Tw* time, the more responsive *mpdecision* is to bring the second core online.

MP-Decision Parameters – Ns, Ts

- Ns and Ts control the decision to take the second core offline. When the system is in Dual Core mode (CPU0-1 online) the runQ average samples read from kernel are compared to the threshold Ns.
- The second core is taken offline only if the sampled runQ average is below the *Ns* threshold *Ts* time. In other terms, the second core is brought offline if a set of consecutive samples with a value lower than *Ns* are read from kernel and the total duration of those samples is greater than *Ts*.
- The lower the value of *Ns*, the more sensitive *mpdecision* is to runQ changes.

Qualcomm Confidential and Proprietary

■ The shorter the *Ts* time, the more responsive *mpdecision* is to take the second core offline.

MP-Decision Parameters – mp_decision

• mp_decision is the rate at which mpdecision reads the runQ average computed by the kernel component. At the end of each mp_decision interval, mpdecision compares the read value with its thresholds to determine whether the second core needs to be taken offline/online.

MP-Decision Parameters – --no_sleep

- --no_sleep option prevents the cores to idle power collapse while mpdecision decisdes to keep the second core online (while the system is in Dual Core mode).
- If --no_sleep is used, then when mpdecision brings the second core online, idle power collapse is disabled on both cores. It is restored the moment mpdecision takes the second core offline (while the system is in Single Core mode).
- Conceptually, if *mpdecision* keeps the second core online is because the runQ average is above the *Nw* threshold meaning that a certain level of workload parallelism is detected in the system. Enabling the --no_sleep option (thus preventing the cores to idle power collapse) allows the system to run at max performance when in Dual Core mode and avoid those cases in which short idles in the workload might cause a core to idle power collapse. If this occurs and a new task is scheduled on that core, then there is a performance impact due to the overhead to wake up the core from power collapse.

MP-Decision Parameters – --debug

- --debug enable verbose debug logging
- If --debug is enabled, mpdecision prints these type of messages at the end of each decision interval:
 - Runqueue depth :<AVG> time :<TIME>\n
 - where <AVG> is the average runq for the sample of duration <TIME>ms (just) read
 - UP Nw:%f Tw:%d rq:%f seq:%f\n
 - Printed when mpdecision brings cpu1 online. Nw and Tw are the values to which the parameters are set. rq is the runq average of the last sample read. seq is the total time the avg runq has been greater than Nw. Assert: seq > Tw.
 - DOWN Ns:%f Ts:%d rq:%f seq:%f online_time: %lli\n

Qualcomm Confidential and Proprietary

Printed when mpdecision brings cpu1 offline. Ns and Ts are the values to which the parameters are set. rq is the runq average of the last sample read. seq is the total time the avg runq has been less than Ns. Assert: seq > Ts. online_time is the time cpu1 has been online (the time since the last "UP" decision).

MP-Decision Parameters – Plotting RQ Depth

- To generate a rq depth plot, you must collect the logs twice:
 - In Single Core mode: for Nw, Tw determination. To force Single Core:

```
/system/bin/mpdecision --no_sleep --avg_comp --Nw=999 --Tw=9999 --Ns=999 --Ts=1
```

In Dual Core mode: for Ns, Ts determination. To force Dual Core:

```
/system/bin/mpdecision --no_sleep --avg_comp --Nw=0.1 --Tw=1 --Ns=0.0 --Ts=99999
```

 Copy and paste (import) the output of messages of the form: (Runqueue depth :<AVG> time :<TIME>) into excel. In the log, each entry looks like this:

```
....
```

```
E/MP-Decision( 1865): Runqueue depth :1.457627 time :59.000000 E/MP-Decision( 1865): Runqueue depth :1.100418 time :239.000000 E/MP-Decision( 1865): Runqueue depth :1.104046 time :519.000000 E/MP-Decision( 1865): Runqueue depth :1.225941 time :239.000000
```


MP-Decision Parameters – Plotting RQ Depth (cont.)

- Assume you imported two columns Lx, Ly in Excel where:
 - Lxi=<time_interval_from_log_entry> and Lyi=<Runq_depth>
 - Create another series S where each entry (Sxi, Syi) corresponds to an entry (Lxi, Lyi), where:

```
Sy0=Ly0, Sx0=Lx0; Sy1=Ly1, Sx1=Sx0+Lx1; ... Syi=Lyi, Sxi=Sx(i-1)+Lxi; ...
```


- Using the sample log:
 - Plot the series (Sx, Sy)

RunQueue depth vs time



For each test case, create a series (Sx,Sy) for the Single Core and Dual Core cases. The synchronization between the series is done just looking at the waveform, and you can typically detect where the app starts/finish.

MP-Decision Parameters – Plotting RQ Depth (Example Plot)



References

Ref.	Document		
Qualcomm			
Q1	Application Note: Software Glossary for Customers	CL93-V3077-1	



Questions?

https://support.cdmatech.com