内核去除电容屏驱动配置编译

由于我们的内核包含有电容屏的官方驱动，现在我们把官方驱动抛弃，自己动手写一个。

在内核中去除官方驱动办法如下：

1.进入虚拟机内核源码目录:

```
mingzhi@sunplusedu:~$ cd unsp210_linux_2.6.35/
```

2.执行 make menuconfig

```
mingzhi@sunplusedu:~$ cd unsp210_linux_2.6.35/
mingzhi@sunplusedu:~/unsp210_linux_2.6.35$ make menuconfig
```

3.进入 Device Drivers

```
        ^(-)
            Floating point emulation  --->
            Userspace binary formats  --->
            Power management options  --->
    [*] Networking support   --->
        Device Drivers  --->
        File systems  --->
        Kernel hacking  --->
        Security options  --->
-*- Cryptographic API  --->
        Library routines  --->
    ---
        Load an Alternate Configuration File
        Save an Alternate Configuration File
```

4. 进入 Input device support

```
    [ ] ISDN support   --->
    < > Telephony support   --->
         Input device support   --->
         Character devices   --->
    <*> I2C support   --->
    [*] SPI support   --->
         PPS support   --->
    -*- GPIO Support   --->
```

5. 进入 Touchscreens

```
         *** Input Device Drivers ***
    [ ]   Keyboards   --->
    [ ]   Mice   --->
    [ ]   Joysticks/Gamepads   --->
    [ ]   Tablets   --->
    [*]   Touchscreens   --->
    [*]   Miscellaneous devices   --->
         Hardware I/O ports   --->
```

6. 把这两项前面的*去掉。

```
    < >   USB Touchscreen Driver
    < >   Sahara TouchIT-213 touchscreen
    < >   TSC2007 based touchscreens
    < >   W90P910 touchscreen driver
    < >   TPS6507x based touchscreens
    < >   GOODIX based touchscreen
    < >   FocalTech tf5x0x touchscreen
```

7. 保存退出。

8. make