








Ручка поворотная УИСВГД-401-070-14-00











1. Ручка
УИСВГД-401-070-14-00-01





2. Гайка
УИСВГД-401-070-02





3. Ручка.
УИСВГД-401-070-14-03






4. Втулка
УИСВГД-401-070-14-04






5. Гайка.
УИСВГД-401-070-14-05



6. Ось
УИСВГД-401-070-14-06



7. Пружина
УИСВГД-401-070-14-07



8. Ручка
УИСВГД-401-070-14-08