SPIRA-LOK®

The Original Helicial Wall Tie System

BLOK-LOK

SPIRA-LOK® INSTALLATION

Installation techniques have evolved to optimize the performance of the **Spira-Lok® Wall Tie System.** Installation procedures are available along with product specifications for typical masonry stabilization. Rotary percussion drilling usually achieves the best results.

TOOLS AND ACCESSORIES

All installation components required, whether it be new construction, refacing, or a dry set pinning application are available from Blok-Lok. Blok-Lok drill bits and setting tools are required for proper **Spira-Lok®** anchor installations.

TYPICAL SPIRA-LOK® MASONRY BIT SIZE (MM)

		BACK-UP MATERIAL					
Facade Material	Spira-Lok	Mortar Joint	Brick	CMU	Concrete	Wood Stud	Metal Stud
Mortar Joint	8mm	5.0	AS	5.0	AS	5.0	5.0
	10mm	6.5	AS	6.5	AS	6.5	6.5
Brick	8mm	6.5/5.0	6.5	6.5/5.0	6.5	6.5/5.0	6.5/5.0
	10mm	8.0/6.5	8.0	8.0/6.5	8.0	8.0/6.5	8.0/6.5
CMU	8mm	5.0	AS	5.0	AS	5.0	5.0
	10mm	6.5	AS	6.5	AS	6.5	6.5
Precast Concrete	8mm	6.5/5.0	6.5	6.5/5.0	6.5	6.5/5.0	6.5/5.0
	10mm	8.0/6.5	8.0	8.0/6.5	8.0	8.0/6.5	8.0/6.5
Stone	8mm	6.5/5.0	6.5	6.5/5.0	6.5	6.5/5.0	6.5
	10mm	8.0/6.5	8.0	8.0/6.5	8.0	8.0/6.5	8.0

Facade Hole / Back-up Hole | AS = Asymmetric Anchor Required

TIE SELECTION

- Available in 8.0 mm and 10.0 mm diameters.
- Tie length to suit wall conditions having a nominal facade width of 4 inches.
- Ties are produced from austenitic stainless steel Type 304. Type 316 Stainless is also available for more severe corrosive environments.

SPIRA-LOK® LENGTH SELECTION

Catalog #	Nominal Length	Minimum Drilled Hole Depth	Cavity Range	
			CMU	Concrete
HWT-155	6-1/8"	6-5/8"	1-1/8" – 0	1-1/2" – 0
HWT-170	6-5/8"	7-1/8"	1-5/8" – 0	2-1/2" – 1-1/2"
HWT-195	7-5/8"	8-1/8"	2-5/8" – 0	3-1/2" – 2-1/2"
HWT-220	8-5/8"	9-1/8"	3-5/8" – 0	4-1/2" – 3-1/2"
HWT-245	9-7/8"	10-1/8"	4-7/8" – 0	5-5/8" – 4-5/8"
HWT-270	10-7/8"	11-3/8"	5-7/8" – 0	6-5/8" – 5-5/8"
HWT-295	11-7/8"	12-3/8"	6-7/8" – 0	7-5/8" – 6-5/8"
HWT-330	13-1/4"	14"	8-1/4" – 0	8-3/4" – 7-3/4"

NOTE: The SDS rotary hammer is ALWAYS used with the dry set insertion tool to install the **Spira-Lok® Wall Tie.**

INSTALLATION MECHANISM

1. Drill a pilot hole through the veneer and into the substrate.

2. Tie cuts a helical channel through both wythes of the wall.

3. Helical channel with "slots" offers resistance to compressive and tensile loads.

SPIRA-LOK® INSTALLATION

STEP 1: Drill a pilot hole using percussion hammer drill (3-jaw chuck type) through the mortar joint and into the block back-up.

STEP 2: Insert the Spira-Lok Wall Tie into the dry set installation tool mounted on the rotary hammer S.D.S. drill.

STEP 3.1: Drive the Spira-Lok Wall Tie through the mortar joint and into the back-up.

STEP 3.2: Drive the Tie until the nose of the dry set installation tool is hard against the veneer.

STEP 4: The dry set installation tool automatically recesses the Spira-Lok Wall Tie into the face of the masonry.

STEP 5: Cap the pilot hole with an aesthetically compatible material.