
## **ADAM Research**

## Berechnungen und Dienstleistungen

## TRM White Paper No. 1

## Mindesttemperatur einer Leiterplatte Minimum Temperature of a Printed Board

**Frage:** Was wäre die Temperatur einer Leiterplatte, wenn man die Verluste aller Bauteile gleichmäßig verteilen würde?



Bevor man an die Detailanalyse von Hotspots geht, sollte man das durchschnittliche Temperaturniveau abschätzen. Dazu nehmen wir an, die Gesamtverlustleistung P [Watt] sei über die Leiterplatte gleichförmig verteilt und die Leiterplatte habe einen "normal schlechten" Wärmeaustausch mit der Umgebung. Wir meinen damit Wärmeabgabe an die Luft in freier Konvektion (ohne Gehäuse) und ohne Wärmestrahlung. Natürlich gibt es noch schlechtere und bessere Konfigurationen. Die Formel, die die Plattentemperatur liefert lautet:

$$T_{\text{PCB}} \approx T_{\text{Luft}} + \frac{P}{\alpha \cdot 2 \cdot L \cdot H}$$

Dabei sind L und H Länge und Höhe der Platte (in m) und  $\alpha$  der sog. Wärmeübergangskoeffizient. Als typische Grösse kann man sich für die oben beschriebene Situation merken  $\alpha = 6 \pm 1$  W/(m²·K).

Falls man ungehinderte **Wärmestrahlung** berücksichtigen möchte, dann erhöht sich  $\alpha$  auf 11 ± 1 W/(m²·K).


**Beispiel**: eine Eurokarte (L=100 mm, H=160 mm) mit 10 Watt Verlustleistung erwärmt sich unter ungünstigen Umständen um

10 W / (6 W/m $^2$ K  $\cdot$ 2 $\cdot$ 0.1 m  $\cdot$ 0.16 m) = 50 K gegen über Umgebung, bzw. 30 K wenn man ungehinderte Abstrahlung annimmt.

Bei Lüfterbetrieb hat man natürlich einen von der Luftgeschwindigkeit abhängigen Wert von  $\alpha$ . Auch im Gehäuse ist der Wert anders. Bauteile erzeugen Hotspots, die in der Formel ebenfalls nicht abgebildet werden.

3.6.2011

**Question:** What could be the temperature of a printed board, if the power loss of all components were distributed uniformly?



Before looking for hotspots in detail, you should *estimate* the **average temperature level** of the board.

We assume that the total power loss P [Watt] is distributed uniformly over the board and the board has an 'usually bad' heat exchange with its environment. By this we mean a heat transfer to air in **free convection** (without enclosure) but **without heat radiation**. Of course, there a worse and better conditions. The formula, which gives us the temperature of the plate is

$$T_{\text{PCB}} \approx T_{\text{sir}} + \frac{P}{h \cdot 2 \cdot L \cdot H}$$

L is length and H is height of the plate (in m) and h is the so-called *heat exchange coefficient*. As a typical value you could memorize  $h = 6 \pm 1$  W/m²K.

Supposed you like to take into account unhindered heat radiation, the value rises to  $h \approx 11 \pm 1$  W/m<sup>2</sup>K. h depends on board geometry and on power.

**Example**: an Euro card PCB (100 mm x 160 mm) with 10 Watts power loss heats up under bad conditions by  $10 \text{ W} / (6 \text{ W/m}^2\text{K} \cdot 2 \cdot 0.1 \text{ m} \cdot 0.16 \text{ m}) = 50 \text{ K}$ 

above ambient, or about 30 K above ambient if heat radiation is allowed.

If fans are active h depends on air speed and is larger than 6 or 11 W/m<sup>2</sup>K, resp. Inside enclosures the value is also different. Components creating hotspots cannot be treated by the formula above properly.

June 6<sup>th</sup> 20112