Number: SOP-CRD-STARTUP	Use Category: CONTINUOUS	Major Rev: 003 Minor Rev: 001 Page: 1 of 1
Title: Control Rod Drive System Startup		

## 1.0 <u>STARTUP</u>

- 1.1 **VERIFY** one CRD pump running.
- 1.2 **VERIFY** CRD system flow increases.
- 1.3 **VERIFY** CRD System Flow Controller in AUTO.
- 1.4 **THROTTLE** CRD-V-3, as required to maintain Drive Water  $\Delta$  Pressure 3/4 of the gauge scale.