# AVR221: Discrete PID controller

## **Features**

- Simple discrete PID controller algorithm **离散的PID控制器算法**
- Supported by all AVR devices
- PID function uses 534 bytes of code memory and 877 CPU cycles (IAR low size optimization)

## 1 Introduction


This application note describes a simple implementation of a discrete <u>Proportional</u>-Integral-Derivative (*PID*) controller.

When working with applications where control of the system output due to changes in the reference value or state is needed, implementation of a control algorithm may be necessary. Examples of such applications are <u>motor control</u>, <u>control of temperature</u>, <u>pressure</u>, <u>flow rate</u>, <u>speed</u>, <u>force</u> or other variables. The *PID* controller can be used to control any measurable variable, as long as this variable can be affected by manipulating some other process variables.

Many control solutions have been used over the time, but the *PID* controller has become the 'industry standard' due to its simplicity and good performance.

For further information about the PID controller and its implications the reader should consult other sources, e.g. *PID Controllers* by K. J. Astrom & T. Hagglund (1995).

Figure 1-1. Typical PID regulator response to step change in reference input





# 8-bit **AVR**® Microcontrollers

## **Application Note**

Rev. 2558A-AVR-05/06






## 2 PID controller

In Figure 2-1 a schematic of a system with a PID controller is shown. The PID controller compares the measured process value y with a reference setpoint value,  $y_0$ . The difference or error, e, is then processed to calculate a new process input, u. This input will try to adjust the measured process value back to the desired setpoint.

The alternative to a closed loop control scheme such as the *PID* controller is an open loop controller. Open loop control (no feedback) is in many cases not satisfactory, and is often impossible due to the system properties. By adding feedback from the system output, performance can be improved.

Figure 2-1. Closed Loop System with PID controller





Unlike simple control algorithms, the *PID* controller is capable of manipulating the process inputs based on the history and rate of change of the signal. This gives a more accurate and stable control method.

控制现在—比例 控制过去—积分 控制将来—导数 The basic idea is that the controller reads the system state by a sensor. Then it subtracts the measurement from a desired reference to generate the error value. The error will be managed in three ways, to handle the present, through the proportional term, recover from the past, using the integral term, and to anticipate the future, through the derivate term.

Figure 2-2 shows the *PID* controller schematics, where  $T_p$ ,  $T_i$ , and  $T_d$  denote the time constants of the proportional, integral, and derivative terms respectively.

Figure 2-2. PID controller schematic






The proportional term (P) gives a system control input proportional with the error. Using only P control gives a stationary error in all cases except when the system control input is zero and the system process value equals the desired value. In Figure 2-3 the stationary error in the system process value appears after a change in the desired value (ref). Using a too large P term gives an unstable system.

预期值 (ref)

Figure 2-3. Step response P controller






The integral term (*I*) gives an addition from the sum of the previous errors to the system control input. The summing of the error will continue until the system process value equals the desired value, and this results in no stationary error when the reference is stable. The most common use of the *I* term is normally together with the *P* term, called a *PI* controller Using only the *I* term gives slow response and often an oscillating system. Figure 2-4 shows the step responses to a *I* and *PI* controller. As seen the *PI* controller response have no stationary error and the *I* controller response is very slow.

[MRQQHI®分(积分部分)的话,反应会很慢并且系统会振荡。





Figure 2-4. Step response I and PI controller






The derivative term (*D*) gives an addition from the rate of change in the error to the system control input. A rapid change in the error will give an addition to the system control input. This improves the response to a sudden change in the system state or reference value. The *D* term is typically used with the *P* or *Pl* as a *PD* or *PlD* controller. A to large *D* term usually gives an unstable system. Figure 2-5 shows *D* and *PD* controller responses. The response of the *PD* controller gives a faster rising system process value than the *P* controller. Note that the *D* term essentially behaves as a highpass filter on the error signal and thus easily introduces instability in a system and make it more sensitive to noise.

PD控制器比P控制器有一个跟快的上升过程

D部分本质上相当于一个对于误差信号的高通滤波器,因此很容易在系统中引入不稳定因素和对噪声很敏感。


Figure 2-5. Step response D and PD controller



Using all the terms together, as a *PID* controller usually gives the best performance. Figure 2-6 compares the *P*, *PI*, and *PID* controllers. *PI* improves the *P* by removing the stationary error, and the *PID* improves the *PI* by faster response and no overshoot.

PI比P少了静态误差,PID比PI反应速度更快并且没有了过冲。

Figure 2-6. Step response P, PI and PID controller





## 2.4 Tuning the parameters

最好的寻找PID参数的办法是从系统的数学模型出发,从想要的反应来计算参数。很多时候 个详细的数学描述是不存在的,这时候就需要实际地调节PID的参数

The best way to find the needed *PID* parameters is from a mathematical model of the system, parameters can then be calculated to get the desired response. Often a detailed mathematical description of the system is unavailable, experimental tuning of the *PID* parameters has to be performed. Finding the terms for the *PID* controller can be a challenging task. Good knowledge about the systems properties and the way the different terms work is essential. The optimum behavior on a process change or setpoint change depends on the application at hand. Some processes must not allow overshoot of the process variable from the setpoint. Other processes must minimize the energy consumption in reaching the setpoint. Generally, stability is the strongest requirement. The process must not oscillate for any combinations or setpoints. Furthermore, the stabilizing effect must appear within certain time limits.

Several methods for tuning the PID loop exist. The choice of method will depend largely on whether the process can be taken off-line for tuning or not. Ziegler-Nichols method is a well-known online tuning strategy. The first step in this method is setting the I and I gains to zero, increasing the I gain until a sustained and stable oscillation (as close as possible) is obtained on the output. Then the critical gain I kc and the oscillation period I is recorded and the I and I values adjusted accordingly using Table 2-1.

Table 2-1. Ziegler-Nichols parameters

Controller	K <sub>p</sub>	T <sub>i</sub>	T <sub>d</sub>
Р	0.5 * K <sub>c</sub>		
PD	0.65 * K <sub>c</sub>		0.12 * P <sub>c</sub>
PI	0.45 * K <sub>c</sub>	0.85 * P <sub>c</sub>	
PID	0.65 * K <sub>c</sub>	0.5 * P <sub>c</sub>	0.12 * P <sub>c</sub>

Further tuning of the parameters is often necessary to optimize the performance of the *PID* controller.

The reader should note there is systems where the *PID* controller will not work very well, or will only work on a small area around a given system state. Non-linear systems can be such, but generally problems often arise with *PID* control when systems are unstable and the effect of the input depends on the system state.

## 一些系统需要避免过冲 一些系统需要在选点上功耗最小

当然稳定性是最高的要求



#### 步骤:

1. 先置Ki=Kd=0,逐渐增加Kp直到 在输出得到一个持续的稳定的振 荡。

2. 记录下振荡时的P部分的临界增 益Kc,和振荡周期Pc,代到下表中 计算出Kp,Ki(Ti),Kd(Td)。

Kp = 0.6\*Km Kd = Kp\* /4\* Ki = Kp\* /

L式中Kp为比例控制参数 Kd为微分控制参数 Ki为积分控制参数 Km为系统开始振荡时的比例值 为振荡时的频率

#### 2.5 Discrete PID controller

A discrete PID controller will read the error, calculate and output the control input at a given time interval, at the sample period T. The sample time should be less than the shortest time constant in the system.

## 2.5.1 Algorithm background

Unlike simple control algorithms, the *PID* controller is capable of manipulating the process inputs based on the history and rate of change of the signal. This gives a more accurate and stable control method.

Figure 2-2 shows the *PID* controller schematics, where  $T_p$ ,  $T_i$ , and  $T_d$  denotes the time constants of the proportional, integral, and derivative terms respectively.

The transfer function of the system in Figure 2-2:

$$\frac{u}{e}(s) = H(s) = K_p \left(1 + \frac{1}{T_i s} + T_d s\right)$$

This gives u with respect to e in the time domain:

$$u(t) = K_p \left( e(t) + \frac{1}{T_i} \int_0^t e(\sigma) d\sigma + T_d \frac{de(t)}{dt} \right)$$

Approximating the integral and the derivative terms to get the discrete form, using:

$$\int_{0}^{t} e(\sigma)d\sigma \approx T \sum_{k=0}^{n} e(k) \qquad \frac{de(t)}{dt} \approx \frac{e(n) - e(n-1)}{T} \qquad t = nT$$

Where n is the discrete step at time t.

This gives the controller:

$$u(n) = K_p e(n) + K_i \sum_{k=0}^{n} e(k) + K_d (e(n) - e(n-1))$$

Where:

$$K_i = \frac{K_p T}{T_i} \qquad K_d = \frac{K_p T_d}{T}$$

To avoid that changes in the desired process value makes any unwanted rapid changes in the control input, the controller is improved by basing the derivative term on the process value only:


$$u(n) = K_p e(n) + K_i \sum_{k=0}^{n} e(k) + K_d (y(n) - y(n-1))$$



## 3 Implementation

A working implementation in C is included with this application note. Full documentation of the source code and compilation information if found by opening the 'readme.html" file included with the source code.

Figure 3-1. Block diagram of demo application



In Figure 3-1 a simplified block diagram of the demo application is shown.

The PID controller uses a struct to store its status and parameters. This struct is initialized in main, and only a pointer to it is passed to the  $Init_PID()$  and PID() functions.

The  $\overline{\text{PID}()}$  function must be called for each time interval T, this is done by a timer who sets the  $\overline{\text{PID\_timer flag}}$  when the time interval has passed. When the  $\overline{\text{PID\_timer flag}}$  is set the main routine reads the desired process value (setPoint) and system process value, calls  $\overline{\text{PID}()}$  and outputs the result to the control input.

To increase accuracy the p\_factor, i\_factor and d\_factor are scaled with a factor 1:128. The result of the *PID* algorithm is later scaled back by dividing by 128. The value 128 is used to allow for optimizing in the compiler.

$$PFactor = 128K_p$$

Furthermore the effect of the IFactor and DFactor will depend on the sample time  $\it{T}$  .

$$IFactor = 128K_{p} \frac{T}{T_{i}}$$

$$DFactor = 128K_{p} \frac{T_{d}}{T}$$

## 3.1 Integral windup

When the process input, u, reaches a high enough value, it is limited in some way. Either by the numeric range internally in the PID controller, the output range of the controller or constraints in amplifiers or the process itself. This will happen if there is a large enough difference in the measured process value and the reference setpoint value, typically because the process has a larger disturbance / load than the system is capable of handling.

## **AVR221**

If the controller uses an integral term, this situation can be a problematic. The integral term will sum up as long as the situation last, and when the larger disturbance / load disappear, the PID controller will overcompensate the process input until the integral sum is back to normal.

This problem can be avoided in several ways. In this implementation the maximum integral sum is limited by not allowing it to become larger than MAX\_I\_TERM. The correct size of the MAX\_I\_TERM will depend on the system and sample time used.

## 4 Further development

The *PID* controller presented here is a simplified example. The controller should work fine, but it might be necessary to make the controller even more robust (limit runaway/overflow) in certain applications. Adding saturation correction on the integral term, basing the proportional term on only the system process value can be necessary.

In the calculating of IFactor and DFactor the sample time T is a part of the equation. If the sample time T used is much smaller or larger than 1 second, accuracy for either IFactor or DFactor will be poor. Consider rewriting the PID algorithm and scaling so accuracy for the integral and derivate term is kept.

## 5 Literature references

K. J. Astrom & T. Hagglund, 1995: *PID Controllers: Theory, Design, and Tuning.* International Society for Measurement and Con.





## **Atmel Corporation**

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311 Fax: 1(408) 487-2600

## **Regional Headquarters**

#### Europe

Atmel Sarl
Route des Arsenaux 41
Case Postale 80
CH-1705 Fribourg
Switzerland

Tel: (41) 26-426-5555 Fax: (41) 26-426-5500

#### Asia

Room 1219 Chinachem Golden Plaza 77 Mody Road Tsimshatsui East Kowloon Hong Kong

Tel: (852) 2721-9778 Fax: (852) 2722-1369

#### Japan

9F, Tonetsu Shinkawa Bldg. 1-24-8 Shinkawa Chuo-ku, Tokyo 104-0033 Japan

Tel: (81) 3-3523-3551 Fax: (81) 3-3523-7581

#### **Atmel Operations**

#### Memory

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311 Fax: 1(408) 436-4314

#### **Microcontrollers**

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311 Fax: 1(408) 436-4314

La Chantrerie BP 70602 44306 Nantes Cedex 3, France Tel: (33) 2-40-18-18-18 Fax: (33) 2-40-18-19-60

#### ASIC/ASSP/Smart Cards

Zone Industrielle 13106 Rousset Cedex, France Tel: (33) 4-42-53-60-00 Fax: (33) 4-42-53-60-01

1150 East Cheyenne Mtn. Blvd. Colorado Springs, CO 80906, USA

Tel: 1(719) 576-3300 Fax: 1(719) 540-1759

Scottish Enterprise Technology Park Maxwell Building East Kilbride G75 0QR, Scotland

Tel: (44) 1355-803-000 Fax: (44) 1355-242-743

#### RF/Automotive

Theresienstrasse 2 Postfach 3535 74025 Heilbronn, Germany Tel: (49) 71-31-67-0 Fax: (49) 71-31-67-2340

1150 East Cheyenne Mtn. Blvd. Colorado Springs, CO 80906, USA

Tel: 1(719) 576-3300 Fax: 1(719) 540-1759

## Biometrics/Imaging/Hi-Rel MPU/ High Speed Converters/RF Datacom

Avenue de Rochepleine BP 123

38521 Saint-Egreve Cedex, France

Tel: (33) 4-76-58-30-00 Fax: (33) 4-76-58-34-80

## Literature Requests www.atmel.com/literature

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN ATMEL'S TERMS AND CONDITIONS OF SALE LOCATED ON ATMEL'S WEB SITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice. Atmel does not make commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel's products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

© Atmel Corporation 2006. All rights reserved. Atmel®, logo and combinations thereof, Everywhere You Are®, AVR®, and AVR Studio® are the registered trademarks of Atmel Corporation or its subsidiaries. Other terms and product names may be trademarks of others.