

Instructions

1. Create a folder in Google Drive with the project name and version in 2.Products -> FibriCheck -> 2.Components -> 0.Project Start
2. Ask Jo/Kevin to create GF151 Change Assessment. Sign this document when ready and move folder to 1.Project scope analysis
3. Create **GF 160** and fill in Section 2. *Project Scope*. This is a summary of all Jira issues connected to this version.
Complete Section 3. *Project Team*
Ask Jo/Kevin to complete section 5. *Phase 1* .
Sign the generated Design Review meeting Phase 1.
Ask Jo and Kobe to sign this document as well.
Move folder to 2.Design Inputs
4. Place the generated **GF161** in the to sign folder of your project.
Copy the link to this file in the **GF160** section 7. *Phase 2*
Sign the generated Design Review meeting Phase 2 and place it in the to sign folder
Ask Jo and Kobe to sign the **GF161** and the meeting Phase 2
Move folder to 3.Implementation Outputs
5. Complete section 9. *Phase 3* of the **GF160**.
Copy all the corresponding forms to the to sign folder and ask Jo/Kobe to sign them.
Copy the generated Phase 3 review to the to sign folder and ask Jo/Kobe to sign it.
Move folder to 4.Validation Outputs
6. Ask Jo to complete section 11. *Phase 4* of **GF160**.
Copy the generated Phase 4 review to the to sign folder and ask Jo/Kobe to sign it.
Sign **GF160** and ask Jo to do the same.
Update [The revision level history](#)
Move folder to 5.Released
7. Create **GF170** and complete it.
Sign this document and ask Kobe to do the same.
Move folder to 6. Deployed
8. Don't forget to update the [Deployment Plan](#) and the [Decommissioning Plan](#)
9. GG WP!