User's Guide

1. Variable and Register

One unsigned 8-bit variable B (Brightness) and sixteen 16-bit registers R0 to R15, the range of register value is -32768 to 32767.

Purpose:

Set the global brightness B and the value stored in registers R0 to R15.

Examples:

```
B = 255
'Set the global brightness B to 255.
B = R0
R1 = 123
'Set the register R1 to 123.
R3 = R1
R4 = B
```

2.Arithmetic Operators

Expressions combine variables and constants to produce new values. Arithmetic operators are used to perform many of the familiar arithmetic operations that involve the calculation of numeric values represented by variables.

You can add two values in an expression together with the + operator or subtract one from another with the - operator, as the following example demonstrates.

```
R1 = R2 + 123
R1 = R2 + R3
R4 = R5 - 123
R4 = 123 - R5
R6 = R7 - R8
```

Negation also uses the - operator, but with only one operand, as the following example demonstrates.

$$R0 = -123$$

Multiplication and division use the * operator and / operator, respectively, as the following example demonstrates.

$$R0 = R0 * 10$$

 $R1 = R2 * R3$

```
R2 = R0 / 10
R2 = R1 / R3
```

3.Logical Operations

Logical operations are performed between two data bits (except for NOT). Bits can be either "1" or "0", and these operations are essential to performing digital math operations.

The NOT operator performs logical negation. It yields the logical opposite of its operand. The following example illustrates this.

```
R1 = 1
R2 = NOT R1
'The preceding statement set R2 to 0.
```

The AND operator performs logical conjunction, the OR operator performs logical disjunction, and the XOR operator performs logical exclusion. The following example illustrates the AND, OR and XOR operators.

```
R1 = 1
R2 = 2
R3 = R1 AND R2
'The preceding statement set R3 to 0.
R1 = 1
R2 = 2
R3 = R1 OR R2
'The preceding statement set R3 to 3.
R1 = 1
R2 = 2
R3 = R1 XOR R2
'The preceding statement set R3 to 3.
```

3.CLS Statement

Purpose:

Set the brightness of all LED to 0.

Syntax:

CLS

Examples:

Set the brightness of all LED to 0.

4.PRINT Statement

Purpose:

To output a display to the LED.

Syntax:

PRINT <Index>/<Ri> [, <Bright>/<Rb>]

Comments:

Index is a string, it constants in the list must be enclosed in double quotation marks. For function keys, please see the following table:

Key	Expression	Key	Expression		
Esc	<esc></esc>	F1	<f1></f1>		
F2	<f2></f2>	F3	<f3></f3>		
F4	<f4></f4>	F5	<f5></f5>		
F6	<f6></f6>	F7	<f7></f7>		
F8	<f8></f8>	F9	<f9></f9>		
F10	<f10></f10>	F11	<f11></f11>		
F12	<f12></f12>	Print Screen	<prtsc></prtsc>		
Scroll Lock	<scroll></scroll>	Pause	<pause></pause>		
Backspace	<bsp></bsp>	Insert	<ins></ins>		
Home	<home></home>	Page Up	<pgup></pgup>		
Num Lock	<num></num>	Tab	<tab></tab>		
Delete		End	<end></end>		
Page Down	<pgdn></pgdn>	Caps Lock	<caps></caps>		
Enter	<ent></ent>	Left Shift	<lshift></lshift>		
Right Shift	<rshift></rshift>	UP	<up></up>		
Left	<left></left>	Down	<down></down>		
Right	<right></right>	Left Ctrl	<lctrl></lctrl>		
Left Win	<lwin></lwin>	Left Alt	<lalt></lalt>		

Space	<space></space>	Right Alt	<ralt></ralt>	
Right Win	<rwin></rwin>	Apps	<app></app>	
Right Ctrl	<rctrl></rctrl>	Keypad /	<k></k>	
Keypad *	<k*></k*>	Keypad -	<k-></k->	
Keypad +	<k+></k+>	Keypad O	<k0></k0>	
Keypad 1	<k1></k1>	Keypad 2	<k2></k2>	
Keypad 3	<k3></k3>	Keypad 4	<k4></k4>	
Keypad 5	<k5></k5>	Keypad 6	<k6></k6>	
Keypad 7	<k7></k7>	Keypad 8	<k8></k8>	
Keypad 9	<k9></k9>	Keypad Enter <kent></kent>		

If [, <Bright>/<Rb>] is omitted, global brightness will be used.

If [, <Bright>/<Rb>] is included, separated by commas, the values of the expressions are displayed. Expressions in the list may be numeric(brightness) or register RO to R15, the range of brightness is 0 to 255.

Examples:

PRINT "WASD<F1><K1>"

'Display LED with index(Key W,A,S,D,F1 and numeric keypad 1), and global brightness (variable \boldsymbol{B}) will be used.

PRINT "A", 255

'Display LED with index(Key A), and the value of brightness is 255.

PRINT "A", R1

'Display LED with index(Key A), and the value of register R1 will be used as brightness.

PRINT ALL[, <Bright>/<Rb>]

Comments:

Display all LED in brightness <Bright> or brightness stored in Rb.

Examples:

PRINT ALL, 255

'Display all LED in brightness 255.

PRINT ALL, 0

'Turn off all LED.

5.PSET Statements

Purpose:

To display LED at a specified place on the keyboard.

Syntax:

PSET X/Rx , Y/Ry [, <Bright>/<Rb>]

Comments:

X , Y (X and Y is an integer) or the value of register (Rx , Ry) represents the coordinates of the key.

If [, <Bright>/<Rb>] is omitted, global brightness will be used.

If [, <Bright>/<Rb>] is included, separated by commas, the values of the expressions are displayed. Expressions in the list may be numeric(brightness) or register RO to R15, the range of brightness is 0 to 255.

The relationship between position and key is as below:

	0	1		21	22
Х, Ү					
0	Esc	NULL	• • •	PN	Togg1e
1	`	1	• • •	Keypad *	Keypad -
2	Tab	Q	• • •	Keypad 9	Keypad +
3	Caps Lock	A	•••	Keypad 6	Keypad +
4	Left Shift	Z	•••	Keypad 3	Keypad Enter
5	Left Ctrl	Left Win		Keypad .	Keypad Enter

Examples 1:

PSET 0,0

'Display LED with position (0,0), and global brightness (variable \boldsymbol{B}) will be used.

Examples 2:

R1 = 10

R2 = 0

R3 = 255

PSET R1,R2,R3

'Display LED with position Rx, Ry(10, 0) in brightness stored in R3.

6. IF ... THEN ... ELSE ... END IF Statement

Purpose:

To make a decision regarding program flow based on the result returned by an expression.

Syntax:

IF condition THEN
statement(s) 1
[ELSE
 statement(s) 2
]

END IF

Comments:

If the result of condition (only one condition can be specified) is nonzero (logical true), statement(s) 1 is executed.

If the result of condition is zero (false), the statement(s) 1 is ignored and the statement(s) 2, if present, is executed. Otherwise, execution continues with the next executable statement.

THEN and ELSE may be followed by one or more statements to be executed.

Examples 1:

The next statement causes the LED of key A to be displayed, depending on the value of register RO. If RO is zero, goes to the line 2; otherwise, goes to the terminal.

```
IF R0 = 0 THEN
    PRINT "A",255
END IF
```

Examples 2:

```
IF R0 >= 0 THEN
    PRINT "A",255
ELSE
    PRINT "B",255
END IF
```

7.GOTO Statement

Purpose:

Goto statement is used for altering the normal sequence of program execution by transferring control to some other part of the program.

Syntax:

GOTO label

. . .

label:

statement(s)

Comments:

Label is an identifier. When, the control of program reaches to goto statement, the control of the program will jump to the label: and executes the code after it.

Examples:

Reset:

```
IF R0 < 10 THEN
    R0 = R0 + 1
    GOTO Reset
END IF</pre>
```

8. WAIT Statement

Purpose:

To suspend program execution.

Syntax:

WAIT <Integer>/Rm

Comments:

Wait for <Integer> or Rm millisecond. The range of <Integer> is 0 to 9999.

Examples:

WAIT 1000

'Wait for 1000 milliseconds.

R0 = 500

WAIT RO

'Wait for 500 milliseconds.