



Office Information (for the requirements of EU Energy Efficiency Regulation (EU2019/1782))

Office Name	main office	commercial registration number	address
Roland Europe Group Itd.	UK	08904664	Hive 2 1530, Arlington Business Park, Theale, Reading, RG7 4SA Berkshire, United Kingdom
Roland Germany GmbH.	Germany	HRB91478	Eisenstrasse 2-4 ,65428 Rüsselsheim, Germany
Electronic Musical Instruments Roland Scandinavia A/S	Denmark	64241419	Tuborg Boulevard 12, 2900 Hellerup, Denmark
Roland Central Europe N.V.	Belgium	0422.585.547	Klaus-Michael Kuehnelaan 13, 2440 Geel, Belgium
Roland Central Europe France S.A.R.L.	France	478267727	4 rue Paul-Henry Spaak Parc de l'esplanade, Saint-Thibault-des-Vignes Cdx, ST THIBAULT DES VIGNES, France
Roland South Europe S.p.A.	Itary	8219930156	Via Rossini, 1/a 20020 Lainate, Milano, Italy
Roland Iberia. S.L.	Spain	375899	Ronda General Mitre, 126 entlo, 08021, Barcelona, Spain
Roland East Europe Ltd.	Hungary	13-09-060895	FSD Park 3. ép., 2045 Törökbálint, Hungary

AC Adaptor Information

Model Identifier	AC Adaptor Manufacture's name	Input Voltage	Input AC Frequency	Output Voltage	Output Current	Output Power	Average Active efficiency	Efficiency at Low Load (10%)	No-load Power Consumption
PSA-230S	Shenzhen Huntkey Power Technology Co., Ltd.	AC100V - AC240V	50Hz/60Hz	DC9.0V	0.5A	4.5W	78.25%	67.35%	0.065W
PSB-1U	Shenzhen Huntkey Power Technology Co., Ltd.	AC100V - AC240V	50Hz/60Hz	DC9.0V	2.0A	18W	85.95%	81.94%	0.0715W
PSB-7U	Shenzhen Huntkey Power Technology Co., Ltd.	AC100V - AC240V	50Hz/60Hz	DC12.0V	4.0A	48W	89.01%	88.05%	0.059W
PSB-14U	Shenzhen Huntkey Power Technology Co., Ltd.	AC100V - AC240V	50Hz/60Hz	DC24.0V	3.75A	90W	89.18%	87.00%	0.2W
PSB-5U	UNIFIVE TECHNOLOGY CO., LTD.	AC100V - AC240V	50Hz/60Hz	DC12.0V	1.5A	18W	85.63%	79.54%	0.078W
PSB-12U	UNIFIVE TECHNOLOGY CO., LTD.	AC100V - AC240V	50Hz/60Hz	DC13.0V	4.0A	52W	89.85%	83.05%	0.115W
PSB-13U	UNIFIVE TECHNOLOGY CO., LTD.	AC100V - AC240V	50Hz/60Hz	DC13.0V	4.0A	52W	89.85%	83.05%	0.115W
PSD-230	UNIFIVE TECHNOLOGY CO., LTD.	AC100V - AC240V	50Hz/60Hz	DC5.7V	2.0A	11.4W	80.13%	76.48%	0.077W
UNE312-5920	UNIFIVE TECHNOLOGY CO., LTD.	AC100V - AC240V	50Hz/60Hz	DC5.9V	2.0A	11.8W	81.57%	75.13%	0.051W
FJ-SW1202000N	Shenzhen Fujia Appliance Co., Ltd.	AC100V - AC240V	50Hz/60Hz	DC12.0V	2.0A	24.0W	89.23%	77.74%	0.09W
ATS018T-W050V	Adapter Technology Co., Ltd.	AC100V - AC240V	50Hz/60Hz	DC5.0V	3.0A	15.0W	81.57%	78.74%	0.068W

Correspondence table between AC adaptor and products

	Products	Brand	AC Adaptor	Remarks
Α	A-300PRO-R	Roland	PSB-1U	Sold separately
	A-500PRO-R	Roland	PSB-1U	Sold separately
	A-800PRO-R	Roland	PSB-1U	Sold separately
	A-88MK2	Roland	PSB-1U	Sold separately
	AC-3	BOSS	PSA-230S	Sold separately
	AC-33	Roland	PSB-12U	
	AC-40	Roland	PSB-12U	
	AD-10	BOSS	PSA-230S	
	AD-2	BOSS	PSA-230S	Sold separately
	Aerophone (AE-10)	Roland	PSD-230	
	Aerophone Pro (AE-30)	Roland	PSD-230	
	AR-200R	Roland	PSB-1U	
	AT-350C	Roland	PSB-1U	
	AW-3	BOSS	PSA-230S	Sold separately
	AX-EDGE	Roland	PSB-1U	
В	BA-330	Roland	PSB-13U	
	BB-1X	BOSS	PSA-230S	Sold separately
	BC-1X	BOSS	PSA-230S	Sold separately
	BCB-90X	BOSS	PSB-1U	
	BD-2	BOSS	PSA-230S	Sold separately
	BD-2W	BOSS	PSA-230S	Sold separately
	BF-3	BOSS	PSA-230S	Sold separately
	BK-3	Roland	PSB-1U	
	BK-5	Roland	PSB-7U	
	BR-80	BOSS	PSA-230S	Sold separately
	BR-800	BOSS	PSA-230S	
С	C-30	Roland	PSB-7U	
	CD-2U	Roland	PSB-1U	
	CE-2W	BOSS	PSA-230S	Sold separately
	CE-5	BOSS	PSA-230S	Sold separately
	CEB-3	BOSS	PSA-230S	Sold separately
	CH-1	BOSS	PSA-230S	Sold separately
	CP-1X	BOSS	PSA-230S	Sold separately
	CS-3	BOSS	PSA-230S	Sold separately
	CUBE-10GX	Roland	PSD-230	
	CUBE-LM-WH	Roland	PSD-230	
	CUBE-LT-BK	Roland	PSD-230	
	CUBE-ST2	BOSS	PSB-1U	
	CUBE-STA	Roland	PSB-1U	•
	CUBE-STEX	Roland	PSB-12U	
	CUBE-STEXR	Roland	PSB-12U	

D				
	CUBE-ST-RA	Roland	PSB-1U	
	DB-90	BOSS	PSA-230S	Sold separately
- 1				
I	DC-2W	BOSS	PSA-230S	Sold separately
	DD-200	BOSS	PSA-230S	Sold separately
ı	DD-3T	BOSS	PSA-230S	Sold separately
ŀ				
L	DD-500	BOSS	PSA-230S	Sold separately
	DD-8	BOSS	PSA-230S	Sold separately
ı	DJ-505		PSB-1U	
- 1		Roland		
L	DJ-707M	Roland	PSB-1U	
	DJ-808	Roland	PSB-1U	
	DM-2W	BOSS	PSA-230S	Sold separately
- 1		BO22		Solu separately
	DP603/603A	Roland	PSB-14U	
ſ	DR-01S	BOSS	PSB-1U	
ŀ				Sold separately
Į.	DS-1	BOSS	PSA-230S	
	DS-1X	BOSS	PSA-230S	Sold separately
ı	DS-2	BOSS	PSA-230S	Sold separately
- 1				, , , , , , , , ,
	E-09	Roland	PSB-1U	
	E-A7	Roland	PSB-7U	
Ī	EC-10	Roland	PSD-230	
- 1				
ı	EC-10M	Roland	PSD-230	
	EQ-200	BOSS	PSA-230S	Sold separately
ı	ES-5	BOSS	PSA-230S	
ŀ				
Į	ES-8	BOSS	PSA-230S	
ſ	EV-1-WL	BOSS	PSA-230S	Sold separately
- 1	F-140R	Roland	PSB-7U	
- 1				
	F701	Roland	PSB-7U	
ſ	FA-06	Roland	PSB-1U	
	FA-06B	Roland	PSB-1U	
ļ				
	FA-07	Roland	PSB-1U	
ı	FA-08	Roland	PSB-1U	
ŀ	FC-300	Roland	PSA-230S	Sold separately
ļ			PSA-2305	Solu separately
	FP-10	Roland	PSB-5U	<u> </u>
ı	FP-30	Roland	PSB-7U	
	FP-30X			<u> </u>
Į.	FP-30X	Roland	PSB-7U	
	FP-60	Roland	PSB-7U	
ı	FP-60X	Roland	PSB-7U	
ŀ				
Į	FP-90	Roland	PSB-14U	
	FP-90X	Roland	PSB-14U	
ŀ	FR-1X	Roland	PSB-1U	
ŀ				
L	FR-1XB	Roland	PSB-1U	
	FR-3X	Roland	PSB-7U	
ŀ	FR-3XB	Roland	PSB-7U	
ŀ				
L	FR-4X	Roland	PSB-7U	
	FR-4XB	Roland	PSB-7U	
ı	FR-8X	Roland	PSB-14U	
ŀ				
L	FR-8XB	Roland	PSB-14U	
	FZ-1W	BOSS	PSA-230S	Sold separately
ı	FZ-5	BOSS	PSA-230S	Sold separately
_				
G	GE-7	BOSS	PSA-230S	Sold separately
	GEB-7	BOSS	PSA-230S	Sold separately
	GO-61K	Roland	UNE312-5920	
	GO-61K	Roland		UK only
			UNE312-5920	UK only
	GO-61K GO-61P	Roland Roland	UNE312-5920 PSD-230 UNE312-5920	
	GO-61P	Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230	UK only
	GO-61P GO-88P	Roland Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N	
	GO-61P	Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230	
	GO-61P GO-88P GP-10	Roland Roland BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S	
	GO-61P GO-88P GP-10 GP607	Roland Roland BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U	
	GO-61P GO-88P GP-10 GP607 GP609	Roland Roland BOSS Roland Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U	
	GO-61P GO-88P GP-10 GP607	Roland Roland BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U	
	GO-61P GO-88P GP-10 GP607 GP609 GR-55	Roland Roland BOSS Roland Roland Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U	UK only
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1	Roland Roland BOSS Roland Roland Roland Roland BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U PSA-230S	
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001	Roland Roland BOSS Roland Roland Roland BOSS BOSS BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U PSA-230S PSA-230S	UK only Sold separately
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1	Roland Roland BOSS Roland Roland Roland Roland BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U PSA-230S	UK only
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S	UK only Sold separately
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S	UK only Sold separately
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1	Roland Roland BOSS Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSD-230 PSA-230S PSB-14U PSB-14U PSB-11U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U	UK only Sold separately
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S	UK only Sold separately
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1	Roland Roland BOSS Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSD-230 PSA-230S PSB-14U PSB-14U PSB-11U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U	UK only Sold separately
	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100 GT-1000 GT-1000 GT-1000CORE GT-1B	Roland Roland BOSS Roland Roland Roland Roland BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSA-30S PSA-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U	UK only Sold separately Sold separately Sold separately
н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100 GT-1000 GT-1000CORE GT-1B HM-2W	Roland Roland BOSS Roland Roland Roland Roland BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSB-1U PSB-30S PSA-230S	UK only Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100 GT-1000 GT-1000 GT-1000CORE GT-1B	Roland Roland BOSS Roland Roland Roland Roland BOSS	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSA-30S PSA-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U	UK only Sold separately Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100 GT-1000 GT-1000CORE GT-1B HM-2W HP601	Roland Roland BOSS Roland Roland Roland Roland BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSB-1U PSB-230S PSB-7U	UK only Sold separately Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100 GT-1000 GT-1000CORE GT-1B HM-2W HP601 HP603/603A	Roland Roland BOSS Roland Roland Roland Roland BOSS Roland Roland Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSD-230 PSB-14U PSB-14U PSB-14U PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U	UK only Sold separately Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-1000 GT-11 HP601 HP603/603A HP605	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland Roland Roland Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSB-14U PSB-14U PSB-14U PSB-15 PSA-230S PSA-230S PSA-230S PSB-10	UK only Sold separately Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100 GT-1000 GT-1000CORE GT-1B HM-2W HP601 HP603/603A	Roland Roland BOSS Roland Roland Roland Roland BOSS Roland Roland Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSD-230 PSB-14U PSB-14U PSB-14U PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U	UK only Sold separately Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-1000 GT-11 HP601 HP603/603A HP605	Roland Roland BOSS Roland Roland Roland BOSS BO	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSA-230S PSA-230S PSA-230S PSB-1U	UK only Sold separately Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1000 GT-1000 GT-11B HM-2W HP601 HP603/603A HP605 HP702 HP704	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland Roland Roland Roland Roland Roland Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-1U PSA-230S PSA-230S PSB-1U	UK only Sold separately Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1000 GT-1000 GT-1000 GT-1000 GT-1B HM-2W HP601 HP603/603A HP702 HP704 HP150E	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSB-1U	UK only Sold separately Sold separately Sold separately
Н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1000 GT-1000 GT-11B HM-2W HP601 HP603/603A HP605 HP702 HP704	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland Roland Roland Roland Roland Roland Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-1U PSA-230S PSA-230S PSB-1U	UK only Sold separately Sold separately Sold separately
H	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100 GT-1000 GT-1000CORE GT-18 HM-2W HP601 HP603/603A HP605 HP702 HP704 HPI50E HPD-20	Roland Roland BOSS Roland Roland Roland Roland BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-10 PSB-1U	UK only Sold separately Sold separately Sold separately
H	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-1000 GT-1000 GT-1000 GT-18 HM-2W HP601 HP603/603A HP605 HP702 HP704 HPI50E HPD-20 HS-5	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSB-14U PSB-14U PSB-14U PSB-14U PSB-15 PSA-230S PSA-230S PSA-230S PSB-17 PSB-17 PSB-18 PSB-18 PSB-19	UK only Sold separately Sold separately Sold separately
H	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1 GT-100 GT-1000 GT-1000CORE GT-18 HM-2W HP601 HP603/603A HP605 HP702 HP704 HPI50E HPD-20	Roland Roland BOSS Roland Roland Roland Roland BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-10 PSB-1U	UK only Sold separately Sold separately Sold separately
H	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-1000 GT-1000 GT-1000 GT-18 HM-2W HP601 HP603/603A HP605 HP702 HP704 HPI50E HPD-20 HS-5	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSB-14U PSB-14U PSB-14U PSB-14U PSB-1U PSB-10	UK only Sold separately Sold separately Sold separately
н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-100 GT-1100 GT-1000 GT-18 HM-2W HP601 HP603/603A HP605 HP702 HP704 HPISOE HPD-20 HS-5 HT-TX01 HT-RX01	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-14U PSB-15	UK only Sold separately Sold separately Sold separately
H	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-1000 GT-10	Roland Roland BOSS Roland Roland Roland Roland BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSB-15 PSA-230S PSB-10 PSB-110	Sold separately Sold separately Sold separately Sold separately
н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-100 GT-1100 GT-1000 GT-18 HM-2W HP601 HP603/603A HP605 HP702 HP704 HPISOE HPD-20 HS-5 HT-TX01 HT-RX01	Roland Roland BOSS Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-14U PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-14U PSB-15	UK only Sold separately Sold separately Sold separately
н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-1000 GT-10	Roland Roland BOSS Roland Roland Roland Roland BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 FJ-SW1202000N PSA-230S PSB-14U PSB-1U PSA-230S PSA-230S PSB-1U PSB-230S	Sold separately Sold separately Sold separately Sold separately
н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-100 GT-1000 GT-10	Roland Roland BOSS Roland Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSB-14U PSB-14U PSB-14U PSB-15 PSA-230S PSA-230S PSB-10 PSB-10 PSB-110 PSB-110 PSB-110 PSB-140 PSB	Sold separately Sold separately Sold separately Sold separately
H	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-100 GT-100 GT-1000 GT-10	Roland Roland BOSS Roland Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSB-120 PSB-14U PSB-14U PSB-14U PSB-15 PSB-10 PSB-110 PS	Sold separately Sold separately Sold separately Sold separately
н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-001 GT-1000 GT-1000 GT-1000 GT-18 HM-2W HP601 HP603/603A HP605 HP702 HP704 HPF05 HP704 HPF05 HPT-1X01 HT-RX01 HR-2X01 HR-2X01 JB-2 JD-XA JD-XI JS-10	Roland Roland BOSS Roland Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSD-230 PSB-14U PSB-14U PSB-14U PSB-15 PSA-230S PSB-10 PSB-10 PSB-10 PSB-10 PSB-11 PSB-10 PSB-11 PSB-12 PSB-12 PSB-230 PSB-71	Sold separately Sold separately Sold separately Sold separately
н	GO-61P GO-88P GP-10 GP607 GP609 GR-55 GS-1 GT-100 GT-100 GT-1000 GT-10	Roland Roland BOSS Roland Roland Roland Roland Roland BOSS BOSS BOSS BOSS BOSS BOSS BOSS Roland	UNE312-5920 PSD-230 UNE312-5920 PSD-230 UNE312-5920 PSD-230 PSD-230 PSB-120 PSB-14U PSB-14U PSB-14U PSB-15 PSB-10 PSB-110 PS	Sold separately Sold separately Sold separately Sold separately

JUNN-CSB8	١,				
K SC220 Roberted PSB-12U FSB-12U FSB-14U			Roland	PSB-1U	
KF-10 Roland PSB-14U FXTN-AIR BOSS PSB-12U Sold separately KTN-AIR BOSS PSB-12U Sold separately LMR-3 BOSS PSB-12U Sold separately PSB-14U LMR-3 BOSS PSB-22US Sold separately PSB-14U LMR-3 BOSS PSB-22US Sold separately PSB-14U LX-75 Roland PSB-14U LX-76 Roland PSB-14U Sold separately PSB-20 ROLAND ROLA	-		Roland	PSB-5U	
KTN-AIRI BOSS PSB-12U Sold separately L MB-3 BOSS PSB-12U Sold separately L S-2 BOSS PSB-230S Sold separately L X-17 Roland PSB-14U X-77 Roland PSB-14U LX706 Roland PSB-14U X-7006 Roland PSB-14U LX708 Roland PSB-14U X-7006 Roland PSB-14U LX708 Roland PSB-14U X-7006 Roland PSB-14U MC-2001 Roland PSB-14U Sold separately MC-277 Roland PSB-11U Sold separately MC-28 BOSS PSB-11U Sold separately MD-200 BOSS PSB-11U Sold separately MD-200 BOSS PSB-11U Sold separately M-2 BOSS PSB-20S Sold separately M-2 BOSS PSB-20S Sold separately M-2 BOSS PSB-20S Sold separately MC-2	K	KC-220	Roland	PSB-12U	
KTN-MIMIN	Ī	KF-10	Roland	PSB-14U	
LIMB-3	Ī	KTN-AIR	BOSS	PSB-12U	
LIMB-3	Ī	KTN-MINI	BOSS	PSB-1U	Sold separately
LS-2					Sold separately
Le-17	ī	LS-2			Sold separately
LX-7	-				
LX706 Roland PSB-14U LX708 Roland PSB-14U LX708 Roland PSB-14U RSB-14U LX708 Roland PSB-14U RSB-14U RSB-14	-				
LX706 Roland PSB-14U LX706 Roland PSB-14U MM-2001 Roland PSB-14U Sold separately MM-2001 Roland PSB-14U Sold separately MM-2001 Roland PSB-14U Sold separately MM-2001 Roland PSB-12U Sold separately MM-2001 ROLAND ROLAND PSB-12U Sold separately MM-2001 ROLAND					
LC708 Roland PSB-14U MM-2008 Roland PSB-14U MM-2008 Roland PSB-11U Sold separately MC-707 Roland PSB-11U Sold separately Roland PSB-11U Roland PSB-12U Roland PSB-12	_				
M MS-2001 Roband PSB-14U Sold separately MB-CUBE Roland PSD-230 Sold separately MC-707 Roland PSD-230 Sold separately MC-208 Roland PSB-11U Sold separately MC-209 BOSS PSB-11U Sold separately MD-200 BOSS PSB-11U Sold separately MD-200 BOSS PSB-11U Sold separately MD-200 BOSS PSB-11U Sold separately MD-201 BOSS PSB-230S Sold separately MD-202 BOSS PSA-230S Sold separately MC-2 BOSS PSA-230S Sold separately MC-2 BOSS PSA-230S Sold separately MC-2 BOSS PSA-230S Sold separately MS-3 BOSS PSA-230S Sold separately MS-3 BOSS PSA-230S Sold separately MT-2 BOSS PSA-230S Sold separately MT-2 BOSS PS	- 12				
MB-CUBE	-		Roland		
MC-POT	-		Roland	PSB-14U	
MC-ERX Roland PSB-1U M-CUBE GX Roland PSB-20 M-CUBE GX Roland PSB-1U Sold separately MD-20 BOSS PSB-1U Sold separately MD-200 BOSS PSB-1U Sold separately MD-200 BOSS PSB-1U Sold separately MC-20 BOSS PSA-230S Sold separately BOS	1	MB-CUBE	Roland	PSB-1U	Sold separately
MC-LUBE GX	I	MC-707	Roland	PSD-230	
MD-2	1	MCB-RX	Roland	PSB-1U	
MD-200	Ī	M-CUBE GX	Roland	PSD-230	
MD-500 SOSS PSR-200S Sold separately ME-80 BOSS PSA-230S Sold separately MD-2 BOSS PSA-230S Sold separately MO2 BOSS PSA-230S Sold separately MOBILE-AC Roband PSB-1U Sold separately MOBILE-BA Roband PSB-1U Sold separately MS-3 BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MT-1W BOSS PSA-230S Sold separately MY-1 Roband PSB-1U MV-1 MY-1 Roband PSD-230 Sold separately MY-1 Roband PSD-230 Sold separately MY-1 Roband PSD-230 Sold separately OC-3 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OD-1X BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S	ı	MD-2	BOSS	PSB-1U	Sold separately
MD-500 BOSS PSA-230S Sold separately ME-60 BOSS PSA-230S Sold separately MC-2 BOSS PSA-230S Sold separately MO-2 BOSS PSA-230S Sold separately MOBILE-AC Roland PSB-1U Sold separately MCRILE-BA Roland PSB-1U Sold separately MS-3 BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MT-1W BOSS PSA-230S Sold separately MY-1 Roland PSD-230 MMX-1 Roland PSD-230 MX-1 Roland PSD-230 Sold separately N S-2 BOSS PSA-230S Sold separately OC-3 BOSS PSA-230S Sold separately OC-3 BOSS PSA-230S Sold separately OD-20 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-3	Ī	MD-200	BOSS	PSB-1U	Sold separately
ME-80 BOSS	-				Sold separately
Mil2 BOSS PSA-230S Sold separately MO-2 BOSS PSA-230S Sold separately MOBILE-AC Roland PSB-1U Sold separately MOBILE-BA Roland PSB-1U Sold separately MS-3 BOSS PSA-230S Sold separately MT-2 BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MV-1 Roland PSD-230 MV-1 MV-1 Roland PSD-230 MV-1 MX-1 Roland PSD-230 Sold separately OC-3 BOSS PSA-230S Sold separately OC-3 BOSS PSA-230S Sold separately OD-20 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold	-				
MO-2 BOSS PSA-230S Sold separately MOBILE-BA Roland PSB-11U Sold separately MS-3 BOSS PSA-230S Sold separately MS-3 BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MT-90U Roland PSB-1U MW-1 MV-1 Roland PSD-230 MX-1 MX-1 Roland PSD-230 MX-1 NS-2 BOSS PSA-230S Sold separately OC-3 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OD-1X BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately PB-3 BOSS PSA-230S Sold separately	-				
MOBILE-AC Roland PSB-1U Sold separately MOBILE-BA Roland PSB-1U Sold separately M8-3 BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MT-W BOSS PSA-230S Sold separately MT-90U Roland PSD-230 MM-1 Roland PSD-230 MV-1 Roland PSD-230 Sold separately MV-1 Roland PSD-230 Sold separately OC-2 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OD-20 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately PP-20HD Roland PSB-7U Sold separately PP-3 BOSS PSA-230S Sold separately PS-6	-				
MOBILE-BIA Roland PSB-1U Sold separately MS-3 BOSS PSA-230S Sold separately MT-2 BOSS PSA-230S Sold separately MT-90U Roland PSB-1U MW-1 Roland PSD-230 MX-1 Roland PSD-230 MM-1 Roland PSD-230 MX-1 Roland PSD-230 Sold separately OC-3 BOSS PSA-230S Sold separately OC-3 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OD-1X BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately PS-3 BOSS PSA-230S Sold separately <	-				. ,
MS-3 BOSS PSA-230S Sold separately MT-2W BOSS PSA-230S Sold separately MT-90U Roland PSB-1U MV-1 Roland PSB-230 MX-1 Roland PSB-230 MX-1 Roland PSB-230 MX-1 Roland PSB-230 MX-1 Roland PSB-230 N NS-2 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OC-6 BOSS PSA-230S Sold separately OC-6 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-6 BOSS PSA-230S Sold separately OD-7 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately PR-3 BOSS PSA-230S Sold separately PR-3 BOSS PSA-230S Sold separately PR-3 BOSS PSA-230S Sold separately PR-4 BOSS PSA-230S Sold separately RC-6 BOSS PSA-230S Sold separately RC-1 BOSS PSA-230S Sold separately RC-20 BOSS PSA-230S Sold separately RC-3 BOSS PSA-230S Sold separately RC-30 BOSS	-				. ,
MT-2	-				Sold separately
MT-2W BOSS PSA-230S Sold separately MT-90U Roland PSB-1U MV-1 Roland PSD-230 MX-1 Roland PSD-230 MX-1 Roland PSD-230 N NS-2 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OC-6 BOSS PSA-230S Sold separately OD-1X BOSS PSA-230S Sold separately OD-200 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately PS-2DHD Roland PSB-7U PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RC-1 BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-3 BOSS PSA-230S Sold separately RC-3 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-50D BOSS PSA-230S Sold separa					
MT-90U Roland PSB-1U MV-1 Roland PSD-230 MX-1 Roland PSD-230 MX-1 Roland PSD-230 MX-1 Roland PSD-230 MX-1 Roland PSD-230 Sold separately PSD-230 MX-1 Roland PSB-230S Sold separately PSD-230 MX-1 Roland PSB-1 Roland PSB-230S Sold separately RR-1 Roland PSB-230S Sold separately RR-2 Roland PSB-230S Sold separately RR-3 Roland PSB-3 Rol	_				
MV-1 Roland PSD-230 MX-1 Roland PSD-230 MX-2 BOSS PSA-230S Sold separately O CC-3 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OD-11X BOSS PSA-230S Sold separately OD-200 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OB-3 BOSS PSA-230S Sold separately OB-2 BOSS PSA-230S Sold separately PH-3 BOSS PSA-230S Sold separately PH-3 BOSS PSA-230S Sold separately PH-3 BOSS PSA-230S Sold separately PP-6 BOSS PSA-230S Sold separately PP-8-8 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately <tr< td=""><td>Ľ</td><td> =</td><td>BOSS</td><td>PSA-230S</td><td>Sold separately</td></tr<>	Ľ	=	BOSS	PSA-230S	Sold separately
MX-1 Roland PSD-230 NNS-2 BOSS PSA-230S Sold separately OC-3 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OD-1X BOSS PSA-230S Sold separately OD-20 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately ODB-3 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately PP-20HD Roland PSB-7U PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately PS-8-8 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately PS-8-230S Sold separately RC-10R BOSS PSA-230S Sold separately PSA-230S Sold separat	ı	MT-90U	Roland	PSB-1U	
N NS-2 BOSS PSA-230S Sold separately O OC-3 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OC-1X BOSS PSA-230S Sold separately OD-200 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately PS-20DD RDB BOSS PSA-230S Sold separately PP-20HD Roband PSB-71 PSB-71 PSB-6 BOSS PSA-230S Sold separately PP-3 BOSS PSA-230S Sold separately PSB-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RC-10 BOSS PSA-230S Sold separately RC-10 BOSS PSA-230S	Ī	MV-1	Roland	PSD-230	
N NS-2 BOSS PSA-230S Sold separately O OC-3 BOSS PSA-230S Sold separately OC-5 BOSS PSA-230S Sold separately OD-1X BOSS PSA-230S Sold separately OD-200 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately OB-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PH-3 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-10R BOS	ī	MX-1			
0 OC-3 BOSS PSA-230S Sold separately 0 C-5 BOSS PSA-230S Sold separately 0 D-1X BOSS PSA-230S Sold separately 0 D-200 BOSS PSA-230S Sold separately 0 D-3 BOSS PSA-230S Sold separately 0 D-3 BOSS PSA-230S Sold separately 0 D-2 BOSS PSA-230S Sold separately 0 S-2 BOSS PSA-230S Sold separately PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230	N	NS-2			Sold separately
OC-5 BOSS PSA-230S Sold separately OD-1X BOSS PSA-230S Sold separately OD-200 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately ODB-3 BOSS PSA-230S Sold separately ODB-3 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately PP-20HD Roland PSB-7U PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately	o	OC-3			Sold separately
OD-1X BOSS PSA-230S Sold separately OD-200 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately ODB-3 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately PP-20HD Roland PSB-7U PPS-7U PH-3 BOSS PSA-230S Sold separately PP-6 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RC-1 BOSS PSA-230S Sold separately RC-1 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-5 BOSS PSA-230S <t< td=""><td>-</td><td></td><td></td><td></td><td></td></t<>	-				
OD-200 BOSS PSA-230S Sold separately OD-3 BOSS PSA-230S Sold separately ODB-3 BOSS PSA-230S Sold separately OB-2 BOSS PSA-230S Sold separately PP-20HD Roland PSB-7U PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separatel					
OD-3 BOSS PSA-230S Sold separately ODB-3 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RC-1 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-3 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-5 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S	-				
ODB-3 BOSS PSA-230S Sold separately OS-2 BOSS PSA-230S Sold separately P P-20HD Roland PSB-7U PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RC-1 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB	-				
OS-2 BOSS PSA-230S Sold separately P P.20HD Roland PSB-7U PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately R R-8B Roland PSB-1U RC-10R RC-10R BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-505MK2 BOSS PSB-1U	-				
P P-20HD Roland PSB-7U PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately RV-3 BOSS PSA-230S Sold separately RC-1 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-3 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RE-20 BOSS PSA-230S Sold separately RPSB-1U RPSB-1U R	-				
PH-3 BOSS PSA-230S Sold separately PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately R R88 Roland PSB-1U RC-10R BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-506 BOSS PSB-1U RC-50B-1U RC-505 BOSS PSB-1U RC-5	-		BOSS		Sold separately
PS-6 BOSS PSA-230S Sold separately PW-3 BOSS PSA-230S Sold separately R R-88 Roland PSB-1U RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505 BOSS PSB-1U RD-8B-1U RD-8B-8U RC-505MK2 BOSS PSB-1U RD-8B-8U RD-8B-8U RC-506MK2 BOSS PSB-1U RD-8B-8U RR-200 BOSS PSB-1U RD-20 ROland PSB-7U RPSB-7U RPSB-	P	P-20HD	Roland	PSB-7U	
PW-3	ı	PH-3	BOSS	PSA-230S	Sold separately
R R-88 Roland PSB-1U RC-1 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S Sold separately RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-506 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RD-88 Roland PSB-5U RC-20 BOSS PSB-1U RP501 Roland PSB-7U RC-20 ROland PSB-7U RP501R Roland PSB-7U RC-20S ROland PSB-7U RP50	F	PS-6	BOSS	PSA-230S	Sold separately
RC-1 BOSS PSA-230S Sold separately RC-10R BOSS PSA-230S RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-30 RC-300 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 RC-505 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505MIZ BOSS PSB-1U RC-600 RC-600 <td>ı</td> <td>PW-3</td> <td>BOSS</td> <td>PSA-230S</td> <td>Sold separately</td>	ı	PW-3	BOSS	PSA-230S	Sold separately
RC-10R BOSS PSA-230S RC-202 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505MK2 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 RC-600 RC-600 BOSS PSB-1U RC-600	R	R-88	Roland	PSB-1U	
RC-202 BOSS PSA-230S Sold separately RC-3 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505MK2 BOSS PSB-1U RC-505MK2 RC-600 BOSS PSB-1U RC-505MK2 RC-505MK2 RC-600 BOSS PSB-1U RC-505MK2 RC-505	Ī	RC-1	BOSS	PSA-230S	Sold separately
RC-202 BOSS PSA-230S Sold separately RC-3 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505MK2 BOSS PSB-1U RC-505MK2 RC-600 BOSS PSB-1U RC-505MK2 RC-505MK2 RC-600 BOSS PSB-1U RC-505MK2 RC-505	ī	RC-10R	BOSS	PSA-230S	
RC-3 BOSS PSA-230S Sold separately RC-30 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-5 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505MK2 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-5U RC-600 BOSS PSB-5U RC-600 BOSS PSA-230S Sold separately RC-600 RC-600 RC-600 RC-600 RC-600 RC-600 RC-600 RC-600 RC-600 RC-60	-				
RC-30 BOSS PSA-230S Sold separately RC-300 BOSS PSA-230S Sold separately RC-50 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S Sold separately RC-505 BOSS PSB-1U RS-230S RC-505MK2 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 ROSS PSB-5U RC-600 RC-600 ROSS PSB-5U RC-600 RC-600 RC-600 ROSS PSB-1U RC-600 RC-600 <td< td=""><td></td><td></td><td></td><td></td><td>Sold separately</td></td<>					Sold separately
RC-300 BOSS PSA-230S Sold separately RC-5 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSB-1U RC-505MK2 BOSS PSB-1U RC-505MK2 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-5U RC-600 RC-600 BOSS PSB-5U RC-600	_				
RC-5 BOSS PSA-230S Sold separately RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S RC-505MK2 BOSS PSB-1U RC-505MK2 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 RD-88 Roland PSB-5U RC-600 RC-600 <td>Ľ</td> <td></td> <td></td> <td></td> <td>ocia coparatory</td>	Ľ				ocia coparatory
RC-500 BOSS PSA-230S Sold separately RC-505 BOSS PSA-230S RC-505MK2 BOSS PSB-1U RC-600 BOSS PSB-1U RC-600 BOSS PSB-1U RD-88 Roland PSB-5U RE-20 BOSS PSA-230S Sold separately RE-20 BOSS PSA-230S Sold separately RE-20 ROIAND PSB-1U RPSB-1U RPSB-1U RPSB-1U RPSB-1U RPSB-1U RPSB-1U RPSB-1U RPSB-1U RPSB-20S Sold separately RPSB-20S Sold separately RPSB-1U RPSB-20S Sold separately RPSB-20S Sold separately SPSB-1U RPSB-20S Sold separately SPSB-1U SPSB-20S Sold separately SPSB-1U SPSB-1U SPSB-1U SPSB-20S Sold separately SPD-20S Sold separately SPD-20S Sold separately SPD-1E Roland <td>-</td> <td></td> <td></td> <td></td> <td>0-14</td>	-				0-14
RC-505 BOSS PSA-230S RC-505MK2 BOSS PSB-1U RC-600 BOSS PSB-1U RD-88 Roland PSB-5U RE-20 BOSS PSA-230S Sold separately RP102 Roland PSB-1U RPB-1U RP302 Roland PSB-7U RP501R Roland PSB-7U RP701 Roland PSB-7U RP501R RV501R					
RC-505MK2 BOSS PSB-1U RC-600 BOSS PSB-1U RD-88 Roland PSB-5U RE-20 BOSS PSA-230S Sold separately RP102 Roland PSB-1U RPSB-1U RP302 Roland PSB-7U RP501R Roland PSB-7U RP701 Roland PSB-7U RPSB-7U RP701 ROMAND PSB-7U RPSB-7U RPSB-60 RPSB-7U RPSB-60 RPSB-7U RPSB-60 RPSB-7U RPSB-7U RPSB-720S Sold separately SPD-1W RPSB-1U RPSB-1U RPSB-1U RPSB-1U RPSB-1U RPSB-230S Sold separately SPD-1W ROland PSB-1U RPSB-1U RPSB-1U	- 11				
RC-600 BOSS PSB-1U RD-88 Roland PSB-5U RE-20 BOSS PSA-230S Sold separately RP102 Roland PSB-1U RP502 Roland PSB-7U RP501R Roland PSB-7U RP501R RP701 Roland PSB-7U RP701 ROLAND ROLAND RP802 Sold separately RP802 ROLAND ROLAND ROLAND ROLAND RP802 Sold separately RP802 ROLAND ROLAND RP802 Sold separately SP802 Sold separately RP802 ROLAND ROLAND RP802 ROLAND </td <td>- 1-</td> <td>RC-500</td> <td>BOSS</td> <td>PSA-230S</td> <td></td>	- 1-	RC-500	BOSS	PSA-230S	
RD-88 Roland PSB-5U RE-20 BOSS PSA-230S Sold separately RP102 Roland PSB-1U RP302 Roland PSB-7U RP501R Roland PSB-7U RP501R Roland PSB-7U RP501R Roland PSB-7U RP701 ROland PSB-7U RP701 RP701 ROland PSB-7U RP501 RP501 <td< td=""><td></td><td>RC-500 RC-505</td><td>BOSS BOSS</td><td>PSA-230S PSA-230S</td><td></td></td<>		RC-500 RC-505	BOSS BOSS	PSA-230S PSA-230S	
RE-20 BOSS PSA-230S Sold separately RP102 Roland PSB-1U RP302 Roland PSB-7U RP501R Roland PSB-7U RP701 Roland PSB-7U RP701 Roland PSB-7U RP701 Roland PSB-7U RT-MICS Roland PSB-7U RT-MICS Roland PSB-230S Sold separately RV-6 BOSS RV-6 BOSS PSA-230S SD-1 BOSS PSA-230S SD-1 BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SE-02 Roland PSB-1U SP-404MK2 Roland PSB-1U SP-404SX Roland PSB-1U SPD-1E Roland PSB-230S Sold separately SPD-1F SPD-1P Roland PSA-230S SPD-1W Roland PSB-1U SPD-8X Roland PSB-1U	Ī	RC-500 RC-505 RC-505MK2	BOSS BOSS BOSS	PSA-230S PSA-230S PSB-1U	
RP102 Roland PSB-1U RP302 Roland PSB-7U RP501R Roland PSB-7U RP701 Roland PSB-7U RT-MICS Roland PSB-7U RT-MICS Roland PSB-1U RV-MICS Roland PSB-1U RV-500 BOSS PSA-230S Sold separately RV-6 BOSS PSA-230S Sold separately SD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SB-1U SH-01 Roland PSB-1U SP-230 SP-404MK2 Roland PSB-1U SP-230S SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S Sold separately SPD-1E Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-SX <td></td> <td>RC-500 RC-505 RC-505MK2 RC-600</td> <td>BOSS BOSS BOSS</td> <td>PSA-230S PSA-230S PSB-1U PSB-1U</td> <td></td>		RC-500 RC-505 RC-505MK2 RC-600	BOSS BOSS BOSS	PSA-230S PSA-230S PSB-1U PSB-1U	
RP302 Roland PSB-7U RP501R Roland PSB-7U RP701 Roland PSB-7U RT-MICS Roland PSA-230S Sold separately RUBIX44 Roland PSB-1U RV-500 BOSS PSA-230S Sold separately RV-6 BOSS PSA-230S Sold separately SD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SB-1U SH-01 Roland PSB-1U SB-1U SP-404MK2 Roland PSB-1U SB-1U SPD-1E Roland PSA-230S Sold separately SPD-1E Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPS-1U SPD-SX Roland PSB-1U SPS-1U </td <td></td> <td>RC-500 RC-505 RC-505MK2 RC-600</td> <td>BOSS BOSS BOSS BOSS</td> <td>PSA-230S PSA-230S PSB-1U PSB-1U</td> <td>Sold separately</td>		RC-500 RC-505 RC-505MK2 RC-600	BOSS BOSS BOSS BOSS	PSA-230S PSA-230S PSB-1U PSB-1U	Sold separately
RP501R Roland PSB-7U RP701 Roland PSB-7U RT-MICS Roland PSA-230S Sold separately RUBIX44 Roland PSB-1U RV-500 BOSS PSA-230S Sold separately RV-6 BOSS PSA-230S Sold separately Sold separately SD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U Sold separately SH-01 Roland PSB-1U SPB-1U SP-404MK2 Roland PSB-1U SPB-1U SPD-1E Roland PSB-230 Sold separately SPD-1E Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-SX Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-600 RD-88	BOSS BOSS BOSS BOSS Roland BOSS	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U	Sold separately
RP701 Roland PSB-7U RT-MICS Roland PSA-230S Sold separately RUBIX44 Roland PSB-1U RV-500 BOSS PSA-230S Sold separately RV-6 BOSS PSA-230S Sold separately Sold separately SD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SP-404 SH-01 Roland PSB-1U SP-404MK2 Roland PSB-1U SP-404SX Roland PSB-1U SPB-1U SPD-1E Roland PSB-230 Sold separately SPD-1E Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U SPD-SX SE Roland PSB-1U S		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20	BOSS BOSS BOSS BOSS Roland BOSS	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S	Sold separately
RP701 Roland PSB-7U RT-MICS Roland PSA-230S Sold separately RUBIX44 Roland PSB-1U RV-500 BOSS PSA-230S Sold separately RV-60 BOSS PSA-230S Sold separately Sold separately SD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SP-404S SH-01 Roland PSB-1U SP-404MK2 Roland PSB-1U SP-404SX Roland PSB-1U SPD-1E Roland PSB-1U SPD-1E Roland PSA-230S Sold separately SPD-1F Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U SP-SX SE Roland PSB-23		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20	BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U	Sold separately
RT-MICS Roland PSA-230S Sold separately RUBIX44 Roland PSB-1U RV-500 BOSS PSA-230S Sold separately RV-6 BOSS PSA-230S Sold separately S SD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U Sold separately SH-01 Roland PSB-1U SP-230 SP-404MK2 Roland PSB-1U SPD-230 SP-404SX Roland PSB-1U SPD-1E SPD-1E Roland PSA-230S Sold separately SPD-1K Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX Roland PSB-1U SPS-230S Sold separately SY-1 <td< td=""><td></td><td>RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302</td><td>BOSS BOSS BOSS Roland BOSS Roland Roland</td><td>PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U</td><td>Sold separately</td></td<>		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302	BOSS BOSS BOSS Roland BOSS Roland Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U	Sold separately
RUBIX44 Roland PSB-1U RV-500 BOSS PSA-230S Sold separately RV-6 BOSS PSA-230S Sold separately S D-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SH-01 Roland PSB-1U SP-404MK2 Roland PSB-1U SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S Sold separately SPD-1K Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX SPD-SX Roland PSB-1U SPD-SX SPD-SX SE Roland PSB-1U SPS-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R	BOSS BOSS BOSS Roland BOSS Roland Roland Roland Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U	Sold separately
RV-500 BOSS PSA-230S Sold separately RV-6 BOSS PSA-230S Sold separately SD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U Sold separately SH-01 Roland PSB-1U SPS-1U SP-404MK2 Roland PSD-230 Sold separately SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S Sold separately SPD-1E Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSB-1U SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U SPD-SX SE Roland PSB-1U SPD-SX SE Roland PSB-1U SPS-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1<		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701	BOSS BOSS BOSS Roland BOSS Roland BOSS Roland Roland Roland Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U	Sold separately Sold separately
RV-6 BOSS PSA-230S Sold separately SD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SH-01 Roland PSB-1U SP-404MK2 Roland PSB-1U SP-404SX Roland PSB-1U SP-1E Roland PSA-230S Sold separately SPD-1E Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-1W Roland PSB-1U SPD-30 Roland PSB-1U SPD-3X Roland PSB-1U SPB-1U SPD-3X Roland PSB-1U SPD-SX SE Roland PSB-1U SPB-1U SP-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SPS-1U SY-200 BOSS PSA-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS	BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSB-7U PSB-7U PSA-230S	Sold separately Sold separately
S DD-1 BOSS PSA-230S Sold separately SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SH-01 Roland PSB-1U SP-404MK2 Roland PSD-230 SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S Sold separately SPD-1E Roland PSA-230S Sold separately SPD-1R Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSB-1U SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPB-1U SPB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44	BOSS BOSS BOSS Roland BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSB-7U PSB-7U PSB-7U PSB-7U	Sold separately Sold separately Sold separately
SD-1W BOSS PSA-230S Sold separately SE-02 Roland PSB-1U SH-01 Roland PSB-1U SP-404MK2 Roland PSB-1U SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S SPD-1K Roland PSA-230S SPD-1K Roland PSA-230S SPD-1P Roland PSA-230S SPD-1W Roland PSA-230S SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U SP-SX SE Roland PSB-1U SY-1 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RF701 RT-MICS RUBIX44 RV-500	BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S	Sold separately Sold separately Sold separately Sold separately
SE-02 Roland PSB-1U SH-01 Roland PSB-1U SP-404MK2 Roland PSD-230 SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S SPD-1K Roland PSA-230S SPD-1P Roland PSA-230S SPD-1P Roland PSA-230S SPD-1W Roland PSA-230S SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U SP-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RF7-MICS RUBIX44 RV-500 RV-6	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSB-1U PSA-230S	Sold separately Sold separately Sold separately Sold separately Sold separately Sold separately
SH-01 Roland PSB-1U SP-404MK2 Roland PSD-230 SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S Sold separately SPD-1K Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SOLD separately SY-200 BOSS PSA-230S Sold separately	S	RC-500 RC-505 RC-505MK2 RC-600 RC-600 RP-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1	BOSS BOSS BOSS BOSS Roland BOSS Roland Roland Roland Roland Roland Roland Roland Roland Roland BOSS BOSS BOSS BOSS	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSB-1U PSA-230S PSA-230S PSA-230S	Sold separately
SP-404MK2 Roland PSD-230 SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S Sold separately SPD-1K Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPB-1U SPD-SX Roland PSB-1U SPB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SOLD separately SY-200 BOSS PSA-230S Sold separately	S	RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W	BOSS BOSS BOSS BOSS Roland BOSS Roland BOSS BOSS BOSS BOSS BOSS	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S	Sold separately
SP-404SX Roland PSB-1U SPD-1E Roland PSA-230S Sold separately SPD-1K Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately	5	RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02	BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S	Sold separately
SPD-1E Roland PSA-230S Sold separately SPD-1K Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately	S S S S S S S S S S S S S S S S S S S	RC-500 RC-505 RC-505MK2 RC-506MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01	BOSS BOSS BOSS Roland BOSS Roland BOSS BOSS BOSS BOSS Roland Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S	Sold separately
SPD-1K Roland PSA-230S Sold separately SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately	S	RC-500 RC-505 RC-505MK2 RC-600 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSB-5U PSB-7U PSB-7U PSB-7U PSB-7U PSA-230S	Sold separately
SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately	S	RC-500 RC-505 RC-505MK2 RC-600 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSB-5U PSB-7U PSB-7U PSB-7U PSB-7U PSA-230S	Sold separately
SPD-1P Roland PSA-230S Sold separately SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U SP-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately	S	RC-500 RC-505 RC-505MK2 RC-600 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RF7-01 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SP-404MK2 SP-404SX	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSB-5U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSB-1U PSB-1U PSD-230 PSB-1U	Sold separately
SPD-1W Roland PSA-230S Sold separately SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S SY-1 BOSS PSA-230S SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately Sy-200	5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	RC-500 RC-505 RC-505MK2 RC-600 RC-600 RP-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1UV SE-02 SH-01 SP-404MK2 SP-404SX SPD-1E	BOSS BOSS BOSS BOSS Roland BOSS Roland BOSS BOSS BOSS BOSS Roland Roland Roland Roland Roland Roland Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSA-230S PSA-1U PSA-230S PSA-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-230	Sold separately
SPD-30 Roland PSB-1U SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately	S S S S S S S S S S S S S S S S S S S	RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SP-404MK2 SP-404SX SPD-1E SPD-1K	BOSS BOSS BOSS Roland BOSS Roland BOSS BOSS BOSS BOSS Roland Roland Roland Roland Roland Roland Roland Roland	PSA-230S PSA-230S PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSB-1U PSB-1U PSB-1U PSB-1U PSA-230S PSB-1U PSA-230S	Sold separately
SPD-SX Roland PSB-1U SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SP-404MK2 SPP-1E SPD-1K SPD-1F	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSA-230S PSA-230S PSA-230S PSA-1U PSA-230S	Sold separately
SPD-SX SE Roland PSB-1U ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SPP-404MX SPD-1E SPD-1K SPD-1F SPD-1W	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S	Sold separately
ST-2 BOSS PSA-230S Sold separately SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately	S S	RC-500 RC-505 RC-505MK2 RC-505MK2 RC-600 RC-600 RP-102 RP-102 RP-102 RP-101 RP-701 RP-701 RP-701 RP-701 RP-701 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SP-404MK2 SP-404SX SPD-1E SPD-1K SPD-1H SPD-1H SPD-1W SPD-1H SPD-10	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSB-5U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSA-230S PSA-230S PSA-230S PSB-1U PSA-230S PSB-1U PSA-230S PSB-1U PSA-230S	Sold separately
SY-1 BOSS PSA-230S Sold separately SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately	5	RC-500 RC-505 RC-505MK2 RC-505MK2 RC-600 RC-600 RP-102 RP102 RP302 RP501R RP701 RF7-01 RF7-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SD-1W SP-404MK2 SP-404MK2 SP-404SX SPD-1E SPD-1F SPD-1H SPD-1H SPD-1P SPD-1P SPD-30 SPD-30 SPD-SX	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSD-230S PSA-230S PSB-1U	Sold separately
SY-1000 BOSS PSB-1U SY-200 BOSS PSA-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-505MK2 RC-600 RC-600 RP-102 RP-102 RP-102 RP-101 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1U SE-02 SH-01 SP-404MK2 SP-404MX SPD-1E SPD-1K SPD-1H SPD-1H SPD-1H SPD-1H SPD-1P SPD-30 SPD-SX SPD-SX SPD-SX SPD-SX SSPD-SX	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSB-5U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSB-1U PSA-230S PSA-1U PSA-230S PSA-1U PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSD-230 PSB-1U PSB-230S PSA-230S PSB-1U PSB-1U PSB-1U	Sold separately
SY-200 BOSS PSA-230S Sold separately		RC-500 RC-505 RC-505MK2 RC-505MK2 RC-600 RC-600 RP-102 RP-102 RP-102 RP-101 RT-MICS RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SP-404SX SPD-1E SPD-1K SPD-1F SPD-1W SPD-19 SPD-1W SPD-30 SPD-5X SPD-SX SPD-SX SPD-SX SPD-SX SPD-SX	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSB-1U PSA-230S PSA-10 PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSA-230S PSB-1U PSB-1U PSB-1U PSB-230 PSB-1U PSB-30S PSB-30S PSB-30S PSB-30S PSB-30S PSA-30S PSA-30S PSA-30S PSA-30S PSA-30S PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U	Sold separately Sold separately
	S S S S S S S S S S S S S S S S S S S	RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SP-404MK2 SP-404MK2 SP-404MK2 SP-1E SPD-1K SPD-1P SPD-1W SPD-30 SPD-5X SPD-5	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSA-1U PSB-1U PSB-1U PSB-1U PSA-230S PSA-230S PSB-1U PSA-230S PSA-10 PSB-1U PSA-230S PSA-10 PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U	Sold separately Sold separately
07.000	S S S S S S S S S S S S S S S S S S S	RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SP-404MK2 SP-404MK2 SP-404MK2 SP-1E SPD-1K SPD-1P SPD-1W SPD-30 SPD-5X SPD-5	BOSS BOSS BOSS BOSS Roland BOSS Roland	PSA-230S PSA-230S PSB-1U PSB-5U PSA-230S PSB-1U PSB-7U PSB-7U PSB-7U PSA-230S PSA-1U PSB-1U PSB-1U PSB-1U PSA-230S PSA-230S PSB-1U PSA-230S PSA-10 PSB-1U PSA-230S PSA-10 PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U	Sold separately Sold separately
SY-300 BOSS PSA-230S		RC-500 RC-505 RC-505MK2 RC-600 RD-88 RE-20 RP102 RP302 RP501R RP701 RT-MICS RUBIX44 RV-500 RV-6 SD-1 SD-1W SE-02 SH-01 SP-404MK2 SP-404MK2 SPP-1E SPP-1K SPD-1R SPD-1R SPD-1R SPD-1W SPD-1P SPD-1W SPD-30 SPD-SX SPD-SX SPD-SX SPD-SX SPD-SX SE ST-2 SY-1	BOSS BOSS BOSS Roland BOSS Roland ROSS BOSS	PSA-230S PSA-230S PSB-1U PSB-5U PSB-1U PSB-7U PSB-7U PSB-7U PSB-7U PSA-230S PSA-110 PSA-230S PSA-110 PSA-230S PSA-110 PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSA-230S PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-1U PSB-230S PSB-1U PSB-1U PSB-230S PSB-1U PSB-1U PSB-1U PSB-230S PSB-1U	Sold separately Sold separately

SYR-E84 Roland PSB-7U SYS-600CSJ Roland PSB-7U SYSTEM-H Roland PSD-230 SYSTEM-HM Roland PSD-230 SYSTEM-B Roland PSB-5U TAJKO-1 Roland PSB-5U TB-2W BOSS PSA-230S SOID SS PSA-230S TD-07 Roland PSB-5U TD-1 Roland PSB-1U TD-17 Roland PSB-1U TE-2 BOSS PSB-230S Sold separately TE-2 BOSS PSA-230S Sold separately TM-2 Roland PSD-230 Sold separately TM-8 PRO Roland PSD-230 Sold separately TM-8 PRO Roland PSD-230S Sold separate		SYB-5	BOSS	PSA-230S	Sold separately
SYS-500CSJ Roland PSB-7U SYSTEM-11 Roland PSD-230 SYSTEM-M Roland PSB-1U TALKO-1 Roland PSB-5U TALW BOSS PSA-230S Sold separately TB-3 Roland PSB-5U TD-07 Roland PSB-5U TD-17 Roland PSB-1U TD-25 Roland PSB-1U TE-2 BOSS PSA-230S Sold separately TM-1 Roland PSB-1U Sold separately TM-2 Roland PSB-1U Sold separately TM-2 BOSS PSA-230S Sold separately TM-2 ROland PSB-1U Sold separately TM-3 ROSS PSA-230S Sold separately TM-3 BOSS PSA-230S Sold					
SYSTEM-1 Roland PSD-230 SYSTEM-8 Roland PSB-230 TAIKO-1 Roland PSB-1U TRAWO-1 Roland PSB-5U TB-2W BOSS PSA-230S Sold separately TB-3 Roland PSB-230 TD-17 Roland PSB-1U TD-17 Roland PSB-1U TD-17 Roland PSB-1U TD-27 Roland PSB-1U TD-27 Roland PSB-1U TD-27 Roland PSB-1U TD-27 Roland PSB-1U TD-27 Roland PSB-1U TD-27 Roland PSB-1U TM-1 Roland PSB-230S Sold separately TM-1 Roland PSB-230S Sold separately TM-2 ROSS PSA-230S Sold separately TM-2 BOSS PSA-230S Sold separately TW-3 ROSS PSA-230S Sold separately TM-3S BOSS PSA-230S Sold separately U.4 TU-3S <td< td=""><td></td><td></td><td></td><td></td><td></td></td<>					
SYSTEM-M Roland PSD-20					
SYSTEM-8 Roland PSB-5U TAIKO-1 Roland PSB-5U TB-2W BOSS PSA-230S Sold separately TB-3 Roland PSB-5U TD-07 Roland PSB-5U TD-07 Roland PSB-5U TD-11 Roland PSB-5U TD-17 Roland PSB-1U TD-17 Roland PSB-1U TD-27 Roland PSB-1U TE-2 BOSS PSA-230S Sold separately TM-1 Roland PSB-230 Sold separately TM-1 Roland PSB-230 Sold separately TM-2 Roland PSB-230 Sold separately TM-2 ROland PSB-230 Sold separately TR-2 BOSS PSA-230S Sold separately TR-2 BOSS PSA-230S Sold separately TU-33 BOSS PSA-230S Sold separately TU-33 BOSS PSA-230S Sold separately TU-38 Roland PSB-1U TU-48					
TAIKO-1 TB-2W BOSS PSA-230S Sold separately TB-3 Roland PSB-5U TB-3 Roland PSB-5U TD-07 Roland PSB-5U TD-17 Roland PSB-5U TD-17 Roland PSB-1U TD-17 Roland PSB-1U TD-25 Roland PSB-1U TD-27 Roland PSB-230 Sold separately TM-1 TR-2 BOSS PSA-230S Sold separately TM-2 TR-2 BOSS PSA-230S Sold separately TR-8S Roland PSD-230 TM-8PRO Roland PSB-1U TU-3 BOSS PSA-230S Sold separately TU-3 BOSS PSA-230S TU-3W BOSS PSA-230S Sold separately TU-3 BOSS PSA-230S TU-3W BOSS PSA-230S Sold separately TU-3 BOSS PSA-230S Sold separately TU-3 BOSS TU-3W BOSS PSA-230S Sold separately TU-3 TU-3 TU-3 TU-3 TU-3 TU-3 TU-3 TU-3					
TB-2W	т				
TB-3	'				Sold congrately
TD-07					Solu separately
TD-1					
TD-17					
TD-25					
TD-27					
TE-2 BOSS PSA-230S Sold separately TM-1 Roland PSA-230S Sold separately TM-2 Roland PSD-230 Sold separately TM-2 Roland PSD-230 TM-6 PRO Roland PSB-1U TR-2 BOSS PSA-230S Sold separately TR-8 Roland PSD-230 TU-3 BOSS PSA-230S Sold separately TU-3 BOSS PSA-230S Sold separately TU-3 BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately TU-3HO ROland PSB-1U UA-1610 Roland PSB-1U UA-1610 Roland PSB-1U V-02HD Roland PSB-1U V-02HD Roland PSB-1U V-12DHD ROland PSB-1U V-11HD ROland PSB-7U V-11HD ROland PSB-7U V-11HD ROland PSB-7U V-15DI ROland PSB-7U V-16DI ROland PSB-1U V-40HD ROland PSB-1U V-45B-1U V					
TM-1 Roland PSA-230S Sold separately TM-2 Roland PSD-230 TM-6 PRO Roland PSB-1U TR-2 BOSS PSA-230S Sold separately TR-8S Roland PSD-230 Sold separately TU-3 BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately U-1010 Roland PSB-1U UV-1010 UA-1010 Roland PSB-1U UV-1010 UA-1610 Roland PSB-1U UV-1010 UA-1610 Roland PSB-1U UV-1010 V-02HD Roland PSB-1U UV-1010 V-02HD Roland PSB-1U UV-1010 V-100HDR Roland PSB-1U UV-1010 V-11DD Roland PSB-7U VV-11D V-11DD Roland PSB-7U VV-1010 V-11DD Roland PSB-14U VV-40HD V-4EX Roland PSB-7U					Sold congrately
TM-2 Roland PSB-1U TM-6 PRO Roland PSB-1U TR-2 BOSS PSA-230S Sold separately TR-8S Roland PSD-230 Sold separately TU-3 BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately U-1610 Roland PSB-1U PSB-1U V-02HD Roland PSB-1U PSB-1U V-11D Roland PSB-7U PSB-7U V-15DI Roland PSB-7U PSB-7U V-4EX Roland PSB-7U PSB-7U V-4EX Roland					
TR-6 PRO					Solu separately
TR-2 BOSS PSA-230S Sold separately TR-8S Roland PSD-230 Sold separately TU-3 BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately U-1010 Roland PSB-1U U-1010 UA-1610 Roland PSB-1U U-102HD U-10410 Roland PSB-1U U-102HD V-02HD Roland PSB-1U U-102HD V-120HDR Roland PSB-1U U-104HD V-120HDR Roland PSB-7U U-114D V-14DDR Roland PSB-7U U-114D V-14DDR Roland PSB-7U U-114D V-15DI Roland PSB-7U U-114D V-15DI Roland PSB-7U U-114D V-4EXX Roland PSB-7U U-114D V-4EXX Roland PSB-7U U-114D V-20HD Roland PSB-7U U-114D V-20HD R					
TR-8S Roland PSD-230 TU-3 BOSS PSA-230S Sold separately TU-3S BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately U JA-1010 Roland PSB-1U UA-1610 Roland PSB-1U UV-02HD Roland PSB-1U V-02HD Roland PSB-1U V-120HDR Roland PSB-1U V-120HDR Roland PSB-1U V-11DD Roland PSB-7U V-11DD Roland PSB-7U V-11DD Roland PSB-7U V-15DI Roland PSB-7U V-15DI Roland PSB-7U V-40DD Roland PSB-7U V-8HD Roland PSB-7U V-8HD Roland PSB-7U V-8HD Roland PSB-7U V-8HD Roland PSB-7U V-8-2W Roland PSB-7U V-1-1-L Roland PSB-1U V-1-1-L Roland PSB-1U V-1-1-L Roland PSB-1U V-1-1-SC Roland PSB-1U V-1-SC ROland PSB-1U R-2-SO ROland PSB-1U R-2					Sold congrately
TU-3 BOSS PSA-230S Sold separately TU-3S BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately UJA-1010 Roland PSB-1U UJA-1010 Roland PSB-1U UV-02HD Roland PSB-1U V-02HD ROLAND ROLAND PSB-1U V-02HD ROLAND PSB-1U V-120HDR ROLAND PSB-1U V-120HDR ROLAND PSB-1U V-14DD ROLAND PSB-7U V-11DD ROLAND PSB-7U V-11DD ROLAND PSB-7U V-11DD ROLAND PSB-7U V-15DI ROLAND PSB-7U V-15DI ROLAND PSB-7U V-160HD ROLAND PSB-7U V-40HD ROLAND PSB-7U V-40HD ROLAND PSB-7U V-80HD ROLAND PSB-8U V-80HD PSB-					Solu separately
TU-3S BOSS PSA-230S Sold separately TU-3W BOSS PSA-230S Sold separately UA-1010 Roland PSB-1U UA-1610 Roland PSB-1U UA-1610 Roland PSB-1U V-02HD ROLAND PSB-1U V-02HD MK2 Roland PSB-1U V-120HDR Roland PSB-1U V-120HDR Roland PSB-7U V-1HD Roland PSB-7U V-1HD Roland PSB-7U V-1HD Roland PSB-7U V-1HD PLUS Roland PSB-7U V-15DI Roland PSB-7U V-16DHD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-8EX Roland PSB-7U V-8HD Roland PSB-7U V-8-8W Roland PSB-7U VB-2W Roland PSB-7U VC-1-DL Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SB PSB-1U VC-1-SB PSB-30S Sold separately VE-2 BOSS PSA-230S Sold separately VE-3 BOSS PSA-230S Sold separately VE-4H Roland PSB-7U VR-99-B Roland PSB-7U VR-99-B Roland PSB-7U VR-99-B Roland PSB-7U VR-50HD Roland PSB-7U VR-50HDMK2 Roland PSB-7U VR-50HDMK2 Roland PSB-7U VR-50HDMK2 Roland PSB-7U VR-50B BOSS PSA-230S Sold separately VR-50B BOSS PSA-230S S					Sold separately
TU-3W BOSS PSA-230S Sold separately U UA-1010 Roland PSB-1U UA-1610 Roland PSB-1U UA-1610 Roland PSB-1U V-02HD Roland PSB-1U V-02HD Roland PSB-1U V-120HDR Roland PSB-1U V-120HDR Roland PSB-7U V-11D Roland PSB-7U V-11D Roland PSB-7U V-11D Roland PSB-7U V-11D Roland PSB-7U V-15DI Roland PSB-7U V-160HD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-80HD Roland PSB-7U V-80HD Roland PSB-7U V-80HD Roland PSB-7U V-8-1DL Roland PSB-7U V-1-1DL Roland PSB-1U VC-1-1BS Roland PSB-1U VC-1-1BS Roland PSB-1U VC-1-SC ROLAND PSB-1U VR-30-S ROLAND PSB-1U XS-42H ROLAND PSB-7U					· · · · · · · · · · · · · · · · · · ·
U UA-1010 Roland PSB-1U V-02HD Roland PSB-1U V-02HD MK2 Roland PSB-1U V-02HD MK2 Roland PSB-1U V-1200HDR Roland PSB-1U V-1200HDR Roland PSB-1U V-1200HDR Roland PSB-7U V-14D Roland PSB-7U V-14D Roland PSB-7U V-14D Roland PSB-7U V-15D Roland PSB-1U V-15D ROLAND ROLA					
UA-1610	,,				cond doparatory
V V-02HD Roland PSB-1U V-02HD MK2 Roland PSB-1U V-1200HDR Roland PSB-7U V-1HD Roland PSB-7U V-1HD Roland PSB-7U V-1HD PLUS Roland PSB-7U V-1SDI Roland PSB-7U V-160HD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-4EX Roland PSB-1U V-4DHD Roland PSB-7U V-4BD Roland PSB-7U V-4BD Roland PSB-7U V-8HD Roland PSB-7U V-1-1C Roland PSB-1U VC-1-1-1 Roland PSB-1U VC-1-1-1 Roland PSB-1U VC-1-1-1 Roland PSB-1U VC-1-1-1 BOSS PSA-230S Sold se	U				
V-02HD MK2 Roland PSB-1U V-1200HDR Roland PSB-7U V-1HD Roland PSB-7U V-1HD PLUS Roland PSB-7U V-15DI Roland PSB-7U V-160HD Roland PSB-14U V-40HD Roland PSB-7U V-4EX Roland PSB-7U V-8HD Roland PSB-7U V-9W Roland PSB-1U VC-1-DL Roland PSB-1U VC-1-BS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC ROSS PSA-230S Sold separate	v				
V-1200HDR Roland PSB-7U V-1HD Roland PSB-7U V-1HD PLUS Roland PSB-7U V-1SDI Roland PSB-7U V-160HD Roland PSB-14U V-40HD Roland PSB-1U V-4EX Roland PSB-1U V-60HD Roland PSB-7U V-8HD Roland PSB-7U V-9B-W Roland PSB-7U V-1DL Roland PSB-1U VC-1-DL Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SB Roland PSB-1U VE-1 BOSS PSA-230S Sold separately	v				
V-1HD Roland PSB-7U V-1SDI Roland PSB-7U V-1SDI Roland PSB-7U V-160HD Roland PSB-14U V-40HD Roland PSB-14U V-40HD Roland PSB-7U V-8DHD Roland PSB-7U V-8HD Roland PSB-7U VB-2W Roland PSB-7U VC-1DL Roland PSB-1U VC-1-DL Roland PSB-1U VC-1+IS Roland PSB-1U VC-1-SE Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-1U VC-100UHD Roland PSB-14U VE-2 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-50 BOSS PSA-230S Sold separately </td <td></td> <td></td> <td></td> <td></td> <td></td>					
V-1HD PLUS Roland PSB-7U V-15DI Roland PSB-7U V-160HD Roland PSB-14U V-40HD Roland PSB-7U V-40HD Roland PSB-7U V-4EX Roland PSB-1U V-60HD Roland PSB-7U V-8HD Roland PSB-7U V-9-2W Roland PSB-1U VC-1-BS Roland PSB-1U VC-1+SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VE-1 BOSS PSA-230S Sold separately </td <td></td> <td></td> <td></td> <td></td> <td></td>					
V-1SDI Roland PSB-7U V-160HD Roland PSB-14U V-4DHD Roland PSB-1U V-4EX Roland PSB-1U V-60HD Roland PSB-7U V-8HD Roland PSB-7U V-8HD Roland PSB-7U VB-2W Roland PSB-7U VC-1-DL Roland PSB-1U VC-1-DL Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-1U VC-100UHD Roland PSB-1U VE-2 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately <td></td> <td></td> <td></td> <td></td> <td></td>					
V-160HD Roland PSB-14U V-40HD Roland PSB-7U V-4EX Roland PSB-1U V-60HD Roland PSB-7U V-8HD Roland PSB-7U V-8HD Roland PSB-7U V-9-10 Roland PSB-7U VC-1-DL Roland PSB-1U VC-1-BS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SC Roland PSB-230S Sold separately VE-2 BOSS PSA-230S VE-2 BOSS PSA-230S Sold separately VE-5 BOSS					
V-40HD Roland PSB-7U V-4EX Roland PSB-1U V-60HD Roland PSB-7U V-8HD Roland PSB-7U VB-2W Roland PSB-7U VC-1-DL Roland PSB-1U VC-1-DL Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-1U VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-3 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U					
V-4EX Roland PSB-1U V-60HD Roland PSB-7U V-8HD Roland PSB-7U VB-2W Roland PSB-7U VC-1-DL Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-1U VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-98-B Roland PSB-7U <t< td=""><td></td><td></td><td></td><td></td><td></td></t<>					
V-60HD Roland PSB-7U V-8HD Roland PSB-7U VB-2W Roland PSA-230S Sold separately VC-1-DL Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-1U VC-100UHD Roland PSB-14U VC-100UHD Roland PSB-1U VE-1 BOSS PSA-230S Sold separately Sold separately VE-2 BOSS PSA-230S Sold separately VE-3 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-500 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-4B Roland PSB-7U PSB-7U VP-42H Roland PSB-7U PSB-7U VR-4HD Roland PSB-7U					
V-8HD Roland PSB-7U VB-2W Roland PSA-230S Sold separately VC-1-DL Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-14U VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-20 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-500 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-4B Roland PSB-7U VP-42H Roland PSB-7U VR-09-B Roland PSB-7U VR-4HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-50HDMK2 Roland					
VB-2W Roland PSA-230S Sold separately VC-1-DL Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-1U VC-1-SH Roland PSB-14U VE-1 BOSS PSA-230S Sold separately VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-99-B Roland PSB-1U VR-99-B Roland PSB-7U VR-9B-7U VR-9B-7U VR-4HD Roland PSB-7U VR-50HD					
VC-1-DL Roland PSB-1U VC-1-HS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-1U VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-4B Roland PSB-7U Sold separately VP-42H Roland PSB-7U VR-09-B Roland PSB-7U VR-09-B Roland PSB-7U VR-4HD Roland PSB-7U VR-30HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-50HDMK2 Roland PSB-1U VR-50 BOSS					Sold separately
VC-1-HS Roland PSB-1U VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-14U VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-20 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-500 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-4B Roland PSB-7U VP-42H Roland PSB-7U VR-49-B Roland PSB-1U VR-4HD Roland PSB-7U VR-4HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-10 Sold separately VK-60 BOSS PSA-230S Sold separately X					
VC-1-SC Roland PSB-1U VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-14U VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-20 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-600 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VO-1 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-9-B Roland PSB-1U VR-9-B Roland PSB-7U VR-4HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U W-60 BOSS PSA-230S Sold separately X XPS-10					
VC-1-SH Roland PSB-1U VC-100UHD Roland PSB-14U VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-20 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-600 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-4B Roland PSB-7U Sold separately VP-42H Roland PSB-7U PSB-1U VR-9-B Roland PSB-1U PSB-1U VR-4HD Roland PSB-7U PSB-7U VR-50HD Roland PSB-14U PSB-14U VR-50HDMK2 Roland PSB-14U PSB-14U VR-730 Roland PSB-10 Sold separately WU-50 BOSS PSA-230S Sold separately XPS-10 Roland PSB-1U PSB-1U XPS-30 Roland </td <td></td> <td></td> <td></td> <td></td> <td></td>					
VC-100UHD Roland PSB-14U VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-20 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-500 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-92H VR-9-B Roland PSB-1U VR-1D VR-1DD Roland PSB-7U VR-4HD VR-4HD Roland PSB-7U VR-50HD VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WW-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately XPS-10 Roland PSB-1U XPS-30 Roland PSB-7U XS-42H Roland PSB-7U					
VE-1 BOSS PSA-230S Sold separately VE-2 BOSS PSA-230S Sold separately VE-20 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-500 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VC-1 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-09-B Roland PSB-7U VR-09-B Roland PSB-1U VR-1HD Roland PSB-7U VR-1HD Roland PSB-7U VR-50HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WW-50 BOSS PSA-230S Sold separately WU-50 BOSS PSA-230S Sold separately XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1					
VE-2 BOSS PSA-230S Sold separately VE-20 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-500 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VO-1 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-09-B Roland PSB-7U VR-09-B Roland PSB-7U VR-4HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WU-50 BOSS PSA-230S Sold separately WU-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U					Sold separately
VE-20 BOSS PSA-230S Sold separately VE-5 BOSS PSA-230S Sold separately VE-500 BOSS PSA-230S Sold separately VE-8 BOSS PSA-230S Sold separately VP-1 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VP-42H VR-09-B Roland PSB-1U VR-09-B Roland VR-1HD Roland PSB-7U VR-4HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WW-50 BOSS PSA-230S Sold separately WW-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U					· · · · · · · · · · · · · · · · · · ·
VE-5 BOSS PSA-230S Sold separately VE-500 BOSS PSA-230S VE-8 BOSS PSA-230S Sold separately VC-1 BOSS PSA-230S Sold separately VE-9-1 Sold separately Sold separately VE-9-1 VE-10-1					
VE-500 BOSS PSA-230S VE-8 BOSS PSA-230S VO-1 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-09-B Roland PSB-1U VR-1HD Roland PSB-1U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U W W-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U					
VE-8 BOSS PSA-230S VO-1 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-09-B Roland PSB-1U VR-1HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WU-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U					
VO-1 BOSS PSA-230S Sold separately VP-42H Roland PSB-7U VR-09-B Roland PSB-1U VR-1HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WU-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VE-8			
VP-42H Roland PSB-7U VR-09-B Roland PSB-1U VR-1HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WU-50 BOSS PSA-230S Sold separately WU-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VO-1			Sold separately
VR-1HD Roland PSB-7U VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WU-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VP-42H	Roland	PSB-7U	
VR-4HD Roland PSB-7U VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U W WL-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VR-09-B	Roland	PSB-1U	
VR-50HD Roland PSB-14U VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U WU-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VR-1HD	Roland	PSB-7U	
VR-50HDMK2 Roland PSB-14U VR-730 Roland PSB-1U W WL-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VR-4HD	Roland	PSB-7U	
VR-730 Roland PSB-1U W WL-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VR-50HD	Roland	PSB-14U	
W WL-50 BOSS PSA-230S Sold separately WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VR-50HDMK2	Roland	PSB-14U	
WL-60 BOSS PSA-230S Sold separately X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		VR-730	Roland	PSB-1U	
X XPS-10 Roland PSB-1U XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U	W	WL-50	BOSS	PSA-230S	Sold separately
XPS-30 Roland PSB-1U XS-1HD Roland PSB-7U XS-42H Roland PSB-7U		WL-60	BOSS	PSA-230S	Sold separately
XS-1HD Roland PSB-7U XS-42H Roland PSB-7U	Х	XPS-10	Roland	PSB-1U	
XS-42H Roland PSB-7U		XPS-30	Roland	PSB-1U	
		XS-1HD	Roland	PSB-7U	
XS-62S Roland PSB-7U		XS-42H	Roland	PSB-7U	
		XS-62S	Roland	PSB-7U	