

ECoG signal recording


- **1. Attach the ground electrode** to the patient's back. Use the white cable having the black plug at its end.
- **2. Run ASALAB with the license key plugged in.** Click "Setup Recording".



3. Select the montage "current_ECoG_CHU_spare11".



Note that the montage "current_ECoG_CHU_spare11" is defined as follows:



The first four channels represent electrodes 1-4 of the short strip. Then, the second short strip (electrodes 5-8). Finally, the 6 electrodes of the long strip.

Remember to connect the channel 18 in place of 11, due to the broken connector number 11.

- 4. Set the stimulation parameters to: 2Hz / 5mA
- **5. Start recording.** Remember to mark events representing onsets of stimulation. Make hand notes describing the stimulation procedure.
- 6. Use the interface of the neuronavigation system to take screenshots showing the placement of electrodes.
- 7. Remind Fabien to take a photo of electrodes and labels.