

<u>Pins</u>	Connections	<u>Pins</u>	<u>Connections</u>	<u>Pins</u>	Connections
1	Pressure sensor 1 Negative	11	NOT CONNECTED	21	Pressure sensor 8 Positive
2	Pressure sensor 2 Negative	12	NOT CONNECTED	22	Temperature sensor 1 Negative
3	Pressure sensor 3 Negative	13	Control sensor Negative	23	NOT CONNECTED
4	Pressure sensor 4 Negative	14	Pressure sensor 1 Positive	24	NOT CONNECTED
5	Pressure sensor 5 Negative	15	Pressure sensor 2 Positive	25	Control sensor Negative
6	Pressure sensor 6 Negative	16	Pressure sensor 3 Positive		
7	Pressure sensor 7 Negative	17	Pressure sensor 4 Positive		
8	Pressure sensor 8 Negative	18	Pressure sensor 5 Positive		
9	Temperature sensor 1 Negative	19	Pressure sensor 6 Positive		
10	NOT CONNECTED	20	Pressure sensor 7 Positive		