


# 8 WAY SCROLLER INSTRUCTIONS

---



## **Installing the mouse**

- 1. Turn your computer OFF.**
- 2. Attach the mouse to the PS/2 port or a serial port using the included adaptor.**
- 3. Turn the computer power on.**

## **Installing the A/P Ware Software for Windows '95 or '98**

\*\*\*\* Please close all applications before starting the installation program\*\*\*\*

- 1. Place the mouse software diskette into drive A (or B).**
- 2. Select Start/Run, then type "A:\Setup" and enter.**
- 3. Follow the on-screen instructions.**
- 4. After the installation is completed select Yes to restart Windows.**

A/P Ware installs a mouse icon on the task bar near the time display. To adjust any of the features, double click on this icon. For more details on the features, see the readme file on the included diskette.

## **Installing the A/P ware Software for Windows 3.x**

A/P Ware is not compatible with Windows 3.x

## **Trouble Shooting**

If the mouse does not function properly or a problem arises, please check the following before calling Customer Service.

- 1.Check that the mouse connector is firmly plugged into the serial port.**
- 2.Clean the mouse ball and the rollers on the following "Cleaning" procedure.**

NOTICE: THERE IS A CORRECTION  
FOR INSTALLING THE A/P SOFTWARE,  
POINT #2. PLEASE SELECT START/RUN,  
THEN TYPE A:\WINSETUP INSTEAD  
OF JUST A:\SETUP.

## **Mouse Use and Care**

## **Operating Conditions**

Your mouse will work properly under most home and office conditions. It is however an electronic device and should be kept away from excessive moisture. Also avoid sudden impacts to the unit and pulling on the cable.

## **Cleaning**

To ensure proper performance and long life, it is important to keep the ball clean. Once every few months, or when you notice the on-screen pointer is not moving smoothly, proceed with the following cleaning process:


- 1.Remove the ball door.**
- 2.Remove the ball.**
- 3.Carefully clean the ball with lukewarm water and mild detergent, making sure not to scratch or tear its surface. Dry the ball thoroughly with a soft cloth.**
- 4.Carefully clean the rollers of dirt and grime using a toothpick, cotton swab, or other soft object.**
- 5.Return the ball to its chamber.**
- 6.replace the ball door to secure the ball in the mouse housing.**

For Technical Support please call (800) 639 3803

All brand names & trademarks are the property of their respective owners


## A/P Ware Plus Function Description

### (1) Movement




This Function allows the user to set the Point Speed, Trail Length and Double Click Speed of the mouse. You can use the scroll bars to adjust the settings.

### (2) Pointer




This Function allows the user to set the pointer size and attribute of the mouse. Use the mouse to select the "Custom Cursor" and then select the size and attribute of the mouse. Click on "System Cursor" to return to the system default settings.

### (3) Third Button - System



This Function allows the user to test the connection between the mouse and the computer. Press any button on the mouse and the corresponding button on the screen will change color. Selecting this option also resets the middle button to the system default setting.

### (4) Third Button- Hand Scroll



This Function allows the user to choose different scroll features.

Vertical Scroll- Select this option to enable the vertical scroll feature.

Horizontal Scroll - Select this option to enable the horizontal scroll feature.


Click Trigger - Selecting this option allows the user to click the middle button once and move the mouse to scroll in the direction of the mouse movement.

Hold Down Trigger - Selecting this option allows the user to hold the middle button down and move the mouse to scroll in the direction of the mouse movement.

Reverse Scroll Direction - Select this option of reverse the scroll direction.

Speed Settings - Adjust the vertical and horizontal scroll bars to change the scroll speed.


## (5) Third Button - AutoScroll



Scroll your document automatically without having to move the mouse.

- Click mouse middle button to set the reference point in test area.
- Move your mouse around the reference point to scroll the test window.
- The scroll speed will change automatically according to the distance of mouse and the reference point.


## (6) Third Button - Zoom



This function allows the user to zoom in/out your document in a small window.

- Press Ctrl and middle button to enable the zoom function.
- When the function is enabled, Use left button to increase zoom factor and right button to decrease zoom factor.


## (7) Third Button - View



This Function allows the user to zoom in/out your document in whole page.  
This is an Office 97 function.


- Press Shift and middle button to enable the view function.
- When the function is enabled, Use left button to increase view factor and right button to decrease view factor.

## (8) Third Button - Assignment



This Function allows the user to set mouse middle button. You can set the middle button as one of the key combinations below :  
Backspace, Close Application, Copy, Cut, Delete, Double Click, Drag Lock, End, Enter, F1, F2, F3, F4, F5, F6, F7, F8, F9, F10, Find Computer, Find File, Home, Main Windows Help, Middle Button, Maximize Window, Minimize Window, Minimize All, Page-Down, Page Up, Paste, Redo, Run, Space, Start Menu, System Property, Tab, Undo.

## (9) Real Scroll



This Function allows the user to set the thumb scroller control to scroll 1 to 10 lines, or scroll 1 page at a time. You can control the vertical and horizontal scroll separately.

**COMPUSA PC**

## **8-Way Scroller**

Internet mouse with Unique Thumb Control

### **Features**

- Unique thumb control makes scrolling a breeze!
- Scrolls the internet in 8 different directions (up/down, side to side and diagonally)
- Magic button saves you time and effort
- Ergonomically designed to reduce fatigue
- PS/2 and serial port compatible

**Unique 8-Way Thumb Controller For Scrolling!**

Windows® 95/98 or NT. Compatible

**COMPUSA PC**

# a unique alternative to a mouse

Any mouse can point, but is that enough? The mouse was invented to make things easier. Why stop half way? Too much time and effort is still wasted traveling back and forth to menus and the keyboard. Useful shortcuts often go unused because they are either too difficult to remember or too hard to reach.

The **8-Way Scrolling Mouse** solves these problems with the innovative Magic Button. Time saving internet functions are at your fingertips to help you get the maximum benefit out of your time on-line. You can custom configure the middle button to have all of the same functions to scroll through the Net pages with just a click of a button. Use the wheel mode to enter your favorite Web site. You can scroll in 8 different directions (up/down, side to side and diagonally) and ZOOM in and out at the same time. These are just a few of the features you will experience with the the **8-Way Scroller**.

**Package Includes:**

The 8-way scrolling mouse  
Scrolling software (3.5" disk)


- installation software for Windows ® drivers
- middle button software
- quick reference

Combo Version (PS/2 and Serial)

**System Requirements:**

IBM PC 486/Pentium  
Serial Port or PS/2 Port  
Windows ® 95/98 or NT

All brand names and trademarks are the property of their respective owners



Distributed By  
**COMP USA INC.**  
DALLAS, TEXAS 75240  
[www.compusa.com](http://www.compusa.com)

Made in China

# 8-way Scroller



- uses just 5.5 x 4 inches of space
  - easy installation
    - smooth gliding action
    - user friendly for left or right hand