

Bot

BTS7960 kiri

Pin BTS7960	Sambung ke	GPIO (BCM)	Pin fisik Pi4
RPWM	Pi	GPIO12	Pin 32
LPWM	Pi	GPIO13	Pin 33
R_EN + L_EN (jumper jadi satu)	Pi (opsional) atau 3.3V	GPIO16 / 3.3V	Pin 36 / Pin 1 atau 17
VCC	Output 5V UBEC	–	–
GND	GND common	–	Pin 6
B+ / B–	Baterai + / –	–	–
M+ / M–	Motor kiri	–	–

BTS7960 kanan

Pin BTS7960	Sambung ke	GPIO (BCM)	Pin fisik Pi4
RPWM	Pi	GPIO18	Pin 12
LPWM	Pi	GPIO19	Pin 35
R_EN + L_EN (jumper jadi satu)	Pi (opsional) atau 3.3V	GPIO26 / 3.3V	Pin 37 / Pin 1 atau 17
VCC	Output 5V UBEC	–	–
GND	GND common	–	Pin 9
B+ / B–	Baterai + / –	–	–
M+ / M–	Motor kanan	–	–

UBEC

UBEC	Sambung ke
Input + / –	Baterai + / – (langsung, sebelum kena BTS7960)
Output + (5V)	Pi pin 2 atau 4 (5V), + VCC BTS7960 kiri & kanan
Output – (GND)	Pi pin 6/9 (GND), GND BTS7960 kiri & kanan, GND baterai (common ground)