Motion4Sim AASD15A Servo- Controller

Firmware Update Guide

Follow these steps to update the firmware


- Download bootloader application
 https://github.com/motion4sim/AASD15A-Servo-Controller-for-Motion-Simrigs/tree/master/bootloader
- 2. Download latest firmware binary

https://github.com/motion4sim/AASD15A-Servo-Controller-for-Motion-Simrigs/tree/master/firmware

Attention: you can save the controller config with new remote app, please check out github for newest version

3. configure the controller for flashing the firmware

remove the shield from the e70 board put the usb cable into the e70 USB port near the ethernet port you can try to press them without removing the shield from the e70 normaly this should work without any problems. be carefully with pins on the pcb



4. Start the controller in downloader mode by pressing button 1 and 2 together (new usb device recognized)


NEW

with the new booloader provided with controller after 14-03-21 there is a second easier way to start the bootloader. follow these instructions:


- a. switch offline an press emergency button
 (pay attention some emergency buttons are "normally closed" they have to be released"
- b. then entert he menu oft he controller, go to "reset", press the encoder button an hold for 3 seconds
- c. the display should hold "reset" and the controller restarts into bootloader mode (new usb device recognized) the red led will go off.
- d. alternatively you can simply power the board




5. Start bootloader_aes application previously downloaded



- 6. Choose com port of the controller already startet in bootloader mode
- 7. Hit "Enter Bootloader"



8. Press "Erase" and wait until erase completed



- 9. Select File "Open File" and check "Encrypted File"
- 10. then press "Program" to flash the firmware

After successfull flashing, the controller restarts itself. Now you should do a factory reset of the eeprom data. Follow the next instructions for factory data restore:

- 1. restart the controller
- 2. wait until display shows "press encoder to calibrate..."



3. now rotate encoder to the left until the display shows "press encoder.. factory restore" and hit the encoder button, wait until eeprom is reprogrammed

New

there are 2 factory presets stored now if you turn left 1. For linear actuators and 1 for rotating actuators



4. now you can turn the encoder to the right to calibrate. if you have a saved config file, now you can load them back with the remote app. But be carefully check all values trough the controller menu.