



HOW-TO GUIDE

Auto Detailing

Every auto service we sell, step by step, with the exact product for each one. Follow it in order. The order is the reason the results are good.

The Kit

Exact products. Anything in **red** is not on the shelf yet, see the last page.

PRODUCT	WHAT IT IS	WHAT IT'S FOR
Koch Chemie Gentle Snow Foam	pH-neutral foam soap	First layer of foam on the whole car. Safe on wax and coatings.
Koch Chemie Nano Magic Shampoo	Wash soap	The two-bucket contact wash.
P&S Brake Buster	Wheel cleaner, non-acid	Wheels, barrels, and lug areas.
Koch Chemie Reactive Rim Cleaner	Iron / fallout remover	Dissolves brake dust and iron specks. Turns purple as it works.
Adam's Visco Clay Bar Kit	Clay bar + lube	Pulls out bonded grit the wash leaves behind.
Koch Chemie Heavy Cut H9.01	Cutting compound	Removes swirls and light scratches.
Koch Chemie Micro Cut M3.01	Finishing polish	Brings the gloss back after cutting.
Koch Chemie Panel Star	Panel prep / degreaser	Wipes off polish oils so wax or coating actually sticks.
P&S Bead Maker	Spray sealant	The Wax add-on. Fast, glossy, lasts a few months.
Adam's Graphene Ceramic Coating	Ceramic coating	The \$225 add-on. Roughly a year of protection.
Koch Chemie Green Star	All-purpose cleaner	Dilute it. Door jambs, engine bay, dirty plastics.
P&S Xpress Interior Cleaner	Interior cleaner	Dash, console, panels, leather, vinyl.
P&S Carpet Bomber	Carpet & upholstery cleaner	Shampooing floors and seats.
Adam's Glass Cleaner	Glass cleaner	Inside and outside of every window.
Adam's Tire Shine	Tire dressing	Final touch on the tires.
Steam cleaner	You already own this	Vents, seams, cup holders, and lifting stains.

Rules That Don't Change

These apply to every single job. Read them once, follow them always.

- **Never work on hot paint or in direct sun.** Move the car into shade or wait. Product dries on the panel and stains it.
- **Top down, always.** Roof first, rockers and bumpers last. The lowest parts are the dirtiest and you don't want that grit going back up.
- **Two buckets, every wash.** One with soap, one with plain rinse water and a grit guard. Rinse the mitt in the plain bucket before it goes back into the soap. This is what prevents swirl marks.
- **Wheels come first, with their own bucket and brushes.** Brake dust in your paint mitt will scratch the car.
- **Never let anything dry on the paint.** Work one panel at a time and rinse it before it flashes.
- **Fresh towel, folded in fours.** When a side gets dirty, flip it. When all four are used, get a new towel. A dropped towel is done, it goes in the laundry bag, not back on the car.
- **Check with the customer before you touch aftermarket wraps, matte paint, or PPF.** Wax and some chemicals will ruin a matte finish.
- **Take before photos every job.** Existing dents, scratches, and cracked trim get photographed before you start. This protects you.

Quick Wash

\$60 flat · about 45 minutes · exterior only, no interior work

A proper outside wash and dry. More than a rinse, less than a detail. No clay, no wax, nothing touches the inside of the car.

1 Walk around the car with the customer

- Point out any damage you see and photograph it.
- Ask if there's anything specific bothering them.

2 Wheels and tires first

- Spray **P&S Brake Buster** on one wheel at a time, cold wheel only.
- Let it sit 1 to 2 minutes. Do not let it dry.
- Agitate the face, the barrel, and behind the spokes with your wheel brushes.
- Rinse completely before moving to the next wheel.

3 Foam the whole car

- Cover the car in **Koch Chemie Gentle Snow Foam** from the bottom up, so you can see where you've been.
- Let it dwell 3 to 5 minutes. It's loosening dirt so your mitt doesn't have to drag it.
- Rinse from the top down until the foam is gone.

4 Two-bucket contact wash

- Soap bucket gets **Koch Chemie Nano Magic Shampoo** per the bottle's dilution.
- Wash top down, one panel at a time, straight lines not circles.
- Rinse the mitt in the plain bucket between every panel.

5 Final rinse

- Pull the nozzle off and let water sheet off the panels. Much less to dry.
- Open the doors and rinse the jambs and sills.

6 Dry

- Big plush drying towel, blot and drag, don't scrub.
- Dry the jambs, mirrors, and around badges and handles, that's where drips show up later.

7 Finish

- **Adam's Tire Shine** on the tires, applicator not spray, so it doesn't sling onto the paint.
- **Adam's Glass Cleaner** on the outside of all glass.

Watch out. Cold wheels only. Wheel cleaner on a hot brake rotor flashes off instantly and can stain the finish.

Done when

- ☐ No water spots or drips anywhere, including jambs and mirrors.
- ☐ Wheel faces and barrels are clean, no brake dust left in the spokes.
- ☐ Glass is clear from the outside with no streaks.
- ☐ Tires are even, no sling on the paint.

Standard Detail

\$200 / \$220 / \$275 by size · about **2 to 3 hours** · the base every other package builds on

Full inside and out. Everything in the Quick Wash, plus a complete interior: vacuum, shampoo carpets and upholstery, stain removal, deodorize, all glass, and a full wipe-down.

Exterior

Run the entire Quick Wash first, steps 1 through 7. Then come inside.

Interior

1 Empty it out

- Every floor mat comes out. All trash out. Personal belongings into a bag, hand them to the customer, never throw anything away that isn't obviously trash.
- Check under seats, in seat back pockets, and in the spare tire well.

2 Dry brush and vacuum

- Brush the carpets and seats first to lift dirt out of the fibers, then vacuum.
- Vacuum top down: headliner area, seats, seat rails, console, then floors last.
- Use the crevice tool along seat rails and between the seat and console. That's where the crumbs are.

3 Shampoo carpets and cloth seats

- Spray **P&S Carpet Bomber** onto the carpet, not soaking it, just damp.
- Agitate with a stiff drill brush or hand brush until it foams up.
- Blot hard with a dry microfiber to pull the dirt out. Fold to a clean side and repeat.
- Repeat on any spot that's still dark. Patience beats more chemical.

4 Steam the tight spots

- Steam the vents, seams, cup holders, shifter surround, and door pockets.
- Wipe immediately behind the steam with a clean microfiber, before it dries.
- Steam also kills odor at the source, which is better than covering it with fragrance.

5 Leather and hard surfaces

- **P&S Xpress Interior Cleaner** sprayed onto your towel, never directly onto a screen or gauge cluster.
- Dash, console, door cards, handles, steering wheel, shifter, all plastics.
- Leather seats: light mist, gentle brush, wipe dry. Don't soak perforated leather, product gets in the holes.

6 Glass, inside

- **Adam's Glass Cleaner** with two towels: one to clean, one dry to buff.
- Do the inside of the windshield last and lower the windows an inch to get the top edge.

7 Mats back in, final look

- Mats must be fully dry before they go back in or they'll smell.
- Sit in the driver's seat and look around. That's the customer's view and it's where you'll spot what you missed.

Watch out. Never spray any cleaner directly onto a touchscreen, gauge cluster, or headliner. Spray the towel instead. Headliners sag permanently if you soak the adhesive.

Tip. Sell the pet hair add-on before you start, not after. Once you're an hour into fighting hair for free, you've lost the money.

Done when

- ☐ Carpets are uniformly clean, not just the visible middle part.
- ☐ No dust on the dash, in the vents, or around the shifter.
- ☐ Glass is clear from the driver's seat with no haze.
- ☐ It smells clean, not perfumed.
- ☐ All the customer's belongings are back or handed over.

Premium Detail

\$260 / \$290 / \$365 by size · about **3 to 4 hours** · most popular package

Everything in the Standard Detail, plus a clay bar treatment and a hand-applied wax. This is the package for a car that looks clean but feels rough to the touch.

Do the full Standard Detail first. The clay and wax happen after the wash and before you go inside, because the car needs to be wet and clean for claying.

1 Iron remover, after the wash

- With the car washed and still wet, spray **Koch Chemie Reactive Rim Cleaner** over the paint and wheels.
- It will bleed purple where it's dissolving iron. That's it working, not blood.
- Let it dwell 3 to 5 minutes, never let it dry, then rinse thoroughly.

2 Clay the paint

- Keep the panel soaked with **Adam's Visco Clay Bar Kit** lube. Clay must never touch dry paint.
- Work a 2ft by 2ft area at a time in straight overlapping lines, light pressure.
- You'll feel it grab at first and then go silent. Silent means that section is done.
- Fold the clay to a clean face often. If you drop it on the ground, throw it away, no exceptions.
- Wipe the panel with a clean towel and move on.

3 Feel-test the paint

- Put your hand in a thin plastic bag and run it over the paint.
- It should feel like glass. Any roughness means that section needs more clay.

4 Wax

- **P&S Bead Maker** is the fastest route: mist onto a damp or dry panel, spread with one towel, buff with a second.
- Work one panel at a time. Thin coats. More product does not mean more protection.
- Keep it off textured black trim, it can leave white residue.

5 Then do the interior

- Now run the full interior portion of the Standard Detail.

Watch out. Clay only removes what's stuck on the surface. It does not remove swirls or scratches. If the customer wants swirls gone, that's Machine Polish or the Signature Detail, quote it separately.

Done when

- ☐ Paint feels glass-smooth through a plastic bag on every panel.
- ☐ Water beads tight and rolls off.
- ☐ No wax residue in panel gaps, badges, or trim.
- ☐ Everything in the Standard Detail checklist also passes.

Signature Detail

\$530 / \$595 / \$690 by size · about **6 to 8 hours, often two days** · the top package

Everything in the Standard Detail, plus clay bar, a full machine polish, and ceramic coating. This is the one that actually removes swirl marks and then locks the finish in for about a year.

Order matters here and it cannot be shuffled: wash, iron remove, clay, polish, panel prep, coat. Every step exists to make the next one work.

1 Wash, iron remove, clay

- Same as the Premium Detail, steps 1 through 3. The paint has to be perfectly clean before a machine touches it.

2 Tape off the edges

- Painter's tape over plastic trim, badges, rubber seals, and panel edges.
- A polisher burns through paint on a sharp edge in seconds. Tape is cheap.

3 Test spot first

- Pick one bad panel. **Koch Chemie Heavy Cut H9.01** on a cutting pad with the dual-action polisher.
- 4 or 5 pea-sized drops, spread at speed 1, then work at speed 4 to 5 with slow overlapping passes.
- Wipe it off and inspect under a bright light. If the swirls are gone, that's your process for the whole car.

4 Cut the whole car

- Work 2ft by 2ft sections, slow and overlapping, letting the machine do the work rather than leaning on it.
- Wipe each section clean before moving on so you can see what you actually did.
- Clean the pad often with a brush. A clogged pad stops cutting and starts smearing.

5 Refine the gloss

- Switch to a polishing pad and **Koch Chemie Micro Cut M3.01**.
- Same technique, lighter pressure. This removes the fine haze the compound leaves.

6 Panel prep, do not skip this

- Wipe every panel with **Koch Chemie Panel Star** on a clean towel.
- This strips the polishing oils. Coating applied over oils will not bond and will fail in weeks.

7 Apply the ceramic coating

- Adam's Graphene Ceramic Coating**. Indoors or in shade only, and follow the bottle for temperature.
- A few drops on the applicator. Work one panel at a time in a cross-hatch pattern.
- Watch for it to flash, usually 1 to 3 minutes depending on temperature. It goes slightly rainbow.
- Buff off with a fresh microfiber, then a second fresh towel to make sure nothing is left behind.
- Leftover coating that cures on the paint leaves high spots you have to polish out. Check every panel in good light before moving on.

8 Interior, then hand it over

- Run the full interior portion of the Standard Detail while the coating cures.
- Tell the customer plainly: keep it dry 24 hours, no wash for a week.

Watch out. Never machine polish a panel you haven't clayed. Trapped grit under the pad will drag across the paint and put in deeper scratches than the ones you're removing.

Watch out. Watch the paint temperature with your hand. If a panel is too hot to rest your palm on, stop and let it cool.

Tip. Charge for what the car needs. Heavily swirled single-stage or soft black paint takes far longer than a two-year-old white SUV. If it's going to run long, say so before you start.

Done when

- ☐ Swirls are gone under a bright light held at an angle, not just in the shade.
- ☐ No haze, holograms, or buffer trails.
- ☐ No coating high spots, streaks, or rainbow patches anywhere.
- ☐ No compound dust left in panel gaps, badges, or trim.
- ☐ Customer has been told the 24 hour and 1 week rules.

Add-Ons

Sold on their own or bolted onto any package

Clay Bar Treatment — \$50 / \$60 / \$75

Steps 1 through 3 of the Premium Detail. Roughly 45 to 75 minutes depending on how contaminated the paint is. Always sell it with the iron remover, they work together.

Wax — \$40 / \$45 / \$55

P&S Bead Maker over clean, dry paint. About 30 minutes. Thin, even, one panel at a time. Worth mentioning to the customer that wax on dirty paint just seals the dirt in, which is why we clay first on the Premium.

Machine Polish — \$150 / \$195 / \$240

Steps 2 through 5 of the Signature Detail, without the ceramic coating. Budget 1.5 to 3 hours. This is real labor and the price reflects it, don't discount it casually.

Ceramic Coating — \$225

Steps 6 and 7 of the Signature Detail. It must go over paint that has been washed, clayed, and panel-prepped. Applying it over neglected paint locks the defects in for a year, so if the paint is rough, tell the customer it needs the polish first.

Heavy Pet Hair Removal — \$35 / \$45 / \$55

Rubber pet hair brush or a pumice stone dragged in one direction to ball the hair up, then vacuum. Work small sections. Rubber gloves dragged across upholstery also work well. Budget 30 to 60 minutes and quote it before you start, heavy dog cars can take far longer.

Engine Bay Cleaning — \$40 / \$50 / \$65

- 1 Cold engine only
- A cold engine, and cover the alternator, any exposed intake, and the fuse box with plastic bags.
- 2 Degrease
- Koch Chemie Green Star** diluted about 1:10, sprayed on and agitated with a soft brush.
- 3 Rinse gently
- Low pressure only. Never blast a pressure washer into an engine bay, water gets into connectors and causes electrical faults you will get blamed for.
- 4 Dry and dress
- Towel dry what you can reach, then let it run for a few minutes to evaporate the rest. A light dressing on plastic covers finishes it.

Watch out. If the customer's car is newer, has exposed electronics, or you have any doubt at all, do a wipe-down by hand instead of a wet clean. A no is cheaper than an electrical repair.

Still Need To Buy

Four of these block services that are already listed for sale on our website. Buy those first.

ITEM	WHY	ROUGHLY
Adam's Visco Clay Bar Kit	You sell Clay Bar Treatment at \$50-75 and can't currently do it	\$25-35
Koch Chemie Reactive Rim Cleaner	Iron removal before clay and before coating	\$25-35
P&S Carpet Bomber	Every full detail includes shampooing carpets and seats	\$20-30
Adam's Graphene Ceramic Coating	You sell Ceramic Coating at \$225 and have nothing to apply	\$70-110
Cutting and polishing pads	Consumable, they wear out. Buy several of each	\$40-60
Carpet extractor (upgrade)	Not required, but it turns interiors from slow to fast and pays for itself	\$150-400