



## Flash and Boot Select R204 ∺ U2 W25Q128JVPIQ TR SW1 SW\_Push R211 1k D0(I01) /WP(I02) /HOLD\_/RESET 7 ♦QSPI\_SD3 QSPI\_SD2♦ C215 Sheet: /Flash and Boot Select/ File: flash\_and\_boot\_select.kicad\_sch Title: Date: KiCad E.D.A. kicad 7.0.9 ld: 3/8

## Power and Data U4 DMG2305UX-13 CHARGERD-+373 CR2 MBR120VLSFT1G CR1 MBR120VLSFT1G C302 RT6150B-33GQW 9 R310 TP3 ⊸OUSB\_D+ GPI025♦ TP1 **♦**GPI024 DUSB\_D-GPI023♦ Ř R301 Sheet: /Power and Data/ File: power\_and\_data.kicad\_sch Title: Date: ld: 4/8 KiCad E.D.A. kicad 7.0.9

## Battery Charger U5 TP4056 VBUSD--CHARGER U6 DW01A R405 1K 1k R406 C419 0.1uF + BT1 Battery\_Cell R403 Sheet: /Battery Charger/ File: battery\_charger.kicad\_sch Title: **Rev:** Id: 5/8 Date: KiCad E.D.A. kicad 7.0.9





