SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	12 in. x 24 in. Leathergrain Aluminum Sheet in Silver

1. Cut a strip of material from the sheet of proper dimensions with a band saw
2. Drill the holes using a power drill
3. Sand the edges using silicon carbide sandpaper
4. Bend the strip, by using the procedure of heat bending, according to the given tollerances

DRAWN BY	DATE
Giampietro Nigro	11/13/2019
APPROVALS:	
AU EMAIL	SINGNATURE

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
ANGLES ARE IN DEGREES
3rd Angle Projection

TOLERANCES:

ANGULAR	± 1°
FRACTIONAL	±1/8"
ONE PLACE DECIMAL	±0.1"
TWO PLACE DECIMAL	±0.05"
THREE PLACE DECIMAL	±0.005"

STOCK VENDOR INFO:	12 in. x 24 in. Leathergrain Aluminum Sheet in Silver	
Careless Broncos		
MATERIAL: Leathergrain Aluminum Sheet in Silver		
TITLE/DESC: Split frame 1		
FILE NAME:	Frame1_Unfolded	
DWG. #: P-002		REV #: C
SCALE: 1:2	SIZE **B**	SHEET 1 OF 1

SOLIDWORKS Educational Product. For Instructional Use Only.