

Module 2: Supporting Cabling and Physical Installations

Module Objectives

By the end of this module, you should be able to:

1. Summarize Ethernet standards.
 2. Summarize copper cabling and connector types.
 3. Summarize fiber optic cabling and connector types.
 4. Describe physical installation factors for rack-based installations in server rooms and data centers.
 5. Deploy and troubleshoot Ethernet cabling.
-

Lesson 2.1: Ethernet Standards

Network Data Transmission

Data transfer occurs when information is converted, or **modulated**, into signals that can travel through a transmission medium. Common signal types include:

- **Electrical current** through copper cable
- **Light pulses** through fiber optic cable
- **Radio waves** through wireless media

Higher frequencies generally allow more data to be transferred during a given period. However, actual performance also depends on the transmission medium, encoding method, distance, interference, and network equipment.

Bandwidth is the data-transfer capacity of a communication channel.

- Frequency-based bandwidth is measured in **hertz (Hz)**.
- Data-transfer capacity is commonly measured in **bits per second (bps)**.
- Common data rates include megabits per second and gigabits per second.

Bandwidth describes the capacity of a connection, not necessarily the amount of data successfully delivered. Throughput is the actual rate achieved after accounting for overhead, interference, retransmissions, and other conditions.

Ethernet Standards

Ethernet standards are defined primarily by the **Institute of Electrical and Electronics Engineers (IEEE) 802.3** family of standards. These standards specify:

- Cable and connector requirements
- Signaling and modulation methods
- Encoding methods
- Transmission speeds
- Maximum cable distances
- Compatibility requirements

Ethernet standards commonly use the **xBASE-y** naming convention:

- **x** identifies the approximate transmission speed.
- **BASE** indicates baseband signaling.
- **y** identifies the transmission medium or cable type.

Examples:

- **10BASE-T**: 10\$ Mbps baseband Ethernet using twisted-pair cable
- **100BASE-TX**: 100\$ Mbps Fast Ethernet using twisted-pair cable
- **1000BASE-SX**: 1\$ Gbps Ethernet using short-wavelength fiber optics
- **10GBASE-T**: 10\$ Gbps Ethernet using twisted-pair cable

Copper cables, including twisted-pair and coaxial cables, carry electrical signals. Electrical signals experience **attenuation**, or signal loss, as they travel. Attenuation increases with distance and can also be affected by cable quality, temperature, interference, and poor terminations.

Media Access Control and Collision Domains

Media Access Control (MAC) refers to the process used to control access to a shared network medium. A MAC address is a unique hardware address assigned to a network interface.

A **collision domain** is a portion of a network in which devices share the same communication medium and could transmit at the same time, causing signal collisions.

- Traditional hubs place all connected devices in one collision domain.
- Switches separate collision domains by providing a dedicated logical segment for each switch port.
- Full-duplex communication allows simultaneous transmission and reception, eliminating collisions on a switched link.
- Half-duplex communication permits transmission in only one direction at a time and is more susceptible to collisions.

100BASE-TX Fast Ethernet Standards

100BASE-TX is Fast Ethernet with these specifications:

- Speed: 100\$ Mbps

- Cable: Category 5 or better twisted-pair cable
- Maximum length: 100 meters, or 328 feet
- Duplex modes: half-duplex or full-duplex

Switches versus hubs:

- A hub repeats incoming signals to every port.
- A hub creates one shared collision domain.
- A switch forwards frames only to the appropriate destination port.
- A switch creates separate collision domains for its ports.
- Switches support full-duplex operation, which eliminates collisions on switched links.

Autonegotiation allows connected devices to automatically determine compatible settings, including:

- 10 Mbps or 100 Mbps speed
- Half-duplex or full-duplex operation

Autonegotiation helps devices maintain compatibility when older and newer equipment are connected.

Gigabit Ethernet Standards

Specification	Cable Type	Maximum Distance
10GBASE-T	UTP, Category 6	55 meters, or 180 feet
10GBASE-T	F/UTP, Category 6A	100 meters, or 328 feet
10GBASE-T	S/FTP, Category 7	100 meters, or 328 feet
40GBASE-T	S/FTP, Category 8	30 meters, or 100 feet

Fiber Ethernet Standards

Specification	Optics / Wavelength	Fiber Type	Maximum Distance	Connectors
100BASE-FX	1300 nm	MMF, OM1	4 km, or 2.48 miles	ST, SC, MT-RJ
100BASE-SX	850 nm	MMF, OM1 or OM2	300 m, or 984 feet	ST, SC, LC

1000BASE-SX	\$850\$ nm	MMF, OM1	\$275\$ m, or \$902\$ feet	ST, SC, LC, MT-RJ
1000BASE-SX	\$850\$ nm	MMF, OM2 or OM3	\$550\$ m, or \$1,804\$ feet	ST, SC, LC, MT-RJ
1000BASE-LX	\$1300\$ nm	MMF, OM1, OM2, or OM3	\$550\$ m, or \$1,804\$ feet	SC, LC
1000BASE-LX	\$1310\$ nm	SMF, OS1 or OS2	\$5\$ km, or \$3.1\$ miles	SC, LC
10GBASE-SR	\$850\$ nm	MMF, OM1	\$33\$ m, or \$108\$ feet	SC, LC
10GBASE-SR	\$850\$ nm	MMF, OM2	\$82\$ m, or \$269\$ feet	SC, LC
10GBASE-SR	\$850\$ nm	MMF, OM3	\$300\$ m, or \$984\$ feet	SC, LC
10GBASE-SR	\$850\$ nm	MMF, OM4	\$400\$ m, or \$1,312\$ feet	SC, LC
10GBASE-LR	\$1310\$ nm	SMF, OS1 or OS2	\$10\$ km, or \$6.2\$ miles	SC, LC

Lesson 2.2: Copper Cables and Connectors

Unshielded Twisted Pair Cable

Twisted-pair cable contains pairs of insulated copper wires twisted around each other. Each pair forms a **balanced pair**:

- One wire carries a signal with one polarity.
- The other wire carries the complementary signal with the opposite polarity.
- The receiver compares the two signals to help reject external noise.

Twisting the wires helps reduce:

- Electromagnetic interference
- Radio-frequency interference

- Crosstalk between adjacent pairs

Different pairs use different twist rates. This prevents the pairs from repeatedly aligning with one another and reduces interference.

Solid conductors:

- Use one solid copper wire per conductor.
- Provide lower signal loss and better long-distance performance.
- Are commonly used for permanent horizontal cable runs.
- Are less flexible and less suitable for repeated movement.

Stranded conductors:

- Use multiple small copper strands per conductor.
- Are flexible and resistant to damage from movement.
- Are commonly used for patch cords.
- Generally have slightly higher signal loss than solid conductors.

Unshielded Twisted Pair (UTP) has no additional metallic shielding around the pairs or cable. It is inexpensive, flexible, and widely used in Ethernet installations.

Shielded and Screened Twisted Pair Cable

Shielding reduces the effects of interference but requires proper grounding and compatible components.

Screened and Foiled Cable Types

- **ScTP:** Screened twisted pair. A conductive screen surrounds the twisted-pair cable, usually without individual foil around each pair.
- **F/UTP:** Foil over unshielded twisted pair. A foil shield surrounds all twisted pairs, but the individual pairs are unshielded.
- **FTP:** Foiled twisted pair. The cable uses foil shielding around the twisted-pair assembly. The term is commonly used for cable with an overall foil shield.

Fully Shielded and Individually Shielded Types

- **S/FTP:** A braided outer shield surrounds individually foil-shielded pairs.
- **F/FTP:** An overall foil shield surrounds individually foil-shielded pairs.
- **U/FTP:** There is no overall shield, but each twisted pair has its own foil shield.

Shielded cabling is useful in environments with substantial electrical noise, such as industrial spaces or areas near motors and high-voltage equipment.

Cat Cable Standards

Category / Class	Cable Types	Ethernet Standards Supported	Maximum Distance	Frequency
Category 5e / Class D	UTP or F/UTP	1000BASE-T	\$100\$ m, or \$328\$ ft	\$100\$ MHz
Category 6 / Class E	UTP, F/UTP, or U/FTP	1000BASE-T	\$100\$ m, or \$328\$ ft	\$250\$ MHz
Category 6 / Class E	UTP, F/UTP, or U/FTP	10GBASE-T	\$55\$ m, or \$180\$ ft	\$250\$ MHz
Category 6A / Class Ea	UTP, F/UTP, U/FTP, or S/FTP	10GBASE-T	\$100\$ m, or \$328\$ ft	\$500\$ MHz
Category 7 / Class F	S/FTP or F/FTP	10GBASE-T	\$100\$ m, or \$328\$ ft	\$600\$ MHz
Category 8 / 8.1, Class I	U/FTP or F/UTP	40GBASE-T	\$30\$ m, or \$100\$ ft	\$2{,}000\$ MHz
Category 8.2 / Class II	F/FTP or S/FTP	40GBASE-T	\$30\$ m, or \$100\$ ft	\$2{,}000\$ MHz

Twisted-Pair Connector Types

RJ45 connectors:

- Use an eight-position modular interface.
- Are commonly used with Ethernet twisted-pair cables.
- Usually contain eight contacts.
- Must be terminated using an appropriate wiring standard, such as T568A or T568B.

RJ11 connectors:

- Are smaller modular connectors commonly used for telephone wiring.
- Typically use fewer conductors than RJ45 connectors.
- Are not normally used for modern Ethernet connections.

Plenum and Riser-Rated Cable

A **plenum space** is an area used for air circulation in a heating, ventilation, and air-conditioning system. Examples include spaces above suspended ceilings and below raised floors.

Plenum spaces require special cable because smoke and toxic fumes can travel quickly through the air-handling system.

Plenum-rated cable:

- Uses fire-retardant materials such as treated PVC or FEP.
- Produces less smoke and fewer toxic fumes during a fire.
- Is marked **CMP**, meaning Communications Multipurpose Plenum.

Riser cabling passes vertically between floors or through building shafts. Riser spaces must be protected against the spread of fire, and penetrations between floors must be fire-stopped.

Riser-rated cable:

- Meets fire-safety requirements that are generally less strict than plenum requirements.
- Is marked **CMR**, meaning Communications Multipurpose Riser.
- Must not be substituted for plenum cable when the cable is installed in a plenum space.

Coaxial and Twinaxial Cable

Coaxial cable consists of:

1. A central copper conductor
2. An insulating dielectric
3. A metallic shield
4. An outer protective jacket

The central conductor carries the signal, while the shield reduces interference and serves as a return path. Coaxial cable has been used for cable television, broadband Internet, antennas, security systems, and older Ethernet technologies.

Twinaxial cable contains two inner copper conductors surrounded by insulation and shielding. It supports balanced signaling and is commonly used for short, high-speed connections in data centers, including direct-attach connections between network equipment.

Lesson 2.3: Wiring Implementation

Structured Cabling System

A structured cabling system organizes network wiring into standardized sections.

Work Area

The work area is the location where end-user devices are connected. It includes:

- Computers
- Phones

- Printers
- Wireless access points
- Wall outlets
- Patch cords connecting devices to outlets

Horizontal Cabling

Horizontal cabling runs from telecommunications outlets in work areas to a telecommunications room on the same floor. It usually consists of permanent cable installed through walls, ceilings, conduits, or cable trays.

Telecommunications Room

The telecommunications room contains network termination and distribution equipment, such as:

- Patch panels
- Access switches
- Cable management hardware
- Racks and cabinets
- Connections between horizontal and backbone cabling

Backbone Cabling

Backbone cabling connects telecommunications rooms to one another and to equipment rooms or data-center facilities. Fiber optic cable is commonly used because it supports higher bandwidth and longer distances.

Entrance Facilities and Demarc

Entrance facilities are the location where telecommunications services enter a building. The **demarc**, or demarcation point, is the boundary between the service provider's network and the customer's network.

T568A and T568B Termination Standards

T568A and T568B define the arrangement of wire pairs in an eight-position Ethernet connector.

Pin	T568A Wire Color	T568B Wire Color	10/100 Mbps Function	1/10/40 Gbps Function
1	Green/White	Orange/White	Tx+	Bi+
2	Green	Orange	Tx-	Bi-
3	Orange/White	Green/White	Rx+	Bi+

4	Blue	Blue	Unused in 10/100 Mbps	Bi+
5	Blue/White	Blue/White	Unused in 10/100 Mbps	Bi-
6	Orange	Green	Rx-	Bi-
7	Brown/White	Brown/White	Unused in 10/100 Mbps	Bi+
8	Brown	Brown	Unused in 10/100 Mbps	Bi-

For 10/100 Mbps Ethernet, pins 1 and 2 carry the transmit pair, and pins 3 and 6 carry the receive pair. Faster Ethernet standards use all four pairs.

A cable terminated with the same standard on both ends is a straight-through cable. A cable terminated with different standards on opposite ends is a crossover cable.

Patch Panels

A **patch panel** is a passive termination and connection device used to organize network cables.

Patch panels:

- Terminate permanent horizontal cable runs.
- Provide labeled ports for easier identification.
- Allow patch cords to connect cables to switches.
- Protect switch ports from frequent reconnection.
- Simplify moves, adds, and changes.
- Improve cable management and troubleshooting.

Structured Cable Installation

Cable pulling techniques:

- Plan the route before pulling cable.
- Use cable trays, conduit, and pathways where appropriate.
- Avoid excessive pulling force.
- Follow the cable manufacturer's minimum bend radius.
- Avoid sharp edges, crushing, kinking, and twisting.
- Keep data cable away from high-voltage electrical wiring when possible.
- Use appropriate pulling lubricant when required.

Labeling and running cable:

- Label both ends of every cable.
- Use consistent identifiers that show the source and destination.
- Maintain a cable schedule or documentation record.
- Run cables neatly through trays, raceways, or ladder racks.
- Separate copper, fiber, and power cables as required.
- Secure cables without compressing or damaging them.

A **service loop** is extra cable intentionally left at the termination point. It allows technicians to reposition equipment, reterminate a cable, or perform future repairs without replacing the entire run.

Cutting practices:

- Measure carefully before cutting.
- Leave enough cable for the service loop and termination.
- Keep cable ends clean and protected.
- Do not cut a cable until the route and labels have been verified.

Common installation tools:

- Cable puller or fish tape
- Cable stripper
- Punch down tool
- Block tool
- Cable crimper
- Modular plugs
- Cable tester
- Tone generator and probe
- Label maker
- Cable cutters
- Velcro straps
- Cable management hardware

Termination Tools and Techniques

Punch down tool:

- Seats individual wires into insulation-displacement connectors.
- Cuts off excess wire during termination.
- Is commonly used with patch panels and keystone jacks.

Block tool:

- Terminates wires on a punch-down block.
- Is often used with telephone blocks or other structured wiring blocks.
- Ensures conductors are seated securely and consistently.

Cable crimper:

- Attaches modular connectors to cable ends.
- Compresses connector contacts into the conductors.
- Must match the cable and connector type.

Modular plug termination:

1. Remove only the necessary amount of the outer jacket.
 2. Untwist the pairs as little as possible.
 3. Arrange wires according to T568A or T568B.
 4. Trim the conductors evenly.
 5. Insert the wires fully into the modular plug.
 6. Confirm that the jacket extends into the plug.
 7. Use a crimper to secure the plug.
 8. Test the completed cable.
-

Lesson 2.4: Fiber Optic Cables and Connectors

Fiber Optic Cable Considerations

Advantages of fiber optic cable include:

- High bandwidth
- Long transmission distances
- Low attenuation over long distances
- Resistance to EMI and RFI
- Electrical isolation between connected devices
- Reduced risk from electrical ground loops
- Smaller size and lower weight than many copper installations
- Support for high-speed backbone connections

Fiber optic cable construction includes:

1. **Core:** The central glass or plastic region through which light travels.
2. **Cladding:** The material surrounding the core. It has a different refractive index and keeps light contained through internal reflection.
3. **Buffer:** A protective layer surrounding the cladding. It protects the fiber from moisture, bending, impact, and other physical damage.
4. **Outer jacket:** The external protective covering. It may include additional strength members and may be rated for plenum or riser installation.

Fiber cables may contain one or more strands and may be bundled for backbone, trunk, or high-density installations.

Single Mode Fiber and Multimode Fiber

Single Mode Fiber (SMF):

- Has a very small core.
- Carries one primary light path.
- Supports long distances and high bandwidth.
- Commonly uses laser-based transmitters.
- Is frequently used by telecommunications providers and for long backbone links.
- Uses OS1 and OS2 classifications.

Multimode Fiber (MMF):

- Has a larger core than SMF.
- Carries multiple light paths, or modes.
- Is commonly used for shorter distances inside buildings and data centers.
- Is generally less expensive to deploy than SMF.
- Uses OM classifications.

OM1 and OM2:

- Older multimode fiber categories.
- Commonly use an orange jacket.
- Support shorter distances than newer multimode categories.
- Are used with standards such as 100BASE-FX, 100BASE-SX, and 1000BASE-SX.

OM3 and OM4:

- Higher-performance multimode categories.
- Commonly use an aqua-colored jacket.
- Support higher-speed links and longer distances than OM1 and OM2.
- Are commonly used for high-speed data-center connections.
- OM4 generally supports greater distances than OM3 at comparable speeds.

Fiber Optic Connector Types

Straight Tip (ST) connector:

- Uses a bayonet-style twist-lock mechanism.
- Has a round body.
- Was common in older fiber installations.
- Is found with both multimode and some legacy network equipment.

Subscriber Connector (SC):

- Uses a square push-pull housing.
- Is easy to insert and remove.
- May be installed as a simplex or duplex connection.
- Is common in structured fiber installations.

Local Connector (LC):

- Is smaller than an SC connector.
- Uses a push-pull latch.
- Supports high-density installations.
- Is widely used in modern switches, transceivers, and patch panels.

Fiber Optic Cable Installation

Fiber optic patch cords are short fiber cables used to connect:

- Fiber wall outlets to network interface devices
- Fiber distribution panels to switch ports
- Transceivers to patch panels

Patch cords must match the fiber type, connector type, polarity, and optical specifications of the equipment.

Ultra Physical Contact (UPC):

- Uses a polished, slightly curved end face.
- Provides low optical reflection.
- Is commonly identified by a blue connector body.
- Is used for many standard data and telecommunications connections.

Angled Physical Contact (APC):

- Uses an angled polished end face.
- Directs reflected light into the cladding rather than back toward the source.
- Produces lower return loss than UPC.
- Is commonly identified by a green connector body.
- Must not be connected directly to a UPC connector.

Fiber Distribution Panels

A **fiber distribution panel** organizes and protects fiber terminations. It performs a role similar to a copper patch panel.

Installation practices include:

- Install permanent fiber cabling through appropriate pathways.
- Route fiber through conduit to wall ports and the fiber distribution panel.
- Avoid frequently replacing permanent fiber runs because repeated handling can cause wear.
- Use fiber patch cables between wall ports and network interface devices.
- Use fiber patch cables between the distribution panel and switch ports.
- Maintain bend-radius requirements and protect connectors from contamination.

Multi-Fiber Push On Connectors

Multi-Fiber Push On (MPO) connectors terminate multiple fiber strands in a single compact ferrule.

MPO capabilities include:

- Supporting low-footprint backbone and trunk cabling
- Terminating cable bundles containing 12 or more strands
- Providing prefabricated assemblies that are usually not field-terminated
- Supporting parallel optical links
- Aggregating 10 Gbps or 25 Gbps lanes into links of 40 Gbps, 100 Gbps, or 400 Gbps

A **ferrule** is the precision component that holds and aligns fiber ends inside a connector.

Wavelength Division Multiplexing

Bidirectional Wavelength Division Multiplexing (BWDM) uses different wavelengths of light to send and receive signals over the same fiber, allowing communication in both directions.

Coarse Wavelength Division Multiplexing (CWDM) combines multiple widely spaced wavelengths on one fiber. It provides increased capacity without requiring a separate fiber for every signal.

Dense Wavelength Division Multiplexing (DWDM) combines many closely spaced wavelengths on one fiber. It provides much greater capacity and is commonly used in telecommunications and carrier networks.

Lesson 2.5: Physical Installation Factors

Rack Systems

Network and server equipment should be installed in secure areas with controlled access.

Secure installation areas help prevent:

- Unauthorized equipment access
- Cable tampering
- Theft
- Accidental disconnection
- Environmental damage

Rack systems allow equipment to be installed vertically in a compact space. Rack height is measured in rack units:

- One rack unit is written as **1U**.
- Common racks range from approximately 8U to 48U.
- Equipment must match the rack's unit dimensions and mounting requirements.

Hot aisle/cold aisle cooling:

- Equipment racks are arranged in alternating rows.
- Cold aisles face the air-intake sides of equipment.
- Hot aisles face the exhaust sides of equipment.
- This arrangement prevents hot exhaust air from mixing with cool intake air.
- Proper airflow improves equipment reliability and reduces cooling costs.

Rack security features:

- Locking doors
- Locking side panels
- Restricted-access rooms
- Surveillance cameras
- Access-control systems
- Tamper alarms
- Secured cable pathways

Humidity and Temperature

Environmental monitoring commonly includes sensors for:

- Temperature
- Humidity
- Electrical conditions
- Flooding or water leaks

Environmental sensors are important because excessive heat, high humidity, static electricity, water, or electrical irregularities can damage equipment or cause service interruptions.

Sensors can provide:

- Early warnings
- Automated alerts
- Historical environmental records
- Support for preventive maintenance
- Protection against equipment failure

Power Management

Power load and voltage must be evaluated before installing equipment. The electrical system must provide sufficient capacity for normal operation and startup loads.

Technicians should consider:

- Total equipment wattage
- Circuit capacity
- Voltage requirements
- Redundant power supplies

- Power-factor characteristics
- Future expansion
- Heat generated by electrical consumption

A **Power Distribution Unit (PDU)** distributes electrical power to equipment in a rack or data center. A PDU may provide:

- Multiple outlets
- Circuit protection
- Load monitoring
- Remote power management
- Redundant power connections

Battery backups supply temporary power when the primary electrical source fails. They provide time to:

- Continue operating briefly
- Shut down systems safely
- Start a generator
- Prevent data loss from short interruptions

An **Uninterruptible Power Supply (UPS)** provides backup power and often performs power conditioning. A UPS can protect equipment from:

- Power outages
- Voltage drops
- Voltage spikes
- Electrical noise
- Brief interruptions

Fire Suppression

Sprinkler Systems

Wet-pipe systems:

- Keep water in the pipes at all times.
- Activate quickly when heat causes a sprinkler head to open.
- May cause water damage to equipment.

Dry-pipe systems:

- Keep pressurized air or nitrogen in the pipes.
- Fill with water after a sprinkler head activates.
- Reduce the risk of accidental water release in cold areas.
- Respond more slowly than wet-pipe systems.

Pre-action systems:

- Require an initial detection event before water enters the pipes.
- Provide additional protection against accidental discharge.
- Are commonly used in data centers and other areas with sensitive equipment.

Gas-Based Systems

Halon:

- Suppresses fire without leaving water or residue.
- Is restricted or prohibited in many locations because of environmental concerns.

Clean-agent systems:

- Use gases that suppress fire without damaging electronic equipment.
- Leave little or no residue.
- Require appropriate room sealing and safety controls.

CO2 systems:

- Displace oxygen or interfere with combustion.
 - Can suppress fires without water residue.
 - Are dangerous to people at effective concentrations and require strict safety measures.
-

Lesson 2.6: Cable Troubleshooting

Specification and Limitations

Speed is the rated signaling or data rate of a connection. **Throughput** is the actual amount of usable data delivered.

Throughput may be lower than the rated speed because of:

- Protocol overhead
- Retransmissions
- Interference
- Congestion
- Faulty equipment
- Poor cable performance
- Latency

Baud rate describes the number of signal changes or symbols transmitted per second. It is associated with signaling frequency and is measured in baud. A symbol may represent one or more bits, so baud rate and bit rate are not always equal.

Bit rate is the number of bits transmitted per second and is measured in bps.

Latency is the time required for data to travel from source to destination. It is commonly measured in milliseconds.

Every cable has a distance limitation. Beyond the recommended distance, the signal may become too weak or distorted for reliable communication.

Attenuation is the reduction in signal strength as a signal travels through a medium. It is measured in decibels.

Interference is unwanted energy that disrupts a signal. **Signal-to-noise ratio (SNR)** compares the desired signal power with the background noise. A higher SNR generally indicates better signal quality.

Cable Issues

Common physical-layer components include:

- **Patch cords:** Short cables used to connect devices, wall outlets, patch panels, and switches. Damaged, poorly terminated, or incorrect patch cords can cause intermittent connections.
- **Transceivers:** Devices or modules that transmit and receive signals. A transceiver must match the cable type, connector, wavelength, speed, and distance requirements.

Cable Category Issues

When troubleshooting a cable installation:

1. **Verify the cable type.**
 - Check labels and markings on the cable jacket.
 - Identify the category, shielding type, plenum or riser rating, and fiber classification.
 - Confirm that the cable matches the installed connectors and equipment.
2. **Evaluate category suitability.**
 - Confirm that the cable category supports the required speed and distance.
 - Check whether the environment requires shielded cable.
 - Verify that the cable meets installation and fire-rating requirements.
3. **Check connector performance.**
 - Inspect connectors for damage, contamination, bent contacts, loose fittings, and poor terminations.
 - Confirm that copper conductors are arranged correctly.
 - Verify that fiber connectors match the equipment and finish type.
4. **Observe safety considerations.**
 - Follow electrical safety procedures.
 - Use appropriate personal protective equipment.
 - Avoid looking directly into fiber connectors.
 - Use proper ladder, ceiling, and cable-pulling practices.
 - Follow building and fire codes.

Cable Testers

Cable testers are used to diagnose:

- Intermittent connectivity
- Poor performance
- Wiring faults
- Incorrect terminations
- Excessive attenuation
- Crosstalk
- Distance and category compliance

Depending on the tester, it may report:

- Continuity
- Wire map
- Length
- Resistance
- Attenuation
- Insertion loss
- Crosstalk
- Return loss
- Signal performance
- Certification results

Certification testers test and document whether an installation meets the performance requirements of a cable category or standard. They help verify that installations exceed required specifications before the cabling is placed into service.

Wire Map Testers and Tone Generators

A **wire map tester** checks the electrical arrangement and continuity of conductors. It can identify:

- **Open:** A broken conductor or incomplete connection
- **Short:** Two conductors are unintentionally connected
- **Incorrect pin-out or termination:** Wires are connected to the wrong pins
- **Reversed pair or crossed pair:** A pair or conductors are connected in the wrong order
- **Split pair:** Conductors from different pairs are incorrectly combined, increasing crosstalk

A **network tone generator**, or toner, applies an audible or detectable signal to a cable. A technician uses a probe at the other end to identify and trace the cable through a bundle.

Attenuation and Interference Issues

Decibel loss, also called **insertion loss**, measures the reduction in signal power as the signal passes through cable, connectors, or other components. Longer cable links generally produce more loss and may result in:

- Higher error rates
- Retransmissions
- Reduced throughput
- Link failures

Electromagnetic interference (EMI) is unwanted electrical or magnetic energy that disrupts a signal. Sources include:

- Motors
- Generators
- Fluorescent lighting
- Power cables
- Electrical equipment

Radio-frequency interference (RFI) is interference caused by radio-frequency energy. Sources include:

- Radio transmitters
- Cellular equipment
- Wireless devices
- Broadcast equipment
- Poorly shielded electronics

Ways to reduce interference include:

- Increasing separation from noise sources
- Using shielded cable where appropriate
- Improving grounding and bonding
- Using fiber optic cable
- Avoiding parallel runs with electrical wiring

Crosstalk Issues

Near End Crosstalk (NEXT) is unwanted signal coupling measured at the same end of the cable as the transmitting signal. Higher NEXT indicates more interference between pairs.

Attenuation to Crosstalk Ratio, Near End (ACRN) compares the received signal level with near-end crosstalk at the receiving end. It indicates how strong the desired signal is relative to interference.

Attenuation-to-Crosstalk Ratio, Far End (ACRF) measures the relationship between signal attenuation and far-end crosstalk. It evaluates crosstalk that arrives at the opposite end from the transmitting source.

Power Sum Alien Crosstalk is interference caused by signals from neighboring cables rather than pairs within the same cable. It is especially important in dense, high-speed copper installations.

Fiber Optic Cable Testing Tools

A **visual fault locator (VFL)** injects visible light into a fiber. Escaping light can reveal:

- Breaks
- Cracks
- Severe bends
- Poor splices
- Incorrect connections

Dirty optical cables can cause:

- Increased insertion loss
- Poor signal levels
- Intermittent links
- Communication failures
- Permanent connector damage if contamination is not removed properly

Fiber connectors should be inspected and cleaned using approved fiber-cleaning materials before testing or connecting.

Cable Troubleshooting Strategies

Use a systematic process:

1. **Perform a physical inspection.**
 - Check for damaged jackets, kinks, sharp bends, loose connectors, crushed cable, and incorrect routing.
 - Inspect patch panels, wall outlets, transceivers, and switch ports.
 - Look for contamination on fiber connectors.
2. **Reseat the cable.**
 - Disconnect and reconnect both ends.
 - Confirm that connectors click or lock into place.
 - Verify that the cable is connected to the intended ports.
 - Replace the cable if the problem follows the cable.
3. **Verify drivers.**
 - Confirm that the network adapter driver is installed and current.
 - Check for device-manager errors.
 - Confirm compatibility between the operating system, network adapter, and transceiver.

Additional steps may include checking link lights, testing with a known-good cable, reviewing switch-port configuration, running a wire map test, tracing the cable with a toner, and checking performance with a certification tester.

Module Summary

Ethernet standards define the speed, signaling, cable requirements, connector specifications, and distance limitations of network connections. The IEEE 802.3 standards use names such as 100BASE-TX, 1000BASE-SX, and 10GBASE-T to identify speed, baseband signaling, and transmission media.

Copper cabling includes UTP, shielded and screened twisted-pair cable, coaxial cable, and twinaxial cable. Cable categories differ in supported Ethernet standards, frequency, shielding, and maximum distance. Correct connector selection, proper termination, and appropriate plenum or riser ratings are essential for safe and reliable installations.

Fiber optic cabling transmits data as light and provides high bandwidth, long distances, electrical isolation, and resistance to EMI and RFI. SMF is designed for long-distance communication, while MMF is commonly used for shorter building and data-center links. Fiber connectors such as ST, SC, LC, and MPO must be matched correctly, kept clean, and handled according to bend-radius and polishing requirements.

Structured cabling organizes network infrastructure into work areas, horizontal cabling, telecommunications rooms, backbone cabling, and entrance facilities. T568A and T568B termination standards define the order of conductors in copper connectors. Patch panels, service loops, labels, cable pathways, and proper termination tools improve organization and maintainability.

Physical installations require secure rack areas, correct rack-unit planning, appropriate hot-aisle and cold-aisle airflow, environmental monitoring, power management, and suitable fire suppression. PDUs distribute power, UPS systems provide backup and conditioning, and sensors help identify temperature, humidity, electrical, and flooding problems.

Cable troubleshooting begins with verifying specifications and limitations. Technicians should distinguish speed from throughput, understand baud rate, bit rate, latency, attenuation, interference, and crosstalk, and use appropriate testers. Physical inspection, cable reseating, wire-map testing, tone tracing, fiber fault locating, connector cleaning, and driver verification help isolate faults. Proper termination and adherence to cabling standards prevent connectivity issues and preserve network performance.

Vocabulary Terms

- **ACRF:** A measurement of attenuation-to-crosstalk ratio at the far end of a cable.
- **ACRN:** A measurement of attenuation-to-crosstalk ratio at the near end of a cable.
- **Attenuation:** The reduction in signal strength as a signal travels through a medium.
- **Backbone cabling:** Cabling that connects telecommunications rooms, equipment rooms, and other major network facilities.
- **Balanced pair:** A pair of conductors carrying complementary signals with opposite polarities.

- **Bandwidth:** The capacity of a communication channel, measured by frequency range or data rate.
- **Baseband:** A signaling method that uses the full medium to carry one transmitted signal or logical channel.
- **Baud rate:** The number of signal symbols or changes transmitted per second.
- **Bit rate:** The number of bits transmitted per second.
- **Buffer:** A protective layer surrounding the cladding of a fiber optic strand.
- **Cable category:** A classification describing the performance characteristics and supported frequencies of twisted-pair cable.
- **Cladding:** The material surrounding a fiber core that keeps light contained through internal reflection.
- **Collision domain:** A network segment in which devices share a medium and could transmit simultaneously.
- **Connector:** A hardware component used to join a cable to a device, panel, or another cable.
- **Crosstalk:** Unwanted signal interference caused by signals traveling through nearby conductors.
- **Demarc:** The demarcation point separating a service provider's network from the customer's network.
- **Dielectric:** The insulating material separating the conductor and shield in coaxial cable.
- **Duplex:** A communication mode describing whether transmission can occur in one or both directions.
- **Electrical isolation:** Separation that prevents electrical current from passing between connected systems.
- **EMI:** Unwanted electromagnetic energy that interferes with signal transmission.
- **Ferrule:** A precision component that holds and aligns fiber ends inside a connector.
- **Fiber optic cable:** Cable that transmits data as pulses of light through glass or plastic fiber.
- **Full-duplex:** Communication in which a device can transmit and receive simultaneously.
- **Half-duplex:** Communication in which devices transmit in only one direction at a time.
- **Horizontal cabling:** Permanent cabling between work-area outlets and a telecommunications room.
- **Insertion loss:** Signal power lost when a signal passes through a cable, connector, or other component.
- **Latency:** The time required for data to travel from one point to another.
- **MAC:** The process of controlling access to a shared communication medium.
- **Modulation:** The process of changing a carrier signal to represent transmitted data.
- **Multimode fiber:** Fiber with a larger core that carries multiple light paths.
- **Patch cord:** A short cable used to connect devices, outlets, patch panels, or switches.
- **Patch panel:** A passive panel that organizes and terminates network cables.
- **Plenum:** An air-handling space used for HVAC circulation.
- **Riser:** A vertical pathway through which cabling passes between building floors.
- **Shielding:** Conductive material used to reduce electromagnetic or radio-frequency interference.

- **Signal-to-noise ratio:** The ratio of desired signal power to background noise.
 - **Single mode fiber:** Fiber with a small core that carries one primary light path over long distances.
 - **Solid conductor:** A cable conductor made from one solid piece of metal.
 - **Stranded conductor:** A flexible conductor made from multiple small strands of metal.
 - **Throughput:** The actual amount of usable data delivered over a connection.
 - **Transceiver:** A device that can both transmit and receive signals.
 - **Twisted pair:** Cable made from pairs of insulated conductors twisted together to reduce interference.
 - **Unshielded twisted pair:** Twisted-pair cable without an additional metallic shield.
 - **Wavelength:** The distance between corresponding points on successive light or radio waves.
 - **Wire map:** The arrangement and continuity of conductors from one cable end to the other.
-

Acronyms

- **ACRF:** Attenuation-to-Crosstalk Ratio, Far End
- **ACRN:** Attenuation-to-Crosstalk Ratio, Near End
- **APC:** Angled Physical Contact
- **bps:** Bits per second
- **BWDM:** Bidirectional Wavelength Division Multiplexing
- **CAT:** Category
- **CMP:** Communications Multipurpose Plenum
- **CMR:** Communications Multipurpose Riser
- **CO2:** Carbon dioxide
- **CWDM:** Coarse Wavelength Division Multiplexing
- **dB:** Decibel
- **DWDM:** Dense Wavelength Division Multiplexing
- **EMI:** Electromagnetic Interference
- **F/FTP:** Foil over individually foiled twisted pair
- **F/UTP:** Foil over unshielded twisted pair
- **FEP:** Fluorinated ethylene propylene
- **FTP:** Foiled twisted pair
- **Gbps:** Gigabits per second
- **GHz:** Gigahertz
- **HVAC:** Heating, Ventilation, and Air Conditioning
- **IEEE:** Institute of Electrical and Electronics Engineers
- **kbps:** Kilobits per second
- **LC:** Local Connector
- **MAC:** Media Access Control
- **MMF:** Multimode Fiber
- **MPO:** Multi-Fiber Push On

- **MT-RJ:** Mechanical Transfer Registered Jack
- **NEXT:** Near End Crosstalk
- **nm:** Nanometer
- **OM:** Optical Multimode
- **OS:** Optical Single Mode
- **PDU:** Power Distribution Unit
- **PVC:** Polyvinyl chloride
- **RFI:** Radio-Frequency Interference
- **RJ:** Registered Jack
- **SC:** Subscriber Connector
- **ScTP:** Screened Twisted Pair
- **S/FTP:** Shielded and Foiled Twisted Pair
- **SMF:** Single Mode Fiber
- **SNR:** Signal-to-Noise Ratio
- **ST:** Straight Tip
- **TCP/IP:** Transmission Control Protocol / Internet Protocol
- **Tx:** Transmit
- **UPC:** Ultra Physical Contact
- **UPS:** Uninterruptible Power Supply
- **U/FTP:** Unshielded with individually foiled twisted pairs
- **UTP:** Unshielded Twisted Pair
- **VFL:** Visual Fault Locator
- **WAN:** Wide Area Network
- **Wi-Fi:** Wireless Fidelity
- **Hz:** Hertz
- **U:** Rack unit