REUSABLES PROGRAM FOR EHT-V DISHMACHINE



THROUGHOUT DAY

SUPPLIES:



KAY® SolidSense™ Machine Warewash Detergent



ECOLAB® Esteem DRY-ALL RINSE ADDITIVE



KAY® Liquid Delimer



KAY® Rapid Multi Surface Disinfectant Cleaner Solution



KAY® SolidSense™ Sanitizer




KAY® SolidSense™ All Purpose Super Concentrate (APSC)




Clean Sanitizer-Soaked Towels

Other supplies needed:
Reusables Rack


DAILY — When Wares Need to be Washed




- **REMOVE** collection bin from sorting station
- **PLACE** onto cart to transport




- **WIPE** up spills from sorting station with Multi Surface Disinfectant Cleaner Solution and a clean, sanitizer-soaked towel
- **RESTOCK** collection bin from below sorting station
- **DISCARD** used towel into soiled towel bucket




- **BRING** cart with bin full of wares to 3-compartment sink to pre-scrape




- **LIFT** wire cover of dish rack
- **LOAD** pre-scraped wares into dish rack




- **ENSURE** wares are racked properly
  - Fry boxes are upside down
  - Yellow clamshells are at a 45° angle



- **DO NOT** stack or nest wares
- **ONLY** run load when rack is full




- **CLOSE** dish rack cover and place into dishmachine



- **SHUT** door; machine will automatically begin cycle

NOTE: Door will not open until cycle is complete



- **REMOVE** rack when cycle is complete

ECOLAB®

Kay Chemical Company
8300 Capital Drive
Greensboro, NC 27409-9790, USA


CUSTOMER SERVICE 800.529.5458

58640.04 MCD US 58640/8004/1224 ©2024 Ecolab USA Inc. All rights reserved.


REUSABLES PROGRAM FOR EHT-V DISHMACHINE (CONTINUED)




THROUGHOUT DAY




- **PLACE** completed rack on metro shelf to complete drying
  NOTE: DO NOT restock wares until completely dry



- **PRESCRAPE**, wash, rinse and sanitize (submerged for 1 minute) collection bin in 3 compartment sink OR run bin through a dishmachine cycle




- **REPLACE** clean collection bin in bottom cabinet of sorting station




- **WASH** hands

THROUGHOUT DAY AS NEEDED — When Replacing Bins



- **SPRAY** surfaces with Multi Surface Disinfectant Cleaner Solution
- **WIPE** and clean thoroughly




- **SPRAY** surface with Multi Surface Disinfectant Cleaner Solution
- **ALLOW** to sit for 30 seconds OR air dry to sanitize




- **DISCARD** used towel into soiled towel bucket


SET-UP




- **ENSURE** machine is **OFF** and drained
  NOTE: Machine must be powered off at end of day, or power cycled at beginning of day



- **CHECK** that machine is clean and drain opening is clear; ensure drain stopper and screens are in place and wash arms spin freely



- **TURN** machine **ON**, machine will be ready for operation in approximately 10-12 minutes



- When display indicates, **REFILL** products

ECOLAB®
Kay Chemical Company
8300 Capital Drive
Greensboro, NC 27409-9790, USA

CUSTOMER SERVICE 800.529.5458


56640.04 MCD US 56640/8004/1224 ©2024 Ecolab USA Inc. All rights reserved.

REUSABLES PROGRAM FOR EHT-V DISHMACHINE (CONTINUED)




THROUGHOUT DAY

CLEAN-UP




- **DO NOT PULL OUT STAND PIPE**




- **PRESS** power button to turn **OFF** machine and allow machine components to completely cool; shut-down time may take up to three minutes


  NOTE: DO NOT open door until screen turns blue; the machine will indicate "**OFF**"



- **ENSURE** machine is drained




- **REMOVE** both top and bottom wash arms and top and bottom rinse arms
- **REMOVE** caps, then flush with water
- **CLEAN** nozzles with toothpick or paperclip and reassemble
- **REINSTALL** wash arms and ensure they spin freely



- **REMOVE** and clean screens; place screens back in machine
- **WIPE** outside of machine with clean, sanitizer soaked towel and Multi Surface Disinfectant Cleaner Solution

WEEKLY / BIMONTHLY DELIMING (as needed)




- **PRESS DELIME** button and follow on-screen instructions to start automated deliming
- **REPLACE** bottle of Liquid Delimer when empty

  NOTE: Delime more frequently as needed


IF WAREWASH MACHINE IS OUT OF SERVICE, USE THE 3-COMPARTMENT SINK PROCEDURE AS FOLLOWS: DRAIN SINKS AND FILL WITH FRESH SOLUTIONS OF SOLIDSENSE ALL PURPOSE SUPER CONCENTRATE (APSC) AND SOLIDSENSE SANITIZER BEFORE WASHING REUSABLE WARES

DAILY — When Wares Need to be Washed




- **REMOVE** collection bin from sorting station
- **PLACE** onto cart to transport

SINK SET UP



- Middle sink should remain empty for rinsing

  NOTE: Dispense Sanitizer Solution at recommended temperature above, however, when testing ppm of sanitizer, allow Solution to cool to 75°F when testing; follow Testing Sanitizers KAY Card for detailed steps



- **PLACE** wares in **HOT** (110-120°F) APSC Solution; clean wares with a clean, sanitizer-soaked towel

ECOLAB®

Kay Chemical Company
8300 Capital Drive
Greensboro, NC 27409-9790, USA


CUSTOMER SERVICE 800.529.5458

58640.04 MCD US 58640/8004/1224 ©2024 Ecolab USA Inc. All rights reserved.


REUSABLES PROGRAM FOR EHT-V DISHMACHINE (CONTINUED)




THROUGHOUT DAY



- **RINSE** items in clean, **HOT** (110-120°F) water from tap or sprayer



- **PLACE** in Sanitizer Solution for a minimum of one minute



- REMOVE wares and place into ware racks and onto metro shelf to air dry

ECOLAB®
Kay Chemical Company
8300 Capital Drive
Greensboro, NC 27409-9790, USA

CUSTOMER SERVICE 800.529.5458

58640.04 MCD US 58640/8004/1224 ©2024 Ecolab USA Inc. All rights reserved.