REUSABLES PROGRAM FOR TSC DISHMACHINE



THROUGHOUT DAY

SUPPLIES:



KAY® SolidSense™ Machine Warewash Detergent



KAY® QSR TSC Rinse Additive



ECOLAB® Dish Machine Pellet Sanitizer (for warewash)



KAY® Liquid Delimer



KAY® Rapid Multi Surface Disinfectant Cleaner Solution



KAY® SolidSense™ Sanitizer




KAY® SolidSense™ All Purpose Super Concentrate (APSC)




KAY® Delimer Tablets


DAILY — When Wares Need to be Washed




- **REMOVE** collection bin from sorting station
- **PLACE** onto cart to transport




- **WIPE** up spills from sorting station with Multi Surface Disinfectant Cleaner Solution and a clean, sanitizer-soaked towel
- **RESTOCK** collection bin from below sorting station
- **DISCARD** used towel into soiled towel bucket




- **BRING** cart with bin full of wares to 3-compartment sink
- **PRE-SCRAPE** food waste into trash **AND RINSE** wares to make sure they are as clean as possible before putting into machine




- **LIFT** wire cover of dish rack
- **LOAD** pre-scraped wares into dish rack




- **ENSURE** wares are racked properly
  - Fry boxes are upside down
  - Yellow clamshells are at a 45° angle




- **DO NOT** stack or nest wares
- **ONLY** run load when rack is full



- **CLOSE** dish rack cover and place into dishmachine



- **SHUT DOOR**; machine will automatically begin cycle



- **DO NOT** open door until machine displays "Ready Open door and insert rack"
- **REMOVE** rack

ECOLAB®

Kay Chemical Company
8300 Capital Drive
Greensboro, NC 27409-9790, USA


CUSTOMER SERVICE 800.529.5458

59445D2 MCD US 59445/8002/1224 ©2024 Ecolab USA Inc. All rights reserved.


REUSABLES PROGRAM FOR TSC DISHMACHINE (CONTINUED)




THROUGHOUT DAY




- **PLACE** completed rack on metro shelf to complete drying
  NOTE: DO NOT restock wares until completely dry



- **PRESCRAPE**, wash, rinse and sanitize (submerged for 1 minute) collection bin in 3 compartment sink OR run bin through a dishmachine cycle




- **REPLACE** clean collection bin in bottom cabinet of sorting station




- **WASH** hands

THROUGHOUT DAY AS NEEDED — When Replacing Bins



- **SPRAY** surfaces with Multi Surface Disinfectant Cleaner Solution
- **WIPE** and clean thoroughly




- **SPRAY** surface with Multi Surface Disinfectant Cleaner Solution
- Allow to **SIT** for 30 seconds, then **DRY** with clean paper towel OR air dry to sanitize




- **DISCARD** used towel into soiled towel bucket


SET-UP




- **ENSURE** machine is **OFF** and drained




- **CHECK** that machine is clean and drain opening is clear; ensure drain stopper and screens are in place and wash arms spin freely



- **TURN** machine **ON**; set soil level setting (see guide on page 2)



- **CHECK** Detergent, Rinse Additive and Sanitizer levels; **REPLACE** if low
- **ENSURE** cover is completely shut



- Daily, after first cycle, **CHECK** chlorine sanitizer concentration level is at 100ppm

ECOLAB®

Kay Chemical Company
8300 Capital Drive
Greensboro, NC 27409-9790, USA

CUSTOMER SERVICE 800.529.5458


59445:02 MCD US 59445/8002/1224 ©2024 Ecolab USA Inc. All rights reserved.

REUSABLES PROGRAM FOR TSC DISHMACHINE (CONTINUED)




THROUGHOUT DAY


CLEAN-UP




- Turn machine **OFF**



- **ENSURE** machine is drained




- **REMOVE** both top and bottom wash arms and top and bottom rinse arms
- **REMOVE** caps, then flush with water
- **CLEAN** nozzles with toothpick or paperclip and reassemble
- **REINSTALL** wash arms and ensure they spin freely




- **REMOVE** and clean screens; place screens back in machine
- **WIPE** outside of machine with clean, sanitizer soaked towel and Multi Surface Disinfectant Cleaner Solution


DELIMING WEEKLY/BI-MONTHLY/AS NEEDED




- Turn machine **OFF**



- **PRESS** and **HOLD** DELIME button on display
- **FOLLOW** display prompts to FILL
- **OPEN** door



- **PLACE** 6 Delimer Tablets OR a half gallon of Liquid Delimer into Warewash machine
- Display will indicate CLOSE DOOR
- **START** DELIME; allow cycle to run for 20 minutes (Cycle will need to be manually timed)



- Display will indicate **PRESS** DELIME TO STOP CYCLE; once pressed, sump will be filled with fresh water to rinse inside of machine
- At completion of rinse cycle, FINAL DRAIN is displayed and machine turns off
- **CHECK** machine and run an additional 20-minute manually-timed cycle with 2 additional tablets of delimer, if necessary

ECOLAB®
Kay Chemical Company
8300 Capital Drive
Greensboro, NC 27409-9790, USA

CUSTOMER SERVICE 800.529.5458

5944502 MCD US 59445/8002/1224 ©2024 Ecolab USA Inc. All rights reserved.

REUSABLES PROGRAM FOR TSC DISHMACHINE (CONTINUED)




THROUGHOUT DAY

IF WAREWASH MACHINE IS OUT OF SERVICE, USE THE 3-COMPARTMENT SINK PROCEDURE AS FOLLOWS: DRAIN SINKS AND FILL WITH FRESH SOLUTIONS OF SOLIDSENSE ALL PURPOSE SUPER CONCENTRATE (APSC) AND SOLIDSENSE SANITIZER BEFORE WASHING REUSABLE WARES




- **REMOVE** collection bin from sorting station
- **PLACE** onto cart to transport




- Middle sink should remain empty for rinsing


  NOTE: Dispense Sanitizer Solution at recommended temperature above, however, when testing ppm of sanitizer, allow Solution to cool to 75°F when testing; follow Testing Sanitizers KAY Card for detailed steps




- **PLACE** wares in **HOT** (110-120°F) APSC Solution; clean wares with a clean, sanitizer-soaked towel



- **RINSE** items in clean, **HOT** (110-120°F) water from tap or sprayer



- **PLACE** in Sanitizer Solution for a minimum of one minute



- REMOVE wares and place into ware racks and onto metro shelf to air dry

ECOLAB®
Kay Chemical Company
8300 Capital Drive
Greensboro, NC 27409-9790, USA
CUSTOMER SERVICE 800.529.5458

59445.02 MCD US 59445/8002/1224 ©2024 Ecolab USA Inc. All rights reserved.