

Customer : ETD

Type: A380

Rev. Date: Jan 01, 2016

Manual : TSM Selected applicability : ALL

36-22-71-991-00100-00-A / SHEET 2/2 - Engine 1 Pylon Loop A Location Zone and Access Panel "Open Circuit"

| | FAULT LOCATION ZONE | | | | | | | | | |
|------------|---------------------|-------|------|----------------|----------------|--------------|-------------|----|------|-----------------|
| LOC | STA | RT OF | ZONE | MID POSITION | | | END OF ZONE | | | ACCESS PANEL(S) |
| | m | ft | ITEM | m | ft | ITEM | m | ft | ITEM | |
| 053 | | | | 1.56 | 5.12 | 62 | | | | |
| 054 | | | | 3.60 | 11.81 | 62 | | | | |
| 055 | | | | 5.64 | 18.50 | 62 | | | | |
| 056 | | | | 1.72 | 5.64 | 4089 | | | | |
| 057 | | | | 3.76 | 12.34 | 4089 | | | | |
| 058 | | | | 5.80 | 19.03 | 4089 | | | | |
| 059 | | | | 7.84 | 25.72 | 4089 | | | | |
| 060 | | | | 9.88 | 32.41 | 4089 | | | | |
| 061 | | | | 11.91 | 39.07 | 4089 | | | | |
| 062 | | | | 13.95 | 45.77 | 4089 | | | | |
| 063 | | | | 15.99 | 52.46 | 4089 | | | | |
| 064 | | | | 18.03 | 59.15 | 4089 | | | | |
| 065 | | | | 20.07 | 65.85 | 4089 | | | | |
| 066 | | | | 22.10 | 72.51 | 4089 | | | | |
| 067 | | | | 24.14 | 79.20 | 4089 | | | | |
| 068 069 | | | | 26.18 28.22 | 85.89 92.59 | 4089 4089 | | | | |
| 070 | | | | 30.26 | 99.28 | 4089 | | | | |
| 070 | | | | | | 4089 | | | | |
| 071 | | | | 34.33 | 112.63 | 4089 | | | | |
| 072 | | | | 1.97 | 6.46 | 924 | | | | |
| 074 | | | | 4.01 | 13.16 | 924 | | | | |
| 075 | | | | 6.05 | 19.85 | 924 | | | | |
| 076 | | | | 8.09 | 26.54 | 924 | | | | |
| 077 | | | | 10.12 | 33.20 | 924 | | | | |
| 078 | | | | 12.16 | 39.90 | 924 | | | | |
| 079 | | | | 14.20 | 46.59 | 924 | | | | |
| 080 | | | | 16.24 | 53.28 | 924 | | | | |
| 081 | | | | 18.28 | 59.97 | 924 | | | | |
| 082 | | | | 20.31 | 66.63 | 924 | | | | |
| 083 | | | | 22.35 | 73.33 | 924 | | | | |
| 084 | | | | 24.39 | 80.02 | 924 | | | | |
| 085 | | | | 26.43 | 86.71 | 924 | | | | |
| 086 | | | | 28.47 | 93.41 | 924 | | | | |
| 087 | | | | 2.04 | 6.69 | 7592 | | | | |
| 088 | | | | 4.08 | 13.39 | 7592 | | | | |
| 089 | | | | 6.12 | 20.08 | 7592 | | | | |
| 090 | | | | 8.16 | 26.77 | 7592 | | | | |
| 091 | | | | 10.20 | 33.46 | 7592 | | | | |
| 092 | | | | 12.24 | 40.16 | 7592 | | | | |
| 093 | | | | 14.27 | 46.82 | 7592 | | | | |
| 094 095 | | | | 2.09 | 6.86 | 22 22 | | | | |
| 095 | | | | 4.13 6.17 | 13.55 20.24 | 22 | | | | |
| 096 | | | | 8.21 | 26.94 | 22 | | | | |
| 097 | | | | 10.24 | 33.60 | 22 | | | | |
| 099 | | | | 1.53 | 5.02 | 14 | | | | |
| 100 | | | | 3.57 | 11.71 | 14 | | | | |
| 100 | | l | | 0.01 | 11.71 | 14 | | | | |

NOTE:

THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN).

ALL THE WIRE IDENTS ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362271_2_BTAA_02_00

Figure 36-22-71-991-00100-A- / SHEET 2/2 - Engine 1 Pylon Loop A Location Zone and Access Panel "Open Circuit" ** ON A/C ALL

Print Date: January 19, 2016 Page 1 of 1