

Customer : ETD

Type : A380

Rev. Date: Jan 01, 2016

Manual : TSM Selected applicability : ALL

36-22-71-991-02700-00-B / SHEET 1/2 - Right Wing Loop 'B'- Fault Location Zone and Access Table (Open Circuit)

FAULT LOCATION ZONE										
LOC	STA	START OF ZONE			MID POSITION			ID OF Z	ONE	ACCESS PANEL(S)
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
001				1.25	4.10	180				
002				2.50	8.20	180				
003				0.36	1.18	186				
004				1.60	5.25	186				
005				2.85	9.35	186				
006 007				4.10 5.35	13.45 17.55	186 186				
007				6.60	21.65	186				
009				7.85	25.75	186				
010				9.10	29.86	186				
011				10.34		186				
012				0.77	2.53	7555				
013				2.02	6.63	7555				
014				3.27	10.73	7555				
015				4.52	14.83	7555				
016				5.77	18.93	7555				
017				7.01	23.00	7555				
018				8.26	27.10	7555				
019				9.51	31.20	7555				
020 021				10.76 12.01	35.30 39.40	7555 7555				
021					43.50	7555				
022				14.51	47.60	7555				
023				0.76	2.49	348HF				621EB/621FB
025				2.45	8.04	348HF				621EB/621FB
026				4.13	13.55	348HF				621EB/621FB
027				5.81	19.06	348HF				621EB/621FB
028				7.50	24.61	348HF				621EB/621FB
029				9.18	30.12	348HF				621EB/621FB
030				10.87	35.66	348HF				621EB/621FB
031				12.55	41.17	348HF				621EB/621FB
032	9.43	30.94	348HF	0.38	1.25	301HF	0.69	2.26	303HF	621EB/621FB
033	12.10	39.70	348HF	3.05	10.01	301HF	0.62	2.03	304HF	621EB/621FB
034	0.76	2.49 0.72	301HF 302HF	1.07	3.51 3.28	303HF 304HF	0.03	0.10 1.94	305HF 306HF	621GB/621HB/621SB/621TB 621JB/621KB/621UB/621VB
036	1.46	4.79	303HF	0.42	1.38	305HF	1.61	5.28	307HF	621LB
037	1.39	4.56	304HF	0.42	3.22	306HF	1.18	3.87	308HF	621XB/621YB
038	0.81	2.66	305HF	2.00	6.56	307HF	1.74	5.71	309HF	622AT/622BT
039	1.37	4.49	306HF		5.15	308HF	1.67			622CB/622EB
040	2.39	7.84	307HF	2.13	6.99	309HF	2.16			622HB
041	1.96	6.43	308HF	2.06	6.76	310HF	2.26	7.41	312HF	622JB/622LB/622NB
042	2.51	8.23	309HF	2.54	8.33	311HF	0.51	1.67	314HF	622PB/622QB/622RB
043	0.26	0.85	311HF	2.64	8.66	312HF	1.68	5.51		622TB/622VB
044	0.36	1.18	312HF	0.90	2.95	314HF	4.35	14.27	349HF	483AL/483BL/483CL/483DL
045				1.31	4.30	349HF				483AL/483BL/483CL/483DL
046				2.99	9.81	349HF				483AL/483BL/483CL/483DL
047				4.68	15.35	349HF				483AL/483BL/483CL/483DL
048				0.27	0.89	757 757				
049 050				1.52 2.76	4.99 9.06	757 757				
050				4.01	13.16	757				
052				0.24	0.79	4065				
002			I	0.24	0.18	4000				

L_TS_362271_2_GGAA_01_01

Figure 36-22-71-991-02700-B- / SHEET 1/2 - Right Wing Loop 'B'- Fault Location Zone and Access Table (Open Circuit)

** ON A/C ALL

Print Date: January 19, 2016