



Customer : ETD  
Type : A380  
Rev. Date : Jan 01, 2016

Manual : TSM  
Selected applicability : ALL

36-22-11-991-03400-00-B / SHEET 1/2 - Right Wing, Loop 'B' -  
Fault Location Zone and Access Table (Short Circuit/Overheat)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
001				10.87	35.66	186				
002				10.84	35.56	7555				
003				13.74	45.08	348HF				621EB/621FB
004	13.54	44.42	348HF	0.36	1.18	301HF	1.18	3.87	301HF	621EB/621FB
005	13.90	45.60	348HF	0.72	2.36	301HF	1.54	5.05	301HF	621EB/621FB
006	0.26	0.85	301HF	1.09	3.58	301HF	1.91	6.27	301HF	621EB/621FB
007	0.63	2.07	301HF	1.45	4.76	301HF	2.27	7.45	301HF	621EB/621FB
008	0.99	3.25	301HF	1.81	5.94	301HF	2.63	8.63	301HF	621EB/621FB
009	1.35	4.43	301HF	2.18	7.15	301HF	3.00	9.84	301HF	621EB/621FB
010	1.72	5.64	301HF	2.54	8.33	301HF	0.11	0.36	302HF	621EB/621FB
011	2.08	6.82	301HF	2.90	9.51	301HF	0.47	1.54	302HF	621EB/621FB
012	2.44	8.01	301HF	3.27	10.73	301HF	0.84	2.76	302HF	621EB/621FB
013	2.81	9.22	301HF	0.38	1.25	302HF	1.20	3.94	302HF	621FB
014	3.17	10.40	301HF	0.74	2.43	302HF	0.09	0.30	303HF	621FB
015	0.28	0.92	302HF	1.11	3.64	302HF	0.46	1.51	303HF	621FB
016	0.65	2.13	302HF	1.47	4.82	302HF	0.82	2.69	303HF	621FB
017	1.01	3.31	302HF	0.36	1.18	303HF	1.18	3.87	303HF	621GB/621HB/621SB/621TB
018	1.37	4.49	302HF	0.73	2.40	303HF	1.55	5.09	303HF	621GB/621HB/621SB/621TB
019	0.27	0.89	303HF	1.09	3.58	303HF	1.91	6.27	303HF	621GB/621HB/621SB/621TB
020	0.63	2.07	303HF	1.45	4.76	303HF	2.27	7.45	303HF	621GB/621HB/621SB/621TB
021	0.99	3.25	303HF	1.82	5.97	303HF	2.64	8.66	303HF	621GB/621HB/621SB/621TB
022	1.36	4.46	303HF	2.18	7.15	303HF	0.31	1.02	304HF	621GB/621HB/621SB/621TB
023	1.72	5.64	303HF	2.54	8.33	303HF	0.67	2.20	304HF	621GB/621HB/621SB/621TB
024	2.08	6.82	303HF	0.22	0.72	304HF	1.04	3.41	304HF	621JB/621KB/621UB/621VB
025	2.45	8.04	303HF	0.58	1.90	304HF	1.40	4.59	304HF	621JB/621KB/621UB/621VB
026	0.12	0.39	304HF	0.94	3.08	304HF	1.76	5.77	304HF	621JB/621KB/621UB/621VB
027	0.48	1.57	304HF	1.31	4.30	304HF	2.13	6.99	304HF	621JB/621KB/621UB/621VB
028	0.85	2.79	304HF	1.67	5.48	304HF	2.49	8.17	304HF	621JB/621KB/621UB/621VB
029	1.21	3.97	304HF	2.03	6.66	304HF	2.85	9.35	304HF	621JB/621KB/621UB/621VB
030	1.57	5.15	304HF	2.40	7.87	304HF	3.22	10.56	304HF	621JB/621KB/621UB/621VB
031	1.94	6.36	304HF	2.76	9.06	304HF	0.33	1.08	305HF	621JB/621KB/621UB/621VB
032	2.30	7.55	304HF	3.12	10.24	304HF	0.69	2.26	305HF	621JB/621KB/621UB/621VB
033	2.66	8.73	304HF	0.24	0.79	305HF	1.06	3.48	305HF	621LB
034	3.03	9.94	304HF	0.60	1.97	305HF	1.42	4.66	305HF	621LB
035	0.14	0.46	305HF	0.96	3.15	305HF	1.78	5.84	305HF	621LB
036	0.50	1.64	305HF	1.33	4.36	305HF	0.04	0.13	306HF	621LB
037	0.87	2.85	305HF	1.69	5.54	305HF	0.40	1.31	306HF	621LB
038	1.23	4.04	305HF	2.05	6.73	305HF	0.76	2.49	306HF	621LB
039	1.59	5.22	305HF	0.31	1.02	306HF	1.13	3.71	306HF	621MB
040	1.96	6.43	305HF	0.67	2.20	306HF	1.49	4.89	306HF	621MB
041	0.21	0.69	306HF	1.03	3.38	306HF	0.20	0.66	307HF	621MB
042	0.57	1.87	306HF	1.40	4.59	306HF	0.57	1.87	307HF	621MB
043	0.94	3.08	306HF	0.11	0.36	307HF	0.93	3.05	307HF	622AT/622BT
044	1.30	4.27	306HF	0.47	1.54	307HF	1.29	4.23	307HF	622AT/622BT
045	0.01	0.03	307HF	0.84	2.76	307HF	1.66	5.45	307HF	622AT/622BT
046	0.38	1.25	307HF	1.20	3.94	307HF	2.02	6.63	307HF	622AT/622BT
047	0.74	2.43	307HF	1.56	5.12	307HF	2.38	7.81	307HF	622AT/622BT
048	1.10	3.61	307HF	1.93	6.33	307HF	2.75	9.02	307HF	622AT/622BT
049	1.47	4.82	307HF	2.29	7.51	307HF	0.01	0.03	308HF	622AT/622BT
050	1.83	6.00	307HF	2.65	8.69	307HF	0.37	1.21	308HF	622AT/622BT
051	2.19	7.19	307HF	3.02	9.91	307HF	0.74	2.43	308HF	622AT/622BT
052	2.56	8.40	307HF	0.28	0.92	308HF	1.10	3.61	308HF	622CB/622EB

L\_TS\_362211\_2\_EPAA\_01\_00

Figure 36-22-11-991-03400-B- / SHEET 1/2 - Right Wing, Loop 'B'  
- Fault Location Zone and Access Table (Short Circuit/Overheat)

\*\* ON A/C ALL