

Customer : ETD

Type : A380

Rev. Date: Jan 01, 2016

Manual : TSM Selected applicability : ALL

36-22-71-991-02500-00-B / SHEET 1/2 - Left Wing Loop 'B'- Fault Location Zone and Access Table (Open Circuit)

	FAULT LOCATION ZONE									
LOC	START OF ZONE			MID POSITION			END OF ZONE			ACCESS PANEL(S)
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	, ,
001				1.20	3.94	140				
002				2.40	7.87	140				
003				0.20	0.66	146				
004				1.40	4.59	146				
005				2.60	8.53	146				
006 007				3.80 5.00	12.47 16.40	146 146				
007				6.19	20.31	146				
009				7.39	24.25	146				
010				8.59	28.18	146				
011				9.79	32.12	146				
012				0.19	0.62	7547				
013				1.38	4.53	7547				
014				2.58	8.46	7547				
015				3.78	12.40	7547				
016				4.98	16.34	7547				
017				6.18	20.28	7547				
018				7.37	24.18	7547				
019				8.57	28.12	7547				
020 021				9.77	32.05	7547				
021				10.97 12.17	35.99 39.93	7547 7547				
022				0.96	3.15	248HF				521EB/521FB
023				2.58	8.46	248HF				521EB/521FB
025				4.20	13.78	248HF				521EB/521FB
026				5.81	19.06	248HF				521EB/521FB
027				7.43	24.38	248HF				521EB/521FB
028				9.04	29.66	248HF				521EB/521FB
029				10.66	34.97	248HF				521EB/521FB
030				12.28	40.29	248HF				521EB/521FB
031				13.89	45.57	248HF				521EB/521FB
	11.46		248HF	2.39	7.84	226HF	2.62	8.60	228HF	521EB/521FB
033	0.02	0.07	226HF	0.24	0.79	228HF	2.44	8.01	229HF	521GB/521HB/521SB/521TB
034 035	2.58	8.46 1.41	226HF 228HF	2.80	9.19 8.63	228HF 229HF	1.75	5.74	230HF 232HF	521GB/521HB/521SB/521TB 521JB/521KB/521UB/521VB
036	0.43 0.25	0.82	228HF	1.94	6.36	230HF	0.55 0.01	1.80 0.03	232HF	521LB
037	2.81	9.22	229HF	0.74	2.43	232HF	0.46	1.51	234HF	522AT/522BT
037	0.01	0.03	231HF	0.74	0.66	233HF	0.48	0.92	235HF	522CB/522EB
	0.92	3.02	232HF	0.65	2.13			2.20	236HF	522HB
040	0.38	1.25	233HF	0.47	1.54	235HF		2.46	237HF	522JB/522LB/522NB
041	0.83	2.72	234HF	0.85	2.79	236HF	0.73	2.40	238HF	522PB/522QB/522RB
042	0.65	2.13	235HF	0.93	3.05	237HF	0.03	0.10	249HF	522TB/522VB
043	1.04	3.41	236HF	0.91	2.99	238HF	2.59	8.50	249HF	523AT
044				0.13	0.43	249HF				453AL/453BL/453DL/453EL
045				1.75	5.74	249HF				453AL/453BL/453DL/453EL
046				3.37	11.06	249HF				453AL/453BL/453DL/453EL
047				4.98	16.34	249HF				453AL/453BL/453DL/453EL
048				0.44	1.44	767				
049				1.64	5.38	767				
050				2.84	9.32	767				
051				4.04 5.24	13.25 17.19	767 767				

L_TS_362271_2_GCAA_01_01

Figure 36-22-71-991-02500-B- / SHEET 1/2 - Left Wing Loop 'B'- Fault Location Zone and Access Table (Open Circuit)

** ON A/C ALL

Print Date: January 19, 2016 Page 1 of 1