Integrated Controller JPM-C210E

User's Guide



B&S MEDIA CO., LTD.

Table of Contents

1	Introduction	3
2	Physical Description	5
3	Operation	9
4	Customer Support	4
5	Warranty	5

1. Introduction

1.1 Specifications

	Description		
	CPU	Samsung 800MHz S3C6410 CPU	
General	OS	WinCE 6.0	
General	Size / Weight	440x240x44.4mm(1U) / 2.0kg	
	Operating Temperature	-10℃~80℃	
Momory	Internal Memory	128MB NAND Flash/256MB DDR SDRAM	
Memory	SD Card	1slot	
VIDEO	VGA	2ch Input, 2ch Output	
VIDEO	Composite	2ch Input, 2ch Output	
	VGA	2ch Input, 2ch Output	
AUDIO	Composite	2ch Input, 2ch Output	
	MIC	2ch Input, 2ch Output	
	SERIAL (RS232/RS485)	4 PORT/2PORT	
	USB	USB HUB 3PORT	
	LAN	10/100 Ethernet HUB 3PORT	
INTERFACE	IR	3 PORT	
	RELAY	9 EA	
	Camera Input	Composite 1PORT	
	Touch panel	JPM-CL7A interface	
Supply Power		DC 12.0V / 2.0A	

1.2 Physical Description

Man Controller




Accessory




2. Physical Description

2.1 Front View



- 1 Power switch
 - Main Power switch
- **② COM port Indicator LED**
- **③** Relay port Indicator LED
- 4 VGA / AV Indicator LED
- **⑤** IR Input window
 - IR signal input
- **6** LAN port Indicator LED
- **7** Reset Switch

2.2 Rear View



1 Audio output port: Port to connect Audio output signal




Female RCA Connector

- 2 Audio input port : Port to Audio input signal
 - Composite audio input port




Female RCA Connector

VGA audio input port



MIC input port




③ Video Input/Output Port: I/O port to connect Composite Video



- A/V Video 2X2 Matrix switcher support
- 4 VGA Video Input/Output Port: I/O port to connect VGA Video signal




- VGA 2X2 Matrix switcher support
- **⑤ COM1, COM2, COM3, COM4 Communication Port**: Port to communicate with external devices




COM port	9-pin D	Connection	
	Pin2	RX line	
COM1	Pin3	TX line	RS232
	Pin5	Signal ground	
	Pin1	TRX+	RS485
	Pin6	TRX-	
	Pin2	RX line	
COM2	Pin3	TX line	RS232
	Pin5	Signal ground	
	Pin1	TRX+	RS485
	Pin6	TRX-	
	Pin2	RX line	
сомз	Pin3	TX line	RS232
	Pin5	Signal ground	
	Pin2	RX line	
COM4	Pin3	TX line	RS232
	Pin5	Signal ground	

(6) Relay port : 9 Relay Ports Control



- IR port: 3 IR port control



- ? Power port
 - DC12V, 2A Adaptor connection port
- **8** Video IN
 - Composite Video input port



- **9** Touch panel connection port
 - JPM-CL7A Touch Panel connection port

NOTE: You must use cables only provided with JPM-CL7.

- 10 LAN port
 - 10/100 Ethernet HUB 3port
- ① USB port
 - USB HUB 3port

3. Operations

3.1 Main Screen



Buttons	Description
1. Logo	It indicates logo of School/Company.
2. MAIN	It returns to the Start-up screen
3. PROJECTOR	It transfers to the PROJECTOR Control screen.
4. DVD/VCR	It transfers to the DVD/VCR Control screen.
5. LIGHTING	It transfers to the Lighting Control screen.
6. PROJECTION TV	It transfers to the PROJECTION TV Control screen.
7. AIRCON	It transfers to the AIRCONDITIONER Control screen.
8. CAMERA	It transfers to the CAMERA Control screen.
9. PC (PC-based	It turns on Projector power, descends projector
Lecture/Presentation)	screen, and ready to use PC.
10. Video (Video/VCR-based	It turns on Projector power, descends projector
Lecture/Presentation)	screen, and ready to use DVD/VCR.
11. EXIT	It turns off Projector, ascends projector screen, and
(Lecture/Presentation End)	returns to the main screen.

3.2 PROJECTOR

- It controls Projector power, selects external input devices, ascends/descends/stops projector screen, increases/decreases microphone 1, 2, and Sound Volume.



1. PROJECTOR ON	2. PROJECTOR OFF	3. PROJECTOR	4. PC MODE
		MUTE	
5. NOTEBOOK	6. DVD/VCR MODE	7. DATA VIEW	8. SCREEN UP
MODE		MODE	
9. SCREEN STOP	10. SCREEN DOWN	11. MIC1 VOLUME	12. MIC1 VOLUME
		UP	DOWN
13. MIC1 VOLUME	14. MIC2 VOLUME	15. MIC2 VOLUME	16. MIC2 VOLUME
MUTE ON/OFF	UP	DOWN	MUTE ON/OFF
17. SOUND	18. SOUND	19. SOUND MUTE	20. VOLUME LEVEL
VOLUME UP	VOLUME DOWN	ON/OFF	

3.3 DVD/VCR

- It controls DVD/VCR and shows video image.



1. DVD MODE	2. Video Input	3. VCR MODE	4. REC
	screen		
5. STOP	6. REW	7. DVD/ VCR Power ON/OFF	8. FF
9. PAUSE	10. PLAY		

3.4 LIGHTING

- It controls lightings.



1 Podium Lighting	2 Middle lighting	3 Side lighting	4 Indirect lighting
-------------------	-------------------	-----------------	---------------------

3.5 PROJECTION TV:

- It controls Projection TV.



1. Monitor 1 Power	2. External Video	3. Monitor 2 Power	4. External Video
ON/OFF	Input Selection	ON/OFF	Input Selection
5. Projection TV	6. External Video	7. Projection TV	8. projection TV
Power ON/OFF	Input Selection	Volume UP	Volume Down
9. Monitor 2 Power	10. External Video	11. Monitor 4	12. External Video
ON/OFF	Input Selection	Power ON/OFF	Input Selection

3.6 AIRCON

- It controls air conditioner.



1. Operating mode	2. Airflow direction	3. Select	4. Cancel
5. Temperature	6. Temperature	7. Power ON	8. Power OFF
adjustment (higher)	adjustment (lower)		

3.6 CAMERA

- It controls camera.



1. Power ON	2. Power OFF	3. PEESET No.1	4. PEESET No.2
5. PEESET No.3	6. PEESET No.4	7. PEESET No.5	8. PEESET No.6
9. PAN to left	10. PAN to right	11. Tilt to up	12. Tilt to down
direction	direction	direction	direction
13. FAST ZOOM IN	14. FAST ZOOM	15. SLOW ZOOM IN	16. SLOW ZOOM
	OUT		OUT

4. Customer Support



#807 Daerung Post Tower II, 182-13, Guro-3dong, Guro-ku, Seoul, Korea(152-790)

TEL: +82.2.588.3323 | Fax: +82.2.588.3659

www.bnsmedia.co.kr support@bsmedia.cokr

- Pictures/Images in this guide pictures are to help user's understanding. It can be subject to change without prior notice.
- Product size and performance in this guide can be subject to change to improve quality without prior notice.
- The contents of this guide can be subject to change by the circumstances of S/W version or B&S MEDIA without prior notice.

5. Warranty

16