OpenTX

Foreword

2.2

A frequent complaint about **OpenTX** is its lack of documentation, and therefore its difficulty of use. This guide sets out to try to rectify that. It is also the case that **OpenTX** is an evolving program, like most software. This brings the problem that much of what has been written in the past is now partially or wholly out of date.

Several principles were used in the writing of this guide:

- It does not try to cover any previous versions of **OpenTX**. For those that need it, there is already a version of this documentation for **OpenTX 2.1**.
- It uses the **OpenTX Companion** as the primary starting point for programming a model and not the transmitter.
- The use of screen shots to simplify the text needed.
- As the range of FrSky transmitters has grown considerably, parts of the user guide are split into transmitter-specific sections.
- It has been laid out to follow the menu system in the **OpenTX Companion**.

The guide is broken down into sections. After the introduction, this section lists the contents of the remaining sections. Section 2 with the green border, **Getting Started** takes the user gently through the actual programming of a model to give a flavour of how the program works. This does not require the reader to have a transmitter, and could be useful for those wondering whether to invest in an FrSky transmitter or whether to move to **OpenTX**. The following **Sections 3 to 8** with the blue border explain briefly what everything does. Finally the last two sections with the red borders of **How To's** explains in more detail some of the aspects of the program or other facilities that can enhance the program.

I would like to thank all those who have already contributed to developing the knowledge base of **OpenTX** on the internet, and especially those who have unknowingly contributed some part of this documentation.

Finally this documentation was also freely produced and is offered in a similar spirit to readers. However, it is a copyright document as such, and must not be reproduced in whole or part for profit without approval. If elements are copied on a non-profit basis, I would appreciate an acknowledgement as the source, as I have tried to do with other contributors in this document.

Martin Phillips March 2018

It is the sole responsibility of the user to ensure that the setting up of their transmitter functions as expected on the model.

Section 1

OpenTX Introduction

Introduction

Without doubt **OpenTX** is the most comprehensive model radio system available today. It has been adapted to cover the whole range of FrSky radios currently available, plus some Turnigy radios. However, that comprehensiveness comes at a price. It can appear very daunting to learn and use, and without doubt that is true to some extent. It is probably true that no modeller will ever use all the features available, but they are there if required.

OpenTX is open source software, that is to say all the development work has, and still is, being done by a team of willing programmers and enthusiasts from around the world at no cost to you the user, though donations to the project are warmly received. This helps keep the cost of equipment much lower than comparable systems with in-house programming. As most who use computers in one form or another realise, computers are constantly evolving, and so is the software surrounding them. This is also true of OpenTX, and users need to accept they are entering a world where regular updating becomes the norm, and new features will constantly appear, and some features will change. Changes to national and international radio regulations have also forced changes to the system. While frustrating at times, it does mean that one always has a fully up-to-date system to match or exceed the best of the rest. The OpenTX team have done much to make this updating process very simple, and if one follows a few basic precautions, there is never any chance of "bricking" (i.e. damaging) the transmitter, or losing all the effort you put into setting up your models.

The **OpenTX** transmitter system is unlike most other transmitter systems. It does not have the normal menu system you may well be used to and be comfortable with. It does not follow all the limiting conventions used by traditional systems, and this has been reflected in the FrSky transmitter designs themselves. For example, the switches are labelled "A", "B", "C", etc., rather than giving them specific designations, so any switch can be used for any purpose. Similarly you decide which channels to use for what purpose.

One needs to step back from ones pre-conceived ideas of how radio systems should be set up to fully appreciate the flexibility of OpenTX.

I hope as you read through this document you will begin to see the wonderful flexibility of this system, and instead of asking whether the program can do this or that, ask how to I get it to do..?

Section 1



Contents

Contents

Section 1: Introduction & Contents	
Foreword	Page 1
Introduction	Page 2
Contents	Page 3
Section 2: Getting Started	
Introduction	Page 2
The Main OpenTX Companion Screen	Page 3
The Model Wizard	Page 5
The Editing Screen	Page 7
The Simulator	Page 8
The Inputs Window	Page 9
The Mixes Window	Page 10
Editing a Model	Page 11
The Setup Window	Page 14
Going Beyond Basics	Page 19
Creating Elevons	Page 20
Playing Sounds	Page 22
Logical Switches	Page 23
The Outputs Screen	Page 25
Section 3: The OpenTX Companion	
The OpenTX Companion	Page 2
The OpenTX Companion Screen	Page 6
Radio Profiles	Page 6
The Three Settings Menus	Page 7
Managing Models on OpenTX Companion	Page 10
Compare Models	Page 11
Synchronise CD	Page 12
, Model Categories	Page 13
The Companion, Edit Radio Profile	Page 14
The Companion, Edit Application Settings	Page 17
The Companion, Edit Simulator Settings	Page 18
The OpenTX Simulator	Page 19
Radio Output	Page 21
Telemetry Simulator	Page 22
Trainer Simulator	Page 22
Debug output	Page 23

OpenT <mark>X</mark>	Introduction
Reload LUA/Reload	d Radio Page 23
Save a Screenshot	Page 23
Simulator Controls	_
Configure Joystick	Page 23
	1.00 =0
Section 4: The Radio Setu	p Menu
The Radio Setup Menu	Page 2
Radio Settings: The Setup	p Screen Page 4
Radio Settings: Global Fu	inctions Page 8
Radio Settings: Trainer	Page 9
Radio Settings: Hardware	e Page 11
Radio Settings: Calibratio	on Page 12
Section 5: The Model Edit	or
Accessing the Model Edit	
The Setup Screen	Page 5
Timers 1, 2, 3	Page 6
Throttle Source	Page 6
Trim Step	Page 6
Trims Display	Page 7
Throttle Idle Only	Page 7
Throttle Warning	Page 7
Reverse Throttle	Page 7
Extended Limits	Page 8
Extended Trim	Page 8
Display Checklist	Page 8
Global Functions	Page 8
Switch Warnings	Page 8
Pot Warnings	Page 8
Internal Radio Syst	em Page 9
The Failsafe Mode	Page 9
Binding a Receiver	Page 10
Range Test	Page 11
External radio Mod	dule Page 11
The Heli Screen	Page 13
The Flight Modes Screen	Page 15
Global Variables	Page 16
The Inputs Screen	Page 18
The Input Edit Win	dow Page 21
Important Warnin	
The Mixes Screen	Page 22
The Outputs Screen	Page 28
Notes on Servos	Page 31
Inputs Diagram	Page 34
Mixes Diagram	Page 35
Milyez Diakiaili	rage 33

Section 1

OpenTX	Introduction
Outputs/Servos Diagra	m Page 36
The Curves Screen	Page 37
The Logical Switches Screen	Page 42
The Special Functions Screen	_
Section 6: Telemetry	
The Telemetry Screen	Page 2
Telemetry Key Points	Page 4
The FrSky Smart Port Sensor	s Page 5
Current Sensors	Page 5
Voltage Sensors	Page 6
Variometer	Page 6
GPS Sensor	Page 9
RPM and Temperature	e Sensor Page 9
Air Speed Sensor	page 10
Discovering new Sensors	Page 11
The Telemetry Screen	Page 12
Analogue Outputs A1/	A2 Page 15
Telemetry Displays (Taranis)	Page 16
Data Logging	Page 17
Section 7: The Taranis Transn	nitters
The Taranis transmitter rang	
The Taranis X9D transmitter	Page 3
The Taranis X9E transmitter	Page 4
The Taranis Q X7 transmitter	_
Entering bootloader mode	Page 6
Sources available X9 transmi	_
Sources available Q X7 Trans	· · · · · · · · · · · · · · · · · · ·
Firmwares	Page 9
Updating the firmwares	Page 10
Updating the SD Card	Page 13
The Taranis transmitter men	_
The Taranis radio setup scre	
The Taranis controls informa	_
The Taranis telemetry screen	
The Taranis model edit scree	_
Section 8: The Horus Transm	ittors
The Horus X10 and X10S Diagram	_
The Horus X12S Diagram	Page 3
Sources for Inputs and Mixes	_
Screen Symbols	Page 6

Section 1

OpenTX	Introduction
Switch Default Settings	Page 7
External/Internal Aerials	Page 7
Memory Storage	Page 8
The SD-HD Card	Page 8
Updating the SD Card	Page 10
The Horus Transmitter Menu System	Page 11
The Horus Screen	Page 12
The System Menu	Page 13
Calibration	Page 14
The Model Setup Menu	Page 15
Bind and range Check	Page 16
Discovering Sensors	Page 16
The Model Select Menu	Page 17
Widget Editing	Page 19
Layout	Page 20
Screen Options	Page 21
Setup Widgets	Page 21
The Widget User Interface	Page 23
Notes on Widgets	Page 25
Firmwares	Page 26
Installing OpenTX	Page 27
Installing Zadig for PC	Page 27
Installing OpenTX Companion	Page 28
Installing OpenTX on the Radio	Page 29
Re-installing FrOS	Page 30
Section 9: How To Part 1	
How to Flash the EU LBT Firmware	Page 2
How to Create a Sound File	Page 6
How to Create a Text File	Page 9
How to Use the Trainer Function	Page 11
How to Record Transmitter Settings	Page 15
How to Set Up a Flybarless Helicopter	Page 16
How to Set Up a CCPM Helicopter	Page 23
How to Create a Kill Switch	Page 33
Section 10: How To Part 2	
How to Add Voltage Telemetry to the X4R	Page 2
How to Create Model Pictures for the Horus	Page 4
Telemetry LiPo Fuel Gauge	Page 8
How to Use the Bluetooth Trainer Function	Page 11
	J