

Object Groups for ACLs

The Object Groups for ACLs feature lets you classify users, devices, or protocols into groups and apply those groups to access control lists (ACLs) to create access control policies for those groups. This feature lets you use object groups instead of individual IP addresses, protocols, and ports, which are used in conventional ACLs. This feature allows multiple access control entries (ACEs), but now you can use each ACE to allow an entire group of users to access a group of servers or services or to deny them from doing so.

In large networks, the number of ACLs can be large (hundreds of lines) and difficult to configure and manage, especially if the ACLs frequently change. Object group-based ACLs are smaller, more readable, and easier to configure and manage than conventional ACLs, simplifying static and dynamic ACL deployments for large user access environments on Cisco IOS routers.

Cisco IOS Firewall benefits from object groups, because they simplify policy creation (for example, group A has access to group A services).

- Restrictions for Object Groups for ACLs, on page 1
- Information About Object Groups for ACLs, on page 2
- How to Configure Object Groups for ACLs, on page 4
- Configuration Examples for Object Groups for ACLs, on page 12
- Additional References for Object Groups for ACLs, on page 14
- Feature History for Object Groups for ACLs, on page 15

Restrictions for Object Groups for ACLs

• You can use object groups only in extended named and numbered ACLs.



Note

On C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches, this is only supported in Extended ACL.

• Object group-based ACLs support only IPv4/IPv6 addresses.



Note

On C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches , object group-based ACLs support both IPv4 and IPv6 addresses.

• Object group-based ACLs support only Layer 3 interfaces (such as routed interfaces and VLAN interfaces) port channel interface, and sub-interfaces.

There is no support on Layer 2 interfaces on C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches .

- Object group-based ACLs are not supported with IPsec.
- The number of object group-based ACEs supported in an ACL varies depending on platform, subject to TCAM availability.
- On C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches, object group-based ACLs are supported only on ingress port. There is no support on egress direction.
- IPv6 object group-based ACLs with Log option is not supported on C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches. However, IPv4 object group-based ACLs with Log option is supported.
- IPv4 object group-based ACL for multicast packet control is not supported on C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches.
- IPv6 object group-based ACL for control packet is not supported on C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches.
- You cannot configure conventional ACEs and ACEs that refer to object groups in the same ACL on C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches.
- Only contiguous address masks (wildcards) such as 255.255.0.0 255.0.0.0 are supported on C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches.
- Time-based ACL is supported on C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches.
- On the C9500X-28C8D model of the Cisco Catalyst 9500 Series Switches, Per ACE statistics is supported
 only for deny ACEs. Per ACE statistics Permit ACE is not supported. If the same ACL is applied to
 multiple ports, then the deny counters is cumulative of all the ports on which the ACL is attached.

Information About Object Groups for ACLs

You can configure conventional ACEs and ACEs that refer to object groups in the same ACL.

You can use object group-based ACLs with quality of service (QoS) match criteria, Cisco IOS Firewall, Dynamic Host Configuration Protocol (DHCP), and any other features that use extended ACLs. In addition, you can use object group-based ACLs with multicast traffic.

When there are many inbound and outbound packets, using object group-based ACLs increases performance when compared to conventional ACLs. Also, in large configurations, this feature reduces the storage needed in NVRAM, because using object groups in ACEs means that you do not need to define an individual ACE for every address and protocol pairing.

Object Groups

An object group can contain a single object (such as a single IP address, network, or subnet) or multiple objects (such as a combination of multiple IP addresses, networks, or subnets).

A typical access control entry (ACE) allows a group of users to have access only to a specific group of servers. In an object group-based access control list (ACL), you can create a single ACE that uses an object group name instead of creating many ACEs (which requires each ACE to have a different IP address). A similar object group (such as a protocol port group) can be extended to provide access only to a set of applications for a user group. ACEs can have object groups for the source only, destination only, none, or both.

You can use object groups to separate the ownership of the components of an ACE. For example, each department in an organization controls its group membership, and the administrator owns the ACE itself to control which departments can contact one another.

You can use object groups in features that use Cisco Policy Language (CPL) class maps.

This feature supports two types of object groups for grouping ACL parameters: network object groups and service object groups. Use these object groups to group IP addresses, protocols, protocol services (ports), and Internet Control Message Protocol (ICMP) types.

Objects Allowed in Network Object Groups

A network object group is a group of any of the following objects:

- Any IP address—includes a range from 0.0.0.0 to 255.255.255 (This is specified using the **any** command.)
- · Host IP addresses
- Hostnames
- Other network object groups
- Subnets
- · Host IP addresses
- Network address of group members
- Nested object groups

Objects Allowed in Service Object Groups

A service object group is a group of any of the following objects:

- Source and destination protocol ports (such as Telnet or Simple Network Management Protocol [SNMP])
- Internet Control Message Protocol (ICMP) types (such as echo, echo-reply, or host-unreachable)
- Top-level protocols (such as Encapsulating Security Payload [ESP], TCP, or UDP)
- Other service object groups

ACLs Based on Object Groups

All features that use or reference conventional access control lists (ACLs) are compatible with object-group-based ACLs, and the feature interactions for conventional ACLs are the same with object-group-based ACLs. This feature extends the conventional ACLs to support object-group-based ACLs and also adds new keywords and the source and destination addresses and ports.

You can add, delete, or change objects in an object group membership list dynamically (without deleting and redefining the object group). Also, you can add, delete, or change objects in an object group membership list

without redefining the ACL access control entry (ACE) that uses the object group. You can add objects to groups, delete them from groups, and then ensure that changes are correctly functioning within the object-group-based ACL without reapplying the ACL to the interface.

You can configure an object-group-based ACL multiple times with a source group only, a destination group only, or both source and destination groups.

You cannot delete an object group that is used within an ACL or a class-based policy language (CPL) policy.

How to Configure Object Groups for ACLs

To configure object groups for ACLs, you first create one or more object groups. These can be any combination of network object groups (groups that contain objects such as, host addresses and network addresses) or service object groups (which use operators such as **lt**, **eq**, **gt**, **neq**, and **range** with port numbers). Then, you create access control entries (ACEs) that apply a policy (such as **permit** or **deny**) to those object groups.

Creating a Network Object Group

A network object group that contains a single object (such as a single IP address, a hostname, another network object group, or a subnet) or multiple objects with a network object-group-based ACL to create access control policies for the objects.

Perform this task to create a network object group.

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	object-group network object-group-name	Defines the object group name and enters
Example	Example:	network object-group configuration mode.
	Device(config)# object-group network my-network-object-group	
Step 4	description description-text	(Optional) Specifies a description of the object
	Example:	group.
		• You can use up to 200 characters.
	<pre>Device(config-network-group)# description test engineers</pre>	

	Command or Action	Purpose
Step 5	<pre>host {host-address host-name} Example: Device (config-network-group) # host 209.165.200.237</pre>	(Optional) Specifies the IP address or name of a host.• If you specify a host address, you must use an IPv4 address.
Step 6	<pre>network-address {/nn network-mask} Example: Device (config-network-group) # 209.165.200.225 255.255.255.224</pre>	(Optional) Specifies a subnet object. • You must specify an IPv4 address for the network address. The default network mask is 255.255.255.255.
Step 7	group-object nested-object-group-name Example:	(Optional) Specifies a nested (child) object group to be included in the current (parent) object group.
	Device(config-network-group)# group-object my-nested-object-group	The type of child object group must match that of the parent (for example, if you are creating a network object group, you must specify another network object group as the child).
		You can use duplicated objects in an object group only via nesting of group objects. For example, if object 1 is in both group A and group B, you can define a group C that includes both A and B. However, you cannot include a group object that causes the group hierarchy to become circular (for example, you cannot include group A in group B and then also include group B in group A).
		You can use an unlimited number of levels of nested object groups (however, a maximum of two levels is recommended).
Step 8	Repeat the steps until you have specified objects on which you want to base your object group.	_
Step 9	<pre>end Example: Device(config-network-group) # end</pre>	Exits network object-group configuration mode and returns to privileged EXEC mode.

Creating a Service Object Group

Use a service object group to specify TCP and/or UDP ports or port ranges. When the service object group is associated with an access control list (ACL), this service object-group-based ACL can control access to ports.

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	object-group service object-group-name	Defines an object group name and enters
	Example:	service object-group configuration mode.
	Device(config)# object-group service my-service-object-group	
Step 4	description description-text	(Optional) Specifies a description of the object
	Example:	• You can use up to 200 characters.
	Device(config-service-group)# description test engineers	Tou can use up to 200 characters.
Step 5	protocol	(Optional) Specifies an IP protocol number or
	Example:	name.
	Device(config-service-group)# ahp	
Step 6	{tcp udp tcp-udp} [source {{[eq] lt gt} port1 range port1 port2}] [{[eq] lt gt} port1 range port1 port2]	(Optional) Specifies TCP, UDP, or both.
	Example:	
	Device(config-service-group)# tcp-udp range 2000 2005	
Step 7	icmp icmp-type	(Optional) Specifies the decimal number or
	Example:	name of an Internet Control Message Protocol (ICMP) type.
	Device(config-service-group)# icmp conversion-error	

	Command or Action	Purpose
Step 8	group-object nested-object-group-name Example:	(Optional) Specifies a nested (child) object group to be included in the current (parent) object group.
	Device(config-service-group)# group-object my-nested-object-group	 The type of child object group must match that of the parent (for example, if you are creating a network object group, you must specify another network object group as the child).
		• You can use duplicated objects in an object group only via nesting of group objects. For example, if object 1 is in both group A and group B, you can define a group C that includes both A and B. However, you cannot include a group object that causes the group hierarchy to become circular (for example, you cannot include group A in group B and then also include group B in group A).
		• You can use an unlimited number of levels of nested object groups (however, a maximum of two levels is recommended).
Step 9	Repeat the steps to specify the objects on which you want to base your object group.	_
Step 10	end Example:	Exits service object-group configuration mode and returns to privileged EXEC mode.
	Device(config-service-group)# end	

Creating an Object-Group-Based ACL

When creating an object-group-based access control list (ACL), configure an ACL that references one or more object groups. As with conventional ACLs, you can associate the same access policy with one or more interfaces.

You can define multiple access control entries (ACEs) that reference object groups within the same object-group-based ACL. You can also reuse a specific object group in multiple ACEs.

Perform this task to create an object-group-based ACL.

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.

	Command or Action	Purpose
	Example:	Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	ip access-list extended access-list-name	Defines an extended IP access list using a name
	Example:	and enters extended access-list configuration mode.
	Device(config)# ip access-list extended nomarketing	
Step 4	remark remark	(Optional) Adds a comment about the configured access list entry.
	Example: Device(config-ext-nacl)# remark protect server by denying access from the Marketing network	• A remark can precede or follow an access
Step 5	deny protocol source [source-wildcard] destination [destination-wildcard] [option option-name] [precedence precedence] [tos tos] [established] [log log-input] [time-range time-range-name] [fragments] Example:	(Optional) Denies any packet that matches all conditions specified in the statement. • Optionally use the object-group **service-object-group-name keyword and argument as a substitute for the protocol. **argument*
	Device(config-ext-nacl)# deny ip 209.165.200.244 255.255.255.224 host 209.165.200.245 log Example based on object-group:	Optionally use the object-group source-network-object-group-name keyword and argument as a substitute for the source source-wildcard. arguments
	Router(config) #object-group network my_network_object_group Router(config-network-group) #209.165.200.224 255.255.255.224 Router(config-network-group) #exit Router(config) #object-group network my_other_network_object_group Router(config-network-group) #host 209.165.200.245 Router(config-network-group) #exit Router(config) #ip access-list extended nomarketing Router(config-ext-nacl) #deny ip object-group my network object group	 Optionally use the object-group destination-network-object-group-name keyword and argument as a substitute for the destination destination-wildcard. arguments If the source-wildcard or destination-wildcardis omitted, a wildcard mask of 0.0.0.0 is assumed, which matches all bits of the source or destination address, respectively.

	Command or Action	Purpose
	object-group my_other_network_object_group log	• Optionally use the any keyword as a substitute for the <i>source source-wildcard</i> or <i>destination destination-wildcard</i> to specify the address and wildcard of 0.0.0.0 255.255.255.255.
		• Optionally use the host <i>source</i> keyword and argument to indicate a source and source wildcard of <i>source</i> 0.0.0.0 or the host <i>destination</i> keyword and argument to indicate a destination and destination wildcard of <i>destination</i> 0.0.0.0.
		• In this example, packets from all sources are denied access to the destination network 209.165.200.244. Logging messages about packets permitted or denied by the access list are sent to the facility configured by the logging facility command (for example, console, terminal, or syslog). That is, any packet that matches the access list will cause an informational logging message about the packet to be sent to the configured facility. The level of messages logged to the console is controlled by the logging console command.
Step 6	remark remark	(Optional) Adds a comment about the
	Example:	configured access list entry.
	Device(config-ext-nacl)# remark allow TCP from any source to any destination	A remark can precede or follow an access list entry.
Step 7	permit protocol source [source-wildcard] destination [destination-wildcard] [option	Permits any packet that matches all conditions specified in the statement.
	option-name] [precedence precedence] [tos tos] [established] [log log-input] [time-range time-range-name] [fragments]	• Every access list needs at least one permit statement.
	Example: Device(config-ext-nacl) # permit tcp any any	• Optionally use the object-group service-object-group-name keyword and argument as a substitute for the protocol.
		Optionally use the object-group source-network-object-group-name keyword and argument as a substitute for the source source-wildcard.
		Optionally use the object-group destination-network-object-group-name

	Command or Action	Purpose
		keyword and argument as a substitute for the <i>destination destination-wildcard</i> .
		• If source-wildcard or destination-wildcard is omitted, a wildcard mask of 0.0.0.0 is assumed, which matches on all bits of the source or destination address, respectively.
		• Optionally use the any keyword as a substitute for the <i>source source-wildcard</i> or <i>destination destination-wildcard</i> to specify the address and wildcard of 0.0.0.0 255.255.255.255.
		• In this example, TCP packets are allowed from any source to any destination.
		Use the log-input keyword to include input interface, source MAC address, or virtual circuit in the logging output.
Step 8	Repeat the steps to specify the fields and values on which you want to base your access list.	Remember that all sources not specifically permitted are denied by an implicit deny statement at the end of the access list.
Step 9	end Example:	Exits extended access-list configuration mode and returns to privileged EXEC mode.
	Device(config-ext-nacl)# end	

Applying an Object Group-Based ACL to an Interface

Use the **ip access-group** command to apply an object group-based ACL to an interface. An object group-based access control list (ACL) can be used to control traffic on the interface it is applied to.

Perform this task to apply an object group-based ACL to an interface.

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	

	Command or Action	Purpose
Step 3	interface type number Example:	Specifies the interface and enters interface configuration mode.
	Device(config)# interface vlan 100	
Step 4	ip access-group {access-list-name access-list-number} {in out}	Applies the ACL to the interface and specifies whether to filter inbound or outbound packets.
	Example:	
	Device(config-if)# ip access-group my-ogacl-policy in	
Step 5	end	Exits interface configuration mode and returns
	Example:	to privileged EXEC mode.
	Device(config-if)# end	

Verifying Object Groups for ACLs

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	Enter your password if prompted.
	Device> enable	
Step 2	show object-group [object-group-name] Example:	Displays the configuration in the named or numbered object group (or in all object groups if no name is entered).
	Device# show object-group my-object-group	
Step 3	show ip access-list [access-list-name]	Displays the contents of the named or numbered
Example: Device# show ip access-list my-ogacl-policy	Example:	access list or object group-based ACL (or for all access lists and object group-based ACLs
	-	no name is entered).

Configuration Examples for Object Groups for ACLs

Example: Creating a Network Object Group

The following example shows how to create a network object group named my-network-object-group, which contains two hosts and a subnet as objects:

```
Device> enable

Device# configure terminal

Device(config)# object-group network my-network-object-group

Device(config-network-group)# description test engineers

Device(config-network-group)# host 209.165.200.237

Device(config-network-group)# host 209.165.200.238

Device(config-network-group)# 209.165.200.241 255.255.255.224

Device(config-network-group)# end
```

The following example shows how to create a network object group named my-company-network, which contains two hosts, a subnet, and an existing object group (child) named my-nested-object-group as objects:

```
Device> enable
Device# configure terminal
Device(config)# object-group network my-company-network
Device(config-network-group)# host host1
Device(config-network-group)# host 209.165.200.242
Device(config-network-group)# 209.165.200.225 255.255.255.224
Device(config-network-group)# group-object my-nested-object-group Device(config-network-group)# end
```

Example: Creating a Service Object Group

The following example shows how to create a service object group named my-service-object-group, which contains several ICMP, TCP, UDP, and TCP-UDP protocols and an existing object group named my-nested-object-group as objects:

```
Device> enable

Device# configure terminal

Device(config)# object-group service my-service-object-group

Device(config-service-group)# icmp echo

Device(config-service-group)# tcp smtp

Device(config-service-group)# tcp telnet

Device(config-service-group)# tcp source range 1 65535 telnet

Device(config-service-group)# tcp source 2000 ftp

Device(config-service-group)# udp domain

Device(config-service-group)# tcp-udp range 2000 2005

Device(config-service-group)# group-object my-nested-object-group

Device(config-service-group)# end
```

Example: Creating an Object Group-Based ACL

The following example shows how to create an object-group-based ACL that permits packets from the users in my-network-object-group if the protocol ports match the ports specified in my-service-object-group:

```
Device> enable
Device# configure terminal
Device(config)# ip access-list extended my-ogacl-policy
Device(config-ext-nacl)# permit object-group my-service-object-group object-group my-network-object-group any
Device(config-ext-nacl)# deny tcp any any
Device(config-ext-nacl)# end
```

Applying an Object Group-Based ACL to an Interface

Use the **ip access-group** command to apply an object group-based ACL to an interface. An object group-based access control list (ACL) can be used to control traffic on the interface it is applied to.

Perform this task to apply an object group-based ACL to an interface.

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	interface type number	Specifies the interface and enters interface
	Example:	configuration mode.
	Device(config)# interface vlan 100	
Step 4	ip access-group {access-list-name access-list-number} {in out}	Applies the ACL to the interface and specifies whether to filter inbound or outbound packets.
	Example:	
	Device(config-if)# ip access-group my-ogacl-policy in	
Step 5	end	Exits interface configuration mode and returns
	Example:	to privileged EXEC mode.
	Device(config-if)# end	

Example: Verifying Object Groups for ACLs

The following example shows how to display all object groups:

Device# show object-group

```
Network object group auth-proxy-acl-deny-dest
host 209.165.200.235
Service object group auth-proxy-acl-deny-services
tcp eq www
tcp eq 443
Network object group auth-proxy-acl-permit-dest
209.165.200.226 255.255.255.224
209.165.200.227 255.255.255.224
209.165.200.228 255.255.255.224
209.165.200.229 255.255.255.224
209.165.200.246 255.255.255.224
 209.165.200.230 255.255.255.224
209.165.200.231 255.255.255.224
209.165.200.232 255.255.255.224
209.165.200.233 255.255.255.224
209.165.200.234 255.255.255.224
Service object group auth-proxy-acl-permit-services
tcp eq www
tcp eq 443
```

The following example shows how to display information about specific object-group-based ACLs:

```
Device# show ip access-list my-ogacl-policy
Extended IP access list my-ogacl-policy
10 permit object-group eng service any any
```

Additional References for Object Groups for ACLs

Related Documents

Related Topic	Document Title
Security commands	Cisco IOS Security Command Reference: Commands A to C
	Cisco IOS Security Command Reference: Commands D to L
	Cisco IOS Security Command Reference: Commands M to R
	Cisco IOS Security Command Reference: Commands S to Z
ACL configuration guide	Security Configuration Guide: Access Control Lists

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature History for Object Groups for ACLs

This table provides release and related information for the features explained in this module.

These features are available in all the releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Gibraltar 16.12.1	Object Groups for ACLs	The Object Groups for ACLs feature lets you classify users, devices, or protocols into groups and apply them to access control lists (ACLs) to create access control policies for those groups. This feature lets you use object groups instead of individual IP addresses, protocols, and ports, which are used in conventional ACLs. This feature allows multiple access control entries (ACEs), but now you can use each ACE to allow an entire group of users to access a group of servers or services or to deny them from doing so. Support for this feature was introduced on all the models of the Cisco Catalyst 9500 Series Switches. Support for this feature was introduced on the C9500-32C, C9500-32QC, C9500-48Y4C, and C9500-24Y4C models of the Cisco Catalyst 9500 Series Switches.
Cisco IOS XE Cupertino 17.7.1	Object Groups for ACLs	Support for this feature was introduced on the C9500X-28C8D model of Cisco Catalyst 9500 Series Switches.

Use the Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to http://www.cisco.com/go/cfn.

Feature History for Object Groups for ACLs