## **FBW A320NEO CHECKLIST**

(For Simulation Purposes Only)



BEFORE START	
COCKPIT PREPCC	MPLETED (BOTH)
GEAR PINS and COVERS	REMOVED
SIGNS	ON/AUTO
ADIRS	NAV
FUEL QUANTITY	KG.LB
TO DATA	SET
BARO REF	SET (BOTH)
WINDOWS/DOORS	CLOSED (BOTH)
BEACON	ON
THR LEVERS	IDLE
PARKING BRAKE	AS RQRD

AFTER START	
ANTI ICE	AS RQRD
FCAM STATUS	CHECKED
PITCH TRIM	% SET
RUDDER TRIM	ZERO

BEFORE TAK	BEFORE TAKEOFF		
FLIGHT CONTROLS	CHECKED (BOTH)		
FLT INST			
BRIEFING			
FLAP SETTING			
V1. VR. V2/FLX TEMP			
	SET		
ECAM MEMO	TO NO BLUE		
- AUTO BRK MAX			
- SIGNS ON			
- CABIN READY			
- SPLRS ARM			
- FLAPS TO			
- TO CONFIG NORM			
TAKEOFF RWY	_CONFIRMED (BOTH)		
CABIN CREW			
	TA OR TA/RA		
ENG MODE SEL			
PACKS	AS RQRD		

AFTER TAKEOFF / CLIMB	
LDG GEAR	UP
FLAPS	RETRACTED
PACKS	ON
BARO REF	

APPROACH	
BRIEFING	
ECAM STATUS	CHECKED
SEAT BELTS	ON
BARO REF	SET (BOTH)
MINIMUM	SET (BOTH)
BARO REF MINIMUM ENG MODE SEL	AS RQRD

LANDI	NG
CABIN CREW	ADVISED
A/THR	SPEED/OFF
AUTOBRAKE	AS RQRD
ECAM MEMO	LDG NO BLUE
- LDG GEAR DN	
- SIGNS ON	
- CABIN READY	
- SPLRS ARM	
- FLAPS SET	

AFTER LANDING	
FLAPS	RETRACTED
SPOILERS	DISARMED
APU	
RADAR	
PREDICTIVE WINDSHEAR S	SYSTEM OFF

PARKING	
APU BLEED	ON
ENGINES	OFF
SEAT BELTS	OFF
EXT LT	AS RQRD
FUEL PUMPS	OFF
PARK BRK and CHOCKS	AS RQRD
Consider HEAVY RAIN	

SECURING THE AIRCRAFT	
ADIRS	OFF
OXYGEN	OFF.
APU BLEED	.OFF
EMER EXIT LT	OFF
SIGNS	OFF
APU AND BAT	OFF
Consider COLD WEATHER	

