COCKPIT PREPARATION	
GEAR PINS & COVERS	REMOVED
FUEL QUANTITY	KG.LB
SEAT BELTS	ON
ADIRS	NAV
BARO REF	SET (BOTH)

BEFORE START	
PARKING BRAKE	
T.O. SPEEDS & THRUST	_ (BOTH)
WINDOWS	CLOSED
BEACON	ON

AFTER START	
ANTI ICE	
ECAM STATUS	. CHECKED
PITCH TRIM	%
RUDDER TRIM	. NEUTRAL

TAXI	
FLIGHT CONTROLS CHECKED (BOTH)	
FLAP SETTINGCONF (BOTH)	
RADAR & PRED W/S ON & AUTO	
ENG MODE SEL	
ECAM MEMO TO NO BLUE	
- AUTO BRK MAX	
- SIGNS ON	
- CABIN READY	
- SPLRS ARM	

LINE-UP
T.O. RWY(BOTH)
TCAS
PACKS 1 & 2

FLAPS TO

TO CONFIRM NORM

APPROACH	
BARO REFSET (BOTH)	
SEAT BELTSON	
MINIMUM	
AUTO BRAKE	
ENG MODE SEL AS RQRD	

LANDING		
ECAM	MEMO	LDG NO BLUE
-	LDG GEAR DN	
-	SIGNS ON	
-	CABIN READY	
-	SPLRS ARM	
-	FLAPS SET	

AFTER LANDING
RADAR & PRED W/SOFF

PARKING
PARK BRK or CHOCKSSET
ENGINESOFF
WINGS LIGHTOFF
FUEL PUMPSOFF

SECURING THE AIRCRAFT	
OXYGENOFF	
EMER EXIT LTOFF	
EFBsOFF	
BATTERIESOFF	