COCKPIT PREPARA	ATION
GEAR PINS and COVERS	REMOVED
FUEL QUANTITY	KG.LB
SEAT BELTS	ON
ADIRS	NAV
BARO REF	SET (BOTH)

BEFORE START	
PARKING BRAKE	
T.O. SPEEDS & THRUST	_(BOTH)
WINDOWS	
BEACON	ON

AFTER START	
ANTI ICE	<u></u>
ECAM STATUS	. CHECKED
PITCH TRIM	%
RUDDER TRIM	

	TAX	(I
		CHECKED (BOTH)
FLAP S	SETTING	CONF (BOTH)
RADAF	R & PRED W/S	ON & AUTO
ENG M	ODE SEL	
ECAM	MEMO	TO NO BLUE
-	AUTO BRK MAX	
-	SIGNS ON	
-	CABIN READY	
_	SPLRS ARM	

LINE-UP
T.O. RWY(BOTH)
TCAS
PACKS 1 & 2

FLAPS TO

TO CONFIRM NORM

APPROACH
BARO REFSET (BOTH)
SEAT BELTSON
MINIMUM
AUTO BRAKE
ENG MODE SELAS RQRD

	LAN	DING
ECAM	MEMO	LDG NO BLUE
-	LDG GEAR DN	
-	SIGNS ON	
-	CABIN READY	
-	SPLRS ARM	
-	FLAPS SET	

AFTER LANDING
RADAR & PRED W/SOFF

PARKING	
PARK BRK or CHOCKSSET	
ENGINES OFF	=
WINGS LIGHTOFF	=
FUEL PUMPSOFF	=

SECURING THE AIRCRAFT
OXYGENOFF
EMER EXIT LTOFF
EFBsOFF
BATTERIESOFF