FLYSKY

Release Notes for FS-ST16-EU Transmitter Software/FS-ST16-EU 软件版本更新记录

Software Version 软件版本	1.0.26	Date 日期	05/2026

新增功能：

1. [模型设置] 功能下新增 [设置为竞赛模式] 功能。通过它可快速关闭 [低信号报警] 功能和 [遥测丢失报警] 功能。
2. [接收机设置] 功能下新增 [高频设置] 功能。用来设置本机高频开启 / 关闭，以及外置高频的相关功能选择，如接收机接口协议、信号强度等设置。
3. [接收机设置] 功能下新增 [低信号报警] 功能。
   - 可设置报警声音；
   - 可设置报警值和报警重复周期；
   - 可以开启或关闭此功能。
4. [接收机设置] 功能下新增 [遥测报警] 功能。
   - 可设置遥测丢失时报警声音；
   - 可以设置报警灵敏度，避免短暂干扰导致丢失报警；
   - 可以开启或关闭此功能。
5. [接收机设置] 功能下的 [失控保护] 功能新增 [失控保护判断时间] 功能：可设置当前模型失控保护判断时间。
6. [设置] 功能下新增 [电池电压] 功能：可校准发射机电池电压。
7. 外置 FRM303 高频头开启时，接收机设置中新增相关功能，如：
   - [对码设置] 中 [RF 系统] 功能中新增 5 种 RF 模式选项：Classic 18、C-Fast 10、Routin 18、Lora 12、Fast 8；
   - 新增 [接口协议] 功能，接口协议根据所选 RF 系统类型而变化；
   - 新增适配外置高频相关的 [失控保护] 功能项；
   - 新增 [响应速度] 功能，根据 RF 系统类型而变化；
   - 新增适配外置高频的 [i-BUS 设置] 相关功能；
   - 新增适配外置高频的 [低信号报警] 功能；
   - 新增适配外置高频的 [遥测报警] 功能；
   - 新增 [信号强度] 功能，即 [接收机设置] 下新增信号强度输出设置功能。

修改功能：

1. 计时器相关报警语音、振动由归属 [系统] 改为归属 [报警]。
2. 修复假性微调相关问题。
3. 适配 WEB 端遥控管家使用。
4. 修复其他已知问题。

特殊变化：

- 无

注意事项

- 发射机固件更新完成后，模型数据会被复位。在固件更新之前，可通过遥控管家进行数据备份，然后导入该版本使用。
- 使用遥控管家备份数据时，须注意以下版本兼容性问题：3.3.5 及以后版本不兼容 3.3.5 之前版本（即 3.0.4 及更早版本互相兼容，3.3.5、4.0.1 及以后版本互相兼容）。因此，导出或导入模型数据时，必须使用相互兼容版本的遥控管家进行操作。
- 发射机固件更新完成后，需完成摇杆校准。
- 发射机和接收机更新完成后需要重新对码。

FLYSKY

Release Notes for FS-ST16-EU Transmitter Software/FS-ST16-EU 软件版本更新记录

Software Version 软件版本	1.0.26	Date 日期	05/2026

New functions:

1. Added a [Set Race Mode] feature within [Model Set]. Quickly disables both [Low Signal Alarm] and [Telemetry Alarm] functions.
2. Added a [RF Setup] feature within [RX Menu], used to enable/disable built-in RF module, or configure external RF module features including: RX Interface Protocol, Signal Strength, etc.
3. Added a [Low Signa] (Low Signal Alarm) feature within [RX Menu]:
   - Alarm sound can be set.
   - Alarm value and alarm repetition cycle can be set.
   - The function can be enabled or disabled.
4. Added a [TLM Loss] (Telemetry Alarm) feature within [RX Menu]:
   - Alarm sound can be set when telemetry is lost.
   - Alarm sensitivity can be set to avoid loss alarms due to briefinterference.
   - The function can be enabled or disabled.
5. Added a [Failsafe time setting] feature within [RX Menu] to configure model's failsafe trigger delay.
6. Added a [Battery Voltage] feature within [Setup]: Calibrate the transmitter's battery voltage.
7. External FRM303 RF Module Features (when enabled):
   - Added 5 [RF System] mode options within [Bind Setup]: Classic 18, C-Fast 10, Routine 18, LoRa 12, and Fast 8.
   - Added a [Interface](Inteface Protocol) feature (dynamic options based on selected RF system).
   - Added a [Failsafe] parameters for external RF.
   - Added a [Frequency] feature (adjustable per RF system type).
   - Added an [i-BUS Set] feature for external RF compatibility.
   - Added a [Low Signa] (Low Signal Alarm) feature for external RF.
   - Added a [TLM Loss] (Telemetry loss Alarm) feature for external RF.
   - Added a [Signal Stre] (Signal Strength) feature, namely adding a signal strength output setting feature within the [RX Setup] menu.

Modified functions:

1. Timer-related voice alerts and vibration have been reassigned from [System] to [Alarm].
2. Fixed issue where trim scale is displayed on the interface without the trim switch being moved.
3. Adapt for use with the web-based Flysky Assistant.
4. Fixed other known issues.

Special changes:

- None

FLYSKY

Release Notes for FS-ST16-EU Transmitter Software/FS-ST16-EU 软件版本更新记录

Software Version 软件版本	1.0.26	Date 日期	05/2025

Notes

1. After the transmitter firmware update is finished, the model data will be reset. It is recommended to back up data through the **FlySkyAssistant**, and then import the data after the update is finished.
2. When using FlySkyAssistant to back up data, observe the following version-compatibility rules:
   - 3.3.5 and later are incompatible with any release before 3.3.5.
   - 3.0.4 and earlier are mutually compatible.
   - 3.3.5, 4.0.1, and all later releases are mutually compatible.

   Therefore, export or import model data only with mutually-compatible versions of FlySkyAssistant.
3. Done the **Stick Calibration** function after the transmitter firmware update is finished.
4. The transmitter and the receiver need to be rebound after the update is finished.