

No.	PIN	STM32F412	AZ3166 Reserved	Extension	Misc
1		RESET	RESET	RESET	
2					
3	1	200		CDIO (ADC	
4	0	PB0		GPIO/ADC	
5	1				
6		PA5		GPIO/ADC	
7		PA4	Button A		
8		PB4	Red LED		
9		PB3	Green LED		
10					
11	1	200		CD10 /114 DT - T1/D	
12	1	PB6		GPIO/UART_TXD	
13	1				
14		PC13	User LED		
15		PB10	IR LED		
16		PC7	Blue LED		
17		PA10	Button B		
18		PB2	Wi-Fi LED		
19					
20	_				
21	2	PB7		GPIO/UART_RXD	
22	1				
23		PB13	I2S_CLK		
24		PB14	I2S_extSD		
25		PB15	I2S_SD		
26		PC6	I2S_MCK		
27			_		
28	1				
29	1				
30	3.3	VDD	3.3V	3.3V	
31	1				
32	1				
33		PB8	I2C1_SCL		
34		PB9	I2C1_SDA		
35	<u> </u>		-		
36	1				
37	1 .				
38	GND	GND	GND	GND	
39	1				
40	1				
41~80		NC	NC	NC	
55	†			-	