

## Base Cube nRF52840 Mesh

## Devlopment Board for LoRa Mesh

- ▲ Pull-Up to enable
- ▼ Pull-Down to enable
- ▼ Low level is detected
- ▲ High level is detected
- 3.3V IO Operating Vlotage
- **1** Jumper Pads
- Interface
- Voltagle
- Function Pin










## Base Cube nRF52840 Mesh

Devlopment Board for LoRa Mesh





## Base Cube nRF52840 Mesh

Devlopment Board for LoRa Mesh

