
## **Breakout ENS160**

## Multi-Gas Sensor Module

- Active Low
- 3.3V IO Operating Vlotage
- Jumper Pads
- Interface
- Voltagle
- Function Pin





INT trigger is programmable, default active low

The two I2C connectors are wired in parallel to the same bus.

ENS160-ADDR: If solder 'H', LSb is '1' (address 0x53), otherwise solder 'L', the LSb value is '0' (address 0x52). Copyright © 2020-2025 FoBE Studio



## **Breakout ENS160**

Multi-Gas Sensor Module

