



- | | |
|--|--|
|  H1
MountingHole |  FID1
Fiducial |
|  H2
MountingHole |  FID2
Fiducial |
|  H3
MountingHole |  FID3
Fiducial |
|  H4
MountingHole | |

Title: Capacity tester

Id: 1/1