

STUDIO CARQUINEZ PATCH BAY

Front view, top of rack first. Left 16 ports: console buckets. Right 8: outboard, FX, monitoring. Generated 2026-09-23 from config.py.

Console core

Room sends

Tie lines

Outboard

Instruments & pedals

Aux sends & FX

Monitoring

2-track

Groups & mix bus

Amp rack

Network

Power

MIDI

Spare

Reserved

Rear not plugged in yet

Normalled

Not normalled

1

24 x 2

5 spare

0 normalled

0/37 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

Tanzb ar Out L

Sub 37 Out

Fuzz In

MXR Dist In

Reserved · Instruments & pedals

LA-2A In

UA 550 In

DBX 160 Link

SSL Fusion In L/R

API L/R In

Dbx 160A L/R In

D-Comp L/R In

902 De-esser IN 1-2

Art Comp In L/R

Tanzb ar Out R

Fuzz Out

MXR Dist Out

Reserved · Instruments & pedals

LA-2A Out

UA 550 Out

DBX 160 Link

SSL Fusion Out L/R

API L/R Out

Dbx 160A L/R Out

D-Comp L/R Out

902 De-esser OUT 1-2

Art Comp Out L/R

2

24 x 2

0 spare

16 normalled

0/48 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

Ghost Channel Insert Send 1-16

NORMALLED

Ghost Channel Insert Return 1-16

Group 1 - 8 Insert Send

Group 1 - 8 Insert Return

3

24 x 2

0 spare

24 normalled

0/44 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

Ghost Channel Insert Send 17-32

NORMALLED

Ghost Channel Insert Return 17-32

Aux 1 Out

Aux 2 Out

Aux 3 Out

Aux 4 Out

Aux 5 / 6 Out

Aux 7 Out L/R

EMT 140 In

PCM60 In

SDE 1000 In

Moog DLY In

4

24 x 2

3 spare

18 normalled

0/39 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

Worm hole Matched to Left Side Patch bay 1-16 top

NORMALLED

Console Line In 1-16

Aux 8 Out L/R

Moog DLY Out

Main Insert Send

Main Insert Return

5

24 x 2

8 spare

16 normalled

0/32 rear plu

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24


Worm hole Matched to Left Side Patch bay 1-16 bottom

NORMALLED

Console Line In 17-32


6

24 x 2
8 spare
16 normalled
0/32 rear plu




7

24 x 2
0 spare
22 normalled
0/46 rear plu




8

24 x 2
0 spare
24 normalled
0/47 rear plu




9

24 x 2
0 spare
22 normalled
0/44 rear plu



10


24 x 2
3 spare
0 normalled
0/42 rear plu



AMP RACK

11 AMP RACK


24 × 2
16 spare
8 normalled
0/16 rear plug



ETHERNET

ETHERNET


Single row
2 spare
0/8 rear plug



MIDI

MIDI


Not in use
Single row
0 spare
0/22 rear plug



POWER SWITCHES

POWER SWITCHES

Single row
1 spare
0/9 rear plug



RACK 1 · EQUIPMENT (20U)

U1	POWER CONDITIONER	
U2	SWITCH PANEL	Not on the patch bay
U3	APOLLO 16 #1	Replacing both Apollos with one 1U unitPatch bay: Bay 6 · 1–16, Bay 8 · 1–16
U4	APOLLO 16 #2	Replacing both Apollos with one 1U unitPatch bay: Bay 7 · 1–16, Bay 9 · 1–16
U5	API 2500 COMPRESSOR	Patch bay: Bay 1 · 15–16, Power Switches · 3
U6–7	D-COMP	Patch bay: Bay 1 · 19–20, Power Switches · 4
U8	DBX 902 DE-ESSER ×2	Patch bay: Bay 1 · 21–22, Power Switches · 5
U9	LEXICON PCM 60 REVERB	Patch bay: Bay 3 · 18, Bay 7 · 19–20, Power Switches · 6
U10	SDE 1000 DELAY	Patch bay: Bay 3 · 19, Bay 7 · 21–22, Power Switches · 7
U11–12	DBX 160 COMPRESSORS	Patch bay: Bay 1 · 12, 17–18, Power Switches · 8–9
U13	EMT REVERB REMOTE	Could move
U14	HEADPHONE AMP	Could movePatch bay: Bay 9 · 23–24
U15	HEADPHONE POWER SUPPLY	
U16	MIDI PATCH BAY	Patch bay: <u>Midi</u> · 1–22
U17	HEARBACK UNIT	Patch bay: Bay 10 · 17–24, Ethernet · 1–8
U18	ETHERNET PATCH BAY	Patch bay: <u>Ethernet</u> · 1–20
U19–20	SOUNDCRAFT GHOST POWER SUPPLY	

OPEN QUESTIONS

CABLE PULLS TO EACH ROOM

Two XLR sends, one XLR return and one Cat5 per room. Every XLR end is soldered onto its cable: pull it, solder the room end, solder the rack end, then patch it (Cat5 ends are terminated instead). Sends land on the patch bay as TRS; the returns stay in a loom on the floor, so they have nothing to patch — **160** steps in all. The destination is where the cable lands at the rack.

KITCHEN

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

BATH UP

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

BATH DN

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

DEN

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

GALLERY

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

MASTER BED

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

GUEST BED

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

OFFICE

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

RECORD PLAYER

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send L	XLR	☐	☐	☐	☐
Send R	XLR	☐	☐	☐	☐
Return	XLR	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐
Notes...					

FRONT DECK

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Speaker	SPEAKER	☐	☐	☐	—

Notes...

BACK DECK

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Speaker	SPEAKER	☐	☐	☐	—

Notes...

REVERB · EMT PLATE

		PULL	SOLDER ROOM	SOLDER CONSOLE	PATCH
Send	XLR	☐	☐	☐	☐
Return L	XLR	☐	☐	☐	☐
Return R	XLR	☐	☐	☐	☐
Motor control · 5-pin	CAT5	☐	☐	☐	—
Network	CAT5	☐	☐	☐	☐

Notes...

MIDI HOOKUPS

0 of 11 connected

INSTRUMENT		PORT	PRIORITY	MIDI PATCH BAY
☐	Moog Sub 37	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned
☐	Waldorf Streichfett	MIDI In	Required	Not assigned
		MIDI Out	Low priority	Not assigned
☐	MFB Tanzbar	MIDI In	Required	Not assigned
		Check which MIDI ports it has	Low priority	Not assigned
☐	Sim n Tonic	MIDI In	Required	Not assigned
		Check which MIDI ports it has		
☐	Oberheim OB-X8	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned
☐	Oberheim OB-6	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned