

STUDIO CARQUINEZ PATCH BAY

Front view, top of rack first. Left 16 ports: console buckets. Right 8: outboard, FX, monitoring. Generated 2026-09-20 from config.py.

Console core

Room sends

Tie lines

Outboard

Instruments & pedals

Aux sends & FX

Monitoring

2-track

Groups & mix bus

Amp rack

Network

Power

MIDI

Spare

Reserved

Normalled

Not normalled

MAIN RACK

1

24 × 2 · 5
spare · 0
normalled

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Tanzbar Out L	Sub 37 Out	Fuzz In	MXR Dist In	Reserved · Instruments & pedals					LA-2A In	UA 550 In	DBX 160 Link	SSL Fusion In L/R	API L/R In			Dbx 160A L/R In	D-Comp L/R In		902 De-esser IN 1-2		Art Comp In L/R		
Tanzbar Out R		Fuzz Out	MXR Dist Out	Reserved · Instruments & pedals					LA-2A Out	UA 550 Out	DBX 160 Link	SSL Fusion Out L/R	API L/R Out			Dbx 160A L/R Out	D-Comp L/R Out		902 De-esser OUT 1-2		Art Comp Out L/R		

2

24 × 2 · 0
spare · 16
normalled

Ghost Channel Insert Send 1-16																Group 1 - 8 Insert Send							
NORMALLED																NORMALLED							
Ghost Channel Insert Return 1-16																Group 1 - 8 Insert Return							

3

24 × 2 · 0
spare · 24
normalled

Ghost Channel Insert Send 17-32																Aux 1 Out								Aux 2 Out		Aux 3 Out		Aux 4 Out		Aux 5 / 6 Out		Aux 7 Out L/R	
NORMALLED																N								N		N		N		NORMALLED		NORMALLED	
Ghost Channel Insert Return 17-32																EMT 140 In								PCM60 In		SDE 1000 In		Moog DLY In					

4

24 × 2 · 3
spare · 18
normalled

Worm hole Matched to Left Side Patch bay 1-16 top																Aux 8 Out L/R								Moog DLY Out						Main Insert Send	
NORMALLED																O								O		O		O		NORMALLED	
Console Line In 1-16																														Main Insert Return	


5

24 × 2 · 8
spare · 16
normalled

Worm hole Matched to Left Side Patch bay 1-16 bottom																															
NORMALLED																															
Console Line In 17-32																															


6

24 × 2 · 8
spare · 16
normalled




7

24 × 2 · 0
spare · 22
normalled




8

24 × 2 · 0
spare · 24
normalled




9

24 × 2 · 0
spare · 22
normalled



10

24 × 2 · 2
spare · 0
normalled



AMP RACK

11 AMP RACK

24 × 2 · 16 spare · 8 normalled

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L / R Audio Source Out		DBX High Out L/R		DBX Mid Out L/R		DBX Low Out L/R																	
NORMALLED		NORMALLED		NORMALLED		NORMALLED																	
DBX Drive Rack L/R IN		High Amp In L/R		Mid Amp In L/R		Low Amp In L/R																	

ETHERNET

ETHERNET

Single row · 2 spare

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Hearback Out 1-8								Kitchen	Bath Up	Bath Dn	Den	Gallery	Master Bed	Guest Bed	Office	Front Deck	Back Deck		

MIDI

MIDI

Single row · 0 spare

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
MIDI 1	MIDI 2	MIDI 3	MIDI 4	MIDI 5	MIDI 6	MIDI 7	MIDI 8	MIDI 9	MIDI 10	MIDI 11	MIDI 12	MIDI 13	MIDI 14	MIDI 15	MIDI 16	MIDI 17	MIDI 18	MIDI 19	MIDI 20	MIDI 21	MIDI 22

POWER SWITCHES

POWER SWITCHES

Single row · 0 spare

1	2	3	4	5	6	7	8	9	10
Switch 1	Switch 2	Switch 3	Switch 4	Switch 5	Switch 6	Switch 7	Switch 8	Switch 9	Switch 10

Moving the Patch Bay Units

Move whole units instead of re-setting normalising channel by channel. With the moves below you flip **4** normalising cards; keeping every unit in its old position would mean flipping **59**. Units already in the right place are marked "Already in place"; where units are mounted now comes from `installed_units` in `config.py`. Units only move within their own rack, and spare ports don't count.

Reading a card: **normalised** (standard) has the grey jack on the **front bottom** row; **not normalised** (turned) has the grey jack on the **rear top** row. "Check" means the old layout had that port unused, so its card position was never recorded. Look at it before mounting the unit.

0 of 3 done

POSITION		UNIT TO PUT THERE	NORMALLING CARDS TO FLIP	
☐	Bay 1 Main rack	Unit from old bay 9 not mounted · old layout: Main Insert Send	Ports 1–2 → not normalised	Check ports 10–16, 18 are not normalised
–	Bay 2 Main rack	Already in place now at bay 2 · old layout: Apollo #2 17-32 Out	No cards to flip	
–	Bay 3 Main rack	Already in place now at bay 3 · old layout: Ghost 17-32 Tape Send	No cards to flip	
–	Bay 4 Main rack	Already in place now at bay 4 · old layout: Worm hole Matched to Left Side Patch bay 1-16 top	No cards to flip	
–	Bay 5 Main rack	Already in place now at bay 5 · old layout: Ghost Channel Insert Send 1-16	No cards to flip	
–	Bay 6 Main rack	Already in place now at bay 6 · old layout: Ghost Channel Insert Send 17-32	No cards to flip	
–	Bay 7 Main rack	Already in place now at bay 7 · old layout: Apollo #1 1-16 Out	No cards to flip	
–	Bay 8 Main rack	Already in place now at bay 8 · old layout: Worm hole Matched to Left Side Patch bay 1-16 bottom	No cards to flip	
☐	Bay 9 Main rack	Already in place now at bay 9 · old layout: Ghost 1-16 Tape Send	Ports 23–24 → not normalised	
☐	Bay 10 Main rack	Already in place now at bay 10 · old layout: Kitchen L	Check ports 11–14 are not normalised	
–	Bay 11-amp-rack Amp rack	Already in place now at bay 11-amp-rack · old layout: L / R Audio Source Out	No cards to flip	

RACK 1 · EQUIPMENT (20U)

U1	POWER CONDITIONER
U2	SWITCH PANEL Patch bay: Power Switches · 1-10
U3	APOLLO 16 #1 Replacing both Apollos with one 1U unit Patch bay: Bay 6 · 1-16, Bay 8 · 1-16
U4	APOLLO 16 #2 Replacing both Apollos with one 1U unit Patch bay: Bay 7 · 1-16, Bay 9 · 1-16
U5	API 2500 COMPRESSOR Patch bay: Bay 1 · 15-16
U6-7	D-COMP Patch bay: Bay 1 · 19-20
U8	DBX 902 DE-ESSER ×2 Patch bay: Bay 1 · 21-22
U9	LEXICON PCM 60 REVERB Patch bay: Bay 3 · 18, Bay 7 · 19-20
U10	SDE 1000 DELAY Patch bay: Bay 3 · 19, Bay 7 · 21-22
U11-12	DBX 160 COMPRESSORS Patch bay: Bay 1 · 12, 17-18
U13	EMT REVERB REMOTE Could move
U14	HEADPHONE AMP Could move Patch bay: Bay 9 · 23-24
U15	MIDI PATCH BAY Patch bay: Midi · 1-22
U16-17	COMPUTER SHELF
U18	EMPTY ? U18 not listed - empty?
U19-20	SOUNDCRAFT GHOST POWER SUPPLY Could move

OPEN QUESTIONS

- Midi, port 1

Channel labels needed for all 22 MIDI jacks
- Power Switches, port 1

Label what each of the 10 power switches turns on