

STUDIO CARQUINEZ PATCH BAY

Front view, top of rack first. Left 16 ports: console buckets. Right 8: outboard, FX, monitoring. Generated 2026-09-23 from config.py.

Console core

Room sends

Tie lines

Outboard

Instruments & pedals

Aux sends & FX

Monitoring

2-track

Groups & mix bus

Amp rack

Network

Power

MIDI

Spare

Reserved

Rear not plugged in yet

Normalled

Not normalled

MAIN RACK

1

24 x 2

5 spare

0 normalled

0/37 rear plu

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Tanzb ar Out L	Sub 37 Out	Fuzz In	MXR Dist In	Reserved · Instruments & pedals					LA-2A In	UA 550 In	DBX 160 Link	SSL Fusion In L/R	API L/R In		Dbx 160A L/R In	D-Comp L/R In	902 De-esser IN 1-2		Art Comp In L/R				
Tanzb ar Out R		Fuzz Out	MXR Dist Out	Reserved · Instruments & pedals					LA-2A Out	UA 550 Out	DBX 160 Link	SSL Fusion Out L/R	API L/R Out		Dbx 160A L/R Out	D-Comp L/R Out	902 De-esser OUT 1-2		Art Comp Out L/R				

2

24 x 2

0 spare

16 normalled

0/48 rear plu

Ghost Channel Insert Send 1-16																Group 1 - 8 Insert Send							
NORMALLED																NORMALLED							
Ghost Channel Insert Return 1-16																Group 1 - 8 Insert Return							

3

24 x 2

0 spare

24 normalled

0/44 rear plu

Ghost Channel Insert Send 17-32																Aux 1 Out								Aux 2 Out	Aux 3 Out	Aux 4 Out	Aux 5 / 6 Out		Aux 7 Out L/R	
NORMALLED																N								N	N	N	NORMALLED		NORMALLED	
Ghost Channel Insert Return 17-32																EMT 140 In								PCM60 In	SDE 1000 In	Moog DLY In				

4

24 x 2

3 spare

18 normalled

0/39 rear plu

Worm hole Matched to Left Side Patch bay 1-16 top																Aux 8 Out L/R								Moog DLY Out			Main Insert Send			
NORMALLED																O								O	O	O	NORMALLED		NORMALLED	
Console Line In 1-16																											Main Insert Return			

5

24 x 2

8 spare


16 normalled

0/32 rear plu

Worm hole Matched to Left Side Patch bay 1-16 bottom																															
NORMALLED																															
Console Line In 17-32																															


6

24 x 2
8 spare
16 normalled
0/32 rear plu




7

24 x 2
0 spare
22 normalled
0/46 rear plu




8

24 x 2
0 spare
24 normalled
0/47 rear plu




9

24 x 2
0 spare
22 normalled
0/44 rear plu



10


24 x 2
3 spare
0 normalled
0/42 rear plu



AMP RACK

11 AMP RACK


24 x 2
16 spare
8 normalled
0/16 rear plug



ETHERNET

ETHERNET


Single row
2 spare
0/8 rear plug



MIDI

MIDI


Not in use
Single row
0 spare
0/22 rear plug



POWER SWITCHES

POWER SWITCHES

Single row
1 spare
0/9 rear plug



RACK 1 · EQUIPMENT (20U)

U1	POWER CONDITIONER	
U2	SWITCH PANEL	Not on the patch bay
U3	APOLLO 16 #1	Replacing both Apollos with one 1U unitPatch bay: Bay 6 · 1–16, Bay 8 · 1–16
U4	APOLLO 16 #2	Replacing both Apollos with one 1U unitPatch bay: Bay 7 · 1–16, Bay 9 · 1–16
U5	API 2500 COMPRESSOR	Patch bay: Bay 1 · 15–16, Power Switches · 3
U6–7	D-COMP	Patch bay: Bay 1 · 19–20, Power Switches · 4
U8	DBX 902 DE-ESSER ×2	Patch bay: Bay 1 · 21–22, Power Switches · 5
U9	LEXICON PCM 60 REVERB	Patch bay: Bay 3 · 18, Bay 7 · 19–20, Power Switches · 6
U10	SDE 1000 DELAY	Patch bay: Bay 3 · 19, Bay 7 · 21–22, Power Switches · 7
U11–12	DBX 160 COMPRESSORS	Patch bay: Bay 1 · 12, 17–18, Power Switches · 8–9
U13	EMT REVERB REMOTE	Could move
U14	HEADPHONE AMP	Could movePatch bay: Bay 9 · 23–24
U15	HEADPHONE POWER SUPPLY	
U16	MIDI PATCH BAY	Patch bay: <u>Midi</u> · 1–22
U17	HEARBACK UNIT	Patch bay: Bay 10 · 17–24, Ethernet · 1–8
U18	ETHERNET PATCH BAY	Patch bay: <u>Ethernet</u> · 1–20
U19–20	SOUNDCRAFT GHOST POWER SUPPLY	

OPEN QUESTIONS

CABLE PULLS TO EACH ROOM

Two XLR sends, one XLR return and one Cat5 per room. Every XLR end is soldered to its cable, so each one takes three steps: pull it, solder the room end, solder the rack end (Cat5 ends are terminated instead) — **129** steps in all. The destination is where the cable lands at the rack.

KITCHEN0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 1 top

XLR at the room, TRS into the patch bay

Send R XLR

Bay 10 · port 1 bottom

XLR at the room, TRS into the patch bay

Return XLR

Loom on the floor - no patching yet

XLR both ends

Network CAT5

Ethernet · jack 9

Notes...

BATH UP0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 2 top

XLR at the room, TRS into the patch bay

Send R XLR

Bay 10 · port 2 bottom

XLR at the room, TRS into the patch bay

Return XLR

Loom on the floor - no patching yet

XLR both ends

Network CAT5

Ethernet · jack 10

Notes...

BATH DN0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 3 top

XLR at the room, TRS into the patch bay

Send R XLR

Bay 10 · port 3 bottom

XLR at the room, TRS into the patch bay

Return XLR

Loom on the floor - no patching yet

XLR both ends

Network CAT5

Ethernet · jack 11

Notes...

DEN0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 4 top

XLR at the room, TRS into the patch bay

Send R XLR

Bay 10 · port 4 bottom

XLR at the room, TRS into the patch bay

Return XLR

Loom on the floor - no patching yet

XLR both ends

Network CAT5

Ethernet · jack 12

Notes...

GALLERY0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 5 top

XLR at the room, TRS into the patch bay

Send R XLR

Bay 10 · port 5 bottom

XLR at the room, TRS into the patch bay

Return XLR

Loom on the floor - no patching yet

XLR both ends

Network CAT5

Ethernet · jack 13

Notes...

MASTER BED0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 6 top

XLR at the room, TRS into the patch bay

Send R XLR

Bay 10 · port 6 bottom

XLR at the room, TRS into the patch bay

Return XLR

Loom on the floor - no patching yet

XLR both ends

Network CAT5

Ethernet · jack 14

Notes...

GUEST BED0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 7 top

XLR at the room, TRS into the patch bay

Send R XLR

Bay 10 · port 7 bottom

XLR at the room, TRS into the patch bay

Return XLR

Loom on the floor - no patching yet

XLR both ends

Network CAT5

Ethernet · jack 15

Notes...

OFFICE0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 8 top

XLR at the room, TRS into the patch bay

Send R XLR

Bay 10 · port 8 bottom

XLR at the room, TRS into the patch bay

Return XLR

Loom on the floor - no patching yet

XLR both ends

Network CAT5

Ethernet · jack 16

Notes...

RECORD PLAYER0/12

PULL ROOMRACK

Send L XLR

Bay 10 · port 9 top

XLR at the room, TRS into the patch bay

☐☐☐

Send R XLR

Bay 10 · port 9 bottom

XLR at the room, TRS into the patch bay

☐☐☐

Return XLR

Loom on the floor - no patching yet

XLR both ends

☐☐☐

Network CAT5

Ethernet · jack 17

Notes...

FRONT DECK0/3

PULL ROOMRACK

Speaker SPEAKER

Amp out to the speaker - not on a patch bay

☐☐☐

Notes...

BACK DECK0/3

PULL ROOMRACK

Speaker SPEAKER

Amp out to the speaker - not on a patch bay

☐☐☐

Notes...

GARAGE (G1) · EMT PLATE0/15

PULL ROOMRACK

Send XLR

☐☐☐

Return L XLR

☐☐☐

Return R XLR

☐☐☐

Motor control 7-PIN

☐☐☐

Network CAT5

☐☐☐

Notes...

MIDI HOOKUPS

0 of 11 connected

INSTRUMENT		PORT	PRIORITY	MIDI PATCH BAY
☐	Moog Sub 37	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned
☐	Waldorf Streichfett	MIDI In	Required	Not assigned
		MIDI Out	Low priority	Not assigned
☐	MFB Tanzbar	MIDI In	Required	Not assigned
		Check which MIDI ports it has	Low priority	Not assigned
☐	Sim n Tonic	MIDI In	Required	Not assigned
		Check which MIDI ports it has		
☐	Oberheim OB-X8	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned
☐	Oberheim OB-6	MIDI In	Required	Not assigned
		MIDI Out	Required	Not assigned