

STUDIO CARQUINEZ PATCH BAY

Front view, top of rack first. Left 16 ports: console buckets. Right 8: outboard, FX, monitoring. Generated 2026-09-20 from config.py.

Console core

Room sends

Tie lines

Outboard

Instruments & pedals

Aux sends & FX

Monitoring

2-track

Groups & mix bus

Amp rack

Network

Power

MIDI

Spare

Reserved

Normalled

Not normalled

MAIN RACK

1

24 × 2 · 5
spare · 0
normalled

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Tanzbar Out L	Sub 37 Out	Fuzz In	MXR Dist In	Reserved · Instruments & pedals					LA-2A In	UA 550 In	DBX 160 Link	SSL Fusion In L/R	API L/R In		Dbx 160A L/R In	D-Comp L/R In	902 De-esser IN 1-2		Art Comp In L/R				
Tanzbar Out R		Fuzz Out	MXR Dist Out	Reserved · Instruments & pedals					LA-2A Out	UA 550 Out	DBX 160 Link	SSL Fusion Out L/R	API L/R Out		Dbx 160A L/R Out	D-Comp L/R Out	902 De-esser OUT 1-2		Art Comp Out L/R				

2

24 × 2 · 0
spare · 16
normalled

Ghost Channel Insert Send 1-16																Group 1 - 8 Insert Send							
NORMALLED																NORMALLED							
Ghost Channel Insert Return 1-16																Group 1 - 8 Insert Return							

3

24 × 2 · 0
spare · 24
normalled

Ghost Channel Insert Send 17-32																Aux 1 Out								Aux 2 Out		Aux 3 Out		Aux 4 Out		Aux 5 / 6 Out		Aux 7 Out L/R	
NORMALLED																N		N		N		N		NORMALLED		NORMALLED							
Ghost Channel Insert Return 17-32																EMT 140 In		PCM60 In		SDE 1000 In		Moog DLY In											

4

24 × 2 · 3
spare · 18
normalled

Worm hole Matched to Left Side Patch bay 1-16 top																Aux 8 Out L/R								Moog DLY Out				Main Insert Send	
NORMALLED																								NORMALLED					
Console Line In 1-16																								Main Insert Return					


5

24 × 2 · 8
spare · 16
normalled

Worm hole Matched to Left Side Patch bay 1-16 bottom																													
NORMALLED																													
Console Line In 17-32																													


6

24 × 2 · 8
spare · 16
normalled




7

24 × 2 · 0
spare · 22
normalled




8

24 × 2 · 0
spare · 24
normalled




9

24 × 2 · 0
spare · 22
normalled



10

24 × 2 · 2
spare · 0
normalled



AMP RACK

11 AMP RACK

24 × 2 · 16 spare · 8 normalled

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L / R Audio Source Out		DBX High Out L/R		DBX Mid Out L/R		DBX Low Out L/R																	
NORMALLED		NORMALLED		NORMALLED		NORMALLED																	
DBX Drive Rack L/R IN		High Amp In L/R		Mid Amp In L/R		Low Amp In L/R																	

ETHERNET

ETHERNET

Single row · 2 spare

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Hearback Out 1-8								Kitchen	Bath Up	Bath Dn	Den	Gallery	Master Bed	Guest Bed	Office	Front Deck	Back Deck		

MIDI

MIDI

Single row · 0 spare

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
MIDI 1	MIDI 2	MIDI 3	MIDI 4	MIDI 5	MIDI 6	MIDI 7	MIDI 8	MIDI 9	MIDI 10	MIDI 11	MIDI 12	MIDI 13	MIDI 14	MIDI 15	MIDI 16	MIDI 17	MIDI 18	MIDI 19	MIDI 20	MIDI 21	MIDI 22

POWER SWITCHES

POWER SWITCHES

Single row · 0 spare

1	2	3	4	5	6	7	8	9	10
Switch 1	Switch 2	Switch 3	Switch 4	Switch 5	Switch 6	Switch 7	Switch 8	Switch 9	Switch 10

RACK 1 · EQUIPMENT (20U)

U1	POWER CONDITIONER
U2	SWITCH PANEL Patch bay: Power Switches · 1-10
U3	APOLLO 16 #1 Replacing both Apollos with one 1U unit Patch bay: Bay 6 · 1-16, Bay 8 · 1-16
U4	APOLLO 16 #2 Replacing both Apollos with one 1U unit Patch bay: Bay 7 · 1-16, Bay 9 · 1-16
U5	API 2500 COMPRESSOR Patch bay: Bay 1 · 15-16
U6-7	D-COMP Patch bay: Bay 1 · 19-20
U8	DBX 902 DE-ESSER ×2 Patch bay: Bay 1 · 21-22
U9	LEXICON PCM 60 REVERB Patch bay: Bay 3 · 18, Bay 7 · 19-20
U10	SDE 1000 DELAY Patch bay: Bay 3 · 19, Bay 7 · 21-22
U11-12	DBX 160 COMPRESSORS Patch bay: Bay 1 · 12, 17-18
U13	EMT REVERB REMOTE Could move
U14	HEADPHONE AMP Could move Patch bay: Bay 9 · 23-24
U15	MIDI PATCH BAY Patch bay: Midi · 1-22
U16-17	COMPUTER SHELF
U18	EMPTY ? U18 not listed - empty?
U19-20	SOUNDCRAFT GHOST POWER SUPPLY Could move

OPEN QUESTIONS

- Midi, port 1

Channel labels needed for all 22 MIDI jacks
- Power Switches, port 1

Label what each of the 10 power switches turns on